



(ENG) pRack pR300T user manual for the management of CO₂ systems in transcritical conditions

**→ LEGGI E CONSERVA
QUESTE ISTRUZIONI ←**
**→ READ AND SAVE
THESE INSTRUCTIONS ←**

  **NO POWER
& SIGNAL
CABLES
TOGETHER**
READ CAREFULLY IN THE TEXT!

IMPORTANT



CAREL bases the development of its products on decades of experience in HVAC, on the continuous investments in technological innovations to products, procedures and strict quality processes with in-circuit and functional testing on 100% of its products, and on the most innovative production technology available on the market. CAREL and its subsidiaries nonetheless cannot guarantee that all the aspects of the product and the software included with the product respond to the requirements of the final application, despite the product being developed according to start-of-the-art techniques. The customer (manufacturer, developer or installer of the final equipment) accepts all liability and risk relating to the configuration of the product in order to reach the expected results in relation to the specific final installation and/or equipment. CAREL may, based on specific agreements, act as a consultant for the positive commissioning of the final unit/application, however in no case does it accept liability for the correct operation of the final equipment/system.

The CAREL product is a state-of-the-art product, whose operation is specified in the technical documentation supplied with the product or can be downloaded, even prior to purchase, from the website www.CAREL.com. Each CAREL product, in relation to its advanced level of technology, requires setup / configuration / programming / commissioning to be able to operate in the best possible way for the specific application. The failure to complete such operations, which are required/indicated in the user manual, may cause the final product to malfunction; CAREL accepts no liability in such cases.

Only qualified personnel may install or carry out technical service on the product.

The customer must only use the product in the manner described in the documentation relating to the product.

In addition to observing any further warnings described in this manual, the following warnings must be heeded for all CAREL products:

- Prevent the electronic circuits from getting wet. Rain, humidity and all types of liquids or condensate contain corrosive minerals that may damage the electronic circuits. In any case, the product should be used or stored in environments that comply with the temperature and humidity limits specified in the manual.
- Do not install the device in particularly hot environments. Too high temperatures may reduce the life of electronic devices, damage them and deform or melt the plastic parts. In any case, the product should be used or stored in environments that comply with the temperature and humidity limits specified in the manual.
- Do not attempt to open the device in any way other than described in the manual.
- Do not drop, hit or shake the device, as the internal circuits and mechanisms may be irreparably damaged.
- Do not use corrosive chemicals, solvents or aggressive detergents to clean the device.
- Do not use the product for applications other than those specified in the technical manual.

All of the above suggestions likewise apply to the controllers, serial boards, programming keys or any other accessory in the CAREL product portfolio.

CAREL adopts a policy of continual development. Consequently, CAREL reserves the right to make changes and improvements to any product described in this document without prior warning.

The technical specifications shown in the manual may be changed without prior warning.

The liability of CAREL in relation to its products is specified in the CAREL general contract conditions, available on the website www.CAREL.com and/or by specific agreements with customers; specifically, to the extent where allowed by applicable legislation, in no case will CAREL, its employees or subsidiaries be liable for any lost earnings or sales, losses of data and information, costs of replacement goods or services, damage to things or people, downtime or any direct, indirect, incidental, actual, punitive, exemplary, special or consequential damage of any kind whatsoever, whether contractual, extra-contractual or due to negligence, or any other liabilities deriving from the installation, use or impossibility to use the product, even if CAREL or its subsidiaries are warned of the possibility of such damage.

DISPOSAL




Fig. 1 Fig.2

Please read and keep.

With reference to European Union directive 2012/19/EU issued on 4 July 2012 and related national legislation, please note that:

1. Waste Electrical and Electronic Equipment (WEEE) cannot be disposed of as municipal waste but must be collected separately so as to allow subsequent recycling, treatment or disposal, as required by law;
2. users are required to take Electrical and Electronic Equipment (EEE) at end-of-life, complete with all essential components, to the WEEE collection centres identified by local authorities. The directive also provides for the possibility to return the equipment to the distributor or retailer at end-of-life if purchasing equivalent new equipment, on a one-to-one basis, or one-to-zero for equipment less than 25 cm on their longest side;
3. this equipment may contain hazardous substances: improper use or incorrect disposal of such may have negative effects on human health and on the environment;
4. the symbol (crossed-out wheeled bin – Fig.1) even if, shown on the product or on the packaging, indicates that the equipment must be disposed of separately at end-of-life;
5. if at end-of-life the EEE contains a battery (Fig. 2), this must be removed following the instructions provided in the user manual before disposing of the equipment. Used batteries must be taken to appropriate waste collection centres as required by local regulations;
6. in the event of illegal disposal of electrical and electronic waste, the penalties are specified by local waste disposal legislation.

Warranty on the materials: 2 years (from the date of production, excluding consumables).

Approval: the quality and safety of CAREL INDUSTRIES Hqs products are guaranteed by the ISO 9001 certified design and production system.

WARNING:

READ CAREFULLY IN THE TEXT!

separate as much as possible the probe and digital input signal cables from the cables carrying inductive loads and power cables to avoid possible electromagnetic disturbance.
Never run power cables (including the electrical panel wiring) and signal cables in the same conduits.

Key icons

	NOTE:	to bring attention to a very important subject; in particular, regarding the practical use of the various functions of the product.
	IMPORTANT:	to bring critical issues regarding the use of the pRack PR300 to the attention of the user.
	TUTORIAL:	some simple examples to accompany the user in configuring the most common settings.

CAREL reserves the right to modify the features of its products without prior notice.

Content

1. INTRODUCTION	7	7. PARAMETERS AND ALARMS TABLE	61
1.1 Main features	7	7.1 Parameter table	61
1.2 Components and accessories	7	7.2 Alarm table	82
1.3 Configuration of the system and configuration of the inputs and outputs	8	7.3 I/O Table	85
2. HARDWARE CHARACTERISTICS AND INSTALLATION	9	8. ALARMS	91
2.1 pRack 300 S, M, D, L board description	9	8.1 Alarm management	91
2.2 Technical specifications	11	8.2 Compressor alarms	91
2.3 pRack pR300T S, M, D, L board dimensions	16	8.3 Pressure and prevent alarms	92
2.4 pRack pR300T general connection diagram	17	9. SUPERVISORY AND COMMISSIONING SYSTEMS	94
2.5 Expansion card	22	9.1 PlantVisor PRO and PlantWatch PRO supervisory systems	94
3. INSTALLATION	23	9.2 Commissioning software	94
3.1 General installation instructions	23	10. SOFTWARE UPDATE AND CONFIGURATION	95
3.2 Power supply	23	10.1 Smart Key: operating instructions	95
3.3 Connecting the analogue inputs	23	10.2 pRack Manager: operating instructions	96
3.4 Connecting the digital inputs	25	10.3 Pendrive: operating instructions	97
3.5 Connecting the analogue outputs	26	10.4 Configuring pCOWeb/pCOnet from a system screen	101
3.6 Connecting the digital outputs	26	11. APPENDIX	102
3.7 pLAN electrical connections	27		
4. START UP	28		
4.1 Starting the first time	28		
4.2 Wizard	28		
4.3 Example of system configuration using the Wizard	28		
4.4 Advanced configuration	29		
5. USER INTERFACE	30		
5.1 Graphic terminal	30		
5.2 Description of the display	30		
5.3 Password	31		
5.4 Menu description	32		
6. FUNCTIONS	33		
6.1 Schematic diagram and system configurations used	33		
6.2 Unit On-Off	34		
6.3 Control	34		
6.4 Compressors	36		
6.5 Gas cooler	40		
6.6 HPV valve management	42		
6.7 RPRV valve management	44		
6.8 Intercooler	44		
6.9 Energy saving	45		
6.10 Accessory functions	46		
6.11 Oil management	46		
6.12 Subcooling	48		
6.13 Heat recovery	48		
6.14 Generic functions	49		
6.15 Double line synchronization (DSS)	51		
6.16 EEVS: Electronic Expansion Valve Synchronization	52		
6.17 Settings	55		
6.18 Managing the default values	55		
6.19 Water chiller function	56		
6.20 Maximum capacity limit	58		
6.21 Valve backup function	59		
6.22 Double line inverter management	60		

1. INTRODUCTION

1.1 Main features

pRack pR300T is the integrated CAREL solution for control and management of CO₂ compressor racks.

The main features and compressor management characteristics of pRack pR300T are listed below.

1.1.1 pR300T functionality list

Main features	Possibility of management integrated in a single control for the medium temperature and low temperature line and the high pressure stage.
	Management of the high pressure valve (HPV)
	Management of the receiver pressure regulating valve (RPRV)
	Valves management via external or built-in (PRK30TD*) driver through fieldbus communication port or via external driver in position mode in 0...10V
	Integration between HPV and receiver pressure
	Accessory functions (pre-positioning, minimum and maximum values differentiated by machine ON and OFF, maximum distance from the setpoint, ...)
	Oil cooler
	Oil receiver and oil injection
	Heat Reclaim
	Integration between heat reclaim and HPV and RPRV valve management
	Double suction line and one high pressure stage
	Up to 16 fans for condensing line
	Inverter regulation on the first compressor and on the first fan
	Generic functions easily configurable (ON/OFF, modulations, alarms, scheduler)
	S, M, D, L version (based on pCO5+ hardware)
Hardware	External display (pGDE) or built-in display
Compressors	Scroll, reciprocating, digital scroll compressors management
	Up to 12 piston compressors per line, a maximum of 4 different sizes
	Up to 4 alarms per compressor
	Inverter management, even with modulation inside the dead zone
Lingue	Pump down
	Control of overheating in suction
	Italian, English, German, French, Spanish, Russian, Portuguese, Swedish
Unit of measure	Temperature: °C, °F
	Pressure: barg, psig (all pressure values are also converted to temperature)
	Date format settable between: dd/mm/yy, mm/dd/yy, yy.mm.dd
Control	Proportional band (P, PI) available for compressors and fans
	Neutral zone available for compressors and fans
Compressor rotation	FIFO
	LIFO
Scheduling by calendar	Timed
	Fixed (the ON/OFF order can be set as required)
	Scheduling available: heating/cooling, 4 daily time bands, 5 special periods (e.g.: closing period), 10 special days (e.g.: holidays)
Setpoint	Schedulable functions: set point compensation for compressors and fans, split condenser (heating/cooling only), anti noise, heat recovery, generic functions
	Compensation from digital input, from scheduling, floating based on supervisor parameter (compressors) or outside temperature (fans)
Prevent	High pressure, including activation of heat recovery or ChillBooster
Alarms	Automatic and manual management
	Configurable compressor alarms
	Double Signal on digital outputs for high or low priority alarms
Supervisor protocol	Log from application
	Carel Modbus®

Tab. 1.a

1.2 Components and accessories

The pRack pR300T is available in 4 hardware sizes listed in the table (for the detailed description of each size, electrical characteristics and installation, refer to Chapter 2):

Hardware sizes:

Size	Available analog inputs	Available digital inputs	Available analog outputs	Available digital outputs
Small	5 (*)	8	4	8
Medium	8 (*)	14	4	13
Medium + Driver	8(*) + 4	14+2	4	13
Large	10 (*)	18	6	18

Tab. 1.b

(*) can also be used as digital inputs

For each size the following versions are available:

- with built-in terminal, without terminal

All pRack pR300T models are equipped with:

- integrated RS485 serial interface
- anthracite gray plastic cover
- connector kit
- USB.

pRack pR300T models

Size	Code	Description
small	PRK30TS0E0	pRack PR300T small, USB, no display, BMS/FBUS OPTO, 2 SSR, connector kit
	PRK30TS3E0	pRack PR300T small, USB, display built-in, BMS/FBUS OPTO, 2 SSR, connector kit
	PRK30TS0F0	pRack PR300T small, USB, no display, BMS/FBUS opto, connector kit
	PRK30TS3F0	pRack PR300T small, USB, display built-in, BMS/FBUS opto, connector kit
medium	PRK30TS3FK	pRack PR300T small, USB, external display, BMS/FBUS opto, connector kit
	PRK30TM0E0	pRack PR300T medium, USB, no display, BMS/FBUS OPTO, 2 SSR, connector kit
	PRK30TM3E0	pRack PR300T medium, USB, display built-in, BMS/FBUS opto, 2 SSR, connector kit
	PRK30TM0F0	pRack PR300T medium, USB, no display, BMS/FBUS opto, connector kit
driver	PRK30TM3F0	pRack PR300T medium, USB, display built-in, BMS/FBUS opto, kit connettori
	PRK30TM3FK	pRack pR300T medium, USB, external display, BMS/FBUS opto, kit connettori
	PRK30TD0E0	pRack PR300T medium, EVD EVO embedded for 2 UNIV. EXV, USB, no display, BMS/FBUS opto, 2 SSR, connector kit
	PRK30TD3E0	pRack PR300T medium, EVD EVO embedded for 2 UNIV. EXV, USB, display built-in, BMS/FBUS opto, 2 SSR, connector kit
large	PRK30TD0F0	pRack PR300T medium, evd evo embedded for 2 univ. EXV, USB, no display, BMS/FBUS opto, connector kit
	PRK30TD3F0	pRack PR300T medium, evd evo embedded for 2 univ. EXV, USB, display built-in, BMS/FBUS opto, connector kit
	PRK30TD3FK	pRack PR300T medium, evd evo embedded for 2 univ. EXV, USB, external display, BMS/FBUS opto, connector kit
	PRK30TL0E0	pRack PR300T large, USB, no display, BMS/FBUS OPTO, 6 SSR, connector kit
	PRK30TL3E0	pRack PR300T large, USB, display built-in, BMS/FBUS opto, 6 SSR, connector kit
large	PRK30TL0F0	pRack PR300T large, USB, no display, BMS/FBUS opto, connector kit
	PRK30TL3F0	pRack pR300T large, USB, display built-in, BMS/FBUS opto, connector kit
	PRK30TL3FK	pRack pR300T large, USB, external display, BMS/FBUS opto, connector kit

Tab. 1.c

Accessories:

Code	Description
PGDERK1FX0	pGD evolution user terminal for pRack pR300T
CONVONOFF0	Module to convert a 0...10V analog output to an SPDT digital output
CVSTDUTLF0	USB/RS485 serial convertor with telephone connector
CVSTDUMORO	USB/RS485 serial converter with 3-way terminal
PCOS00AKY0	Smart Key programming key
S90CONN002	Connection cable for terminal 1=0.8m
S90CONN000	Connection cable for terminal 1=1.5m
S90CONN001	Connection cable for terminal 1=3 m
SPKT*R* and SPKC00*	Ratiometric pressure probes 0...5 Vdc
SPK*C*, SPK1*, SPK2*, SPK3*	Active pressure probes 4...20 mA
NTC*	Pressure probe NTC -50T90°C
NTC*HT*	Pressure probe NTC -0T150°C
EVD0000E50	EVD EVO universal driver for Carel valves, RS485/Modbus™
EVDIS00D*0	Display for EVD EVO
E2VCABS*00	EVD-valve connection cable

Tab. 1.d

1.3 Configuration of the system and configuration of the inputs and outputs

pRack pR300T has the same system configuration management and input and output configuration management as the standard pRack.

Note: each input/output is completely configurable with the only requirements being those set by the system configuration. For example, the suction pressure probe on line 1 can be arbitrarily configured to any one of the analog inputs in the pLAN control board with address 1 compatible with the type of probe.

1.3.1 System configurations available

pRack pR300T can manage system configurations with up to 2 suction lines (maximum 12 scroll or piston compressors for lines 1 and 2) and up to 1 high pressure line (maximum 16 fans per line). When there are two suction lines, the lines can be managed by the same pRack board or by separate boards. The condenser line can be managed by the board that manages the suction line, or by a separate board, in accordance with the number of inputs/outputs available.

For each line, both suction and condensing, pRack pR300T can manage a modulating device (inverter, Digital Scroll® compressor or compressor with continuous control).

Example 1: 1 suction line with scroll or piston compressors, 1 high pressure line:




Fig. 1.a

Example 2: 2 suction lines on the same board with scroll or piston compressors, 1 high pressure line:




Fig. 1.b

Example 3: 2 suction lines on separate boards (scroll or piston compressors), 1 high pressure line (on the first suction line board):




Fig. 1.c

Example 4: 2 suction lines on separate boards with scroll or piston compressors, 1 high pressure line on separate board:




Fig. 1.d

Note: if connecting more than one pRack pR300 board in a pLAN, mixed networks cannot be created combining Compact boards and S, M, L boards, while mixed networks are possible using combinations of the latter models only.

Important: all the boards connected to the pLAN must have the same software revision.

2. HARDWARE CHARACTERISTICS AND INSTALLATION

2.1 pRack 300 S, M, D, L board description

pRack pR300T S




Fig. 2.a

pRack pR300T M




Fig. 2.b

Key:

Ref.	Description
1	Power supply connector [G(+), G0(-)]
2	+Vterm: power supply for additional terminal+5 VREF power supply for ratiometric probes
3	Universal inputs/outputs
4	+VDC: power supply for active probes
5	Button for setting pLAN address, second display, LED
6	VG: power supply at voltage A(*) for opto-isolated analogue output
7	VG0: power to opto-isolated analogue output, 0 Vac/Vdc
8	ID: digital inputs for voltage A (*)
9	ID.: digital inputs for voltage A (*)
10	IDH.: digital inputs for voltage B (**)
10	pLAN telephone connector for terminal/downloading application

Ref.	Description
11	pLAN plug-in connector
12	Reserved
13	Reserved
14	Reserved
15	Relay digital outputs
16	BMS2 connector
17	FieldBus2 connector
18	Jumpers for selecting FieldBus/ BMS

(*) Voltage A: 24 Vac or 28 to 36 Vdc; (**) Voltage B: 230 Vac - 50/60 Hz.

Tab. 2.a

pRack pR300T D




Fig. 2.c

Key:

Ref.	Description	Ref.	Description
1	Power supply connector [G(+), G0(-)]	13	Reserved
2	+Vterm: power supply for additional terminal +5 VREF power supply for ratiometric probes	14	Reserved
3	Universal inputs/outputs	15	Relay digital outputs
4	+VDC: power supply for active probes	16	BMS2 connector
5	Button for setting pLAN address, second display, LED	17	FieldBus2 connector
6	VG: power supply at voltage A(*) for opto-isolated analogue output VG0: power to opto-isolated analogue output, 0 Vac/Vdc	18	Jumpers for selecting FieldBus/ BMS
7	Analogue outputs	20	Electronic valve A connector
8	ID: digital inputs for voltage A (*)	21	Electronic valve B connector
9	ID...: digital inputs for voltage A (*); IDH...: digital inputs for voltage B (**)	22	Connector for external Ultracap module (accessory)
10	pLAN telephone connector for terminal/downloading application	23	Valve driver analogue and digital inputs
11	pLAN plug-in connector	24	Valve status signal LED
12	Reserved		

Tab. 2.b

pRack pR300T L




Fig. 2.d

Key:

Ref.	Description	Ref.	Description
1	Power supply connector [G(+), G0(-)]	11	pLAN plug-in connector
2	+Vterm: power supply for additional terminal +5 VREF power supply for ratiometric probes	12, 13, 14	Reserved
5	Button for setting pLAN address, second display, LED	15	Relay digital outputs
6	VG: power supply at voltage A(*) for opto-isolated analogue output VG0: power to opto-isolated analogue output, 0 Vac/Vdc	16	BMS2 connector
7	Analogue outputs	17	FieldBus2 connector
8	ID: digital inputs for voltage A (*)	18	Jumpers for selecting FieldBus/ BMS
9	ID...: digital inputs for voltage A (*); IDH...: digital inputs for voltage B (**)	19	FieldBus2 connector
10	pLAN telephone connector for terminal/downloading application		

Tab. 2.c

2.2 Technical specifications

2.2.1 Physical specifications

Dimensions	SMALL	13 DIN modules	110 X 227,5 X 60 mm
	MEDIUM, LARGE	18 DIN modules	110 X 315 X 60 mm
	BUILT-IN DRIVER	18 DIN modules	110 X 315 X 75 mm
Plastic case	Assembly	fitted on DIN rail in accordance with DIN 43880 CEI EN 50022	
	Material	technopolymer	
	Flammability	V2 (UL94) and 850 °C (in accordance with IEC 60695)	
	Ball pressure test	125 °C	
	Resistance to creeping current	≥ 250 V	
Built-in terminal	Colour	Antracite	
	PGDE (132x64 pixel) with backlit keypad		
Other features	Operating conditions	PRK300T*3**, PRK300T*0**(w/o built-in terminal): -40T70 °C, 90% RH non-condensing(*) PRK300T*3*0 (with built-in terminal): -20T60 °C, 90% RH non-condensing (*) with Ultracap module fitted: -40T60°C	
	Storage conditions	PRK300TD*** (w/o built-in terminal): -40T70 °C, 90% RH non-condensing PRK300TD*** (with built-in terminal): -30T70 °C, 90% RH non-condensing	
	Ingress protection	Models with USB port and/or with Ultracap module: IP20 on the front panel only Models without USB port and without Ultracap module: IP40 on the front panel only	
	Environmental pollution	2	
	Class according to protection against electric shock	to be integrated into Class I and/or II appliances in the versions without valve driver, class I in the versions with valve driver	
	PTI of the insulating materials	PCB: PTI 250 V; insulating material: PTI 175	
	Period of stress across the insulating parts	long	
	Type of action	1C; 1Y for SSR versions	
	Type of disconnection or microswitching	microswitching	
	Heat and fire resistance category	Category D (UL94-V2)	
Ageing characteristics (operating hours)	80,000		
Number of automatic operating cycles	100,000 (EN 60730-1); 30,000 (UL 873)		
Overvoltage category	category II		

Tab. 2.d

2.2.2 Electrical specifications

Power supply	SMALL, MEDIUM, LARGE: use a dedicated 50 class II safety transformer VA.				
	BUILT IN DRIVER: use a dedicated 100 VA class II safety transformer.				
		Vac	P (Vac)	Vdc	P (Vdc)
	SMALL	24 Vac (+10/-15%), 50/60 Hz protected by an external 2.5 A type T fuse	45 VA	28 to 36 Vdc (-20/+10%) protected by an external 2.5 A type T fuse	30 W
	MEDIUM				
LARGE					
BUILT-IN DRIVER		90 VA		Not allowed	

Important: only power "PRK300TD****" with alternating current. The power transformer secondary **must** be earthed.

Terminal block	with male/female plug-in connectors
Cable cross-section	min 0.5 mm ² - max 2.5 mm ²
CPU	32 bit, 100 MHz
Non-volatile memory (FLASH)	2 M byte Bios + 11 Mbyte application program
Data memory (RAM)	3.2 Mbyte (1.76 Mbyte Bios + 1.44 Mbyte application program)
T buffer memory (EEPROM)	13 kbyte
P parameter memory(EEPROM)	32 kbyte (not available to the pLAN)
Clock with battery	standard, precision 100 ppm
Battery	CR2430 3 Vdc lithium button battery (size 24x3 mm)
Software class and structure	Class A
Category of immunity to voltage surges (EN 61000-4-5)	Category III

Device not designed to be hand-held when powered

Tab. 2.e

2.2.3 Universal inputs/outputs U...

Analogue inputs, Lmax = 30 m (maximum number)			SMALL	MEDIUM/ BUILT-IN DRIVER	LARGE
	- CAREL NTC probes (-50T90°C; R/T 10 kΩ±1% at 25°C); - HT NTC (0T150°C); - PTC (600Ω to 2200Ω) - PT500 (-100T400°C) - PT1000 (-100T400°C) - PT100 probes (-100T200°C)	5		8	
- 0 to 1 Vdc/0 to 10 Vdc signals from probes powered by controller	2		3 (2 on U1...U5, 1 on U6...U8)		4 (2 on U1...U5, 1 on U6...U8, 1 on U9...U10)
- 0 to 1 Vdc/0 to 10 Vdc signals powered externally	max tot 5	5	max tot 8	6	max tot 10
- 0 to 20 mA /4 to 20 mA inputs from probes powered by the controller	max tot 4	4	max tot 7	6 (max 4 on U1...U5, 3 on U6...U8)	max tot 9 6 (max 4 on U1...U5, 3 on U6...U8, 2 on U9...U10)
- 0 to 20 mA /4 to 20 mA inputs powered externally	max tot 4	4	max tot 7	7 (max 4 on U1...U5, 3 on U6...U8)	max tot 9 9 (max 4 on U1...U5, 3 on U6...U8, 2 on U9...U10)
- 0 to 5 V signals from ratiometric probes powered by controller	5		6		6
Input precision: ± 0.3 % f.s. Time constant for each input: 0.5 s Classification of measuring circuits (CEI EN 61010-1): category I					
Digital inputs w/o optical isolation, Lmax = 30 m (maximum number)			SMALL	MEDIUM/ BUILT-IN DRIVER	LARGE
- voltage-free contacts	5		8		10
- fast digital inputs type: voltage-free contact max current: 10 mA max frequency 2kHz and resolution ±1 Hz	max 2		4 (max 2 on U1...U5, max 2 on U6...U8)		6 (max 2 on U1...U5, max 2 on U6...U8, 2 on U9...U10)



Important:

- for active probes powered externally (0 to 1 V, 0 to 10 V, 0 to 20 mA, 4 to 20 mA), to avoid irreparably damaging the controller, implement adequate current protection measures that must ensure < 100 mA;
- the ratiometric probes can only be powered by the controller;
- on power-up, the universal inputs/outputs remain shorted to GND for around 500 ms until the end of the configuration procedure.

Analogue outputs w/o optical isolation (maximum number), Lmax = 30 m			SMALL	MEDIUM/ BUILT-IN DRIVER	LARGE
	0 to 10 Vdc (maximum current 2 mA)	5		8	
PWM (output 0/3.3 Vdc, maximum current 2 mA, frequency: 2kHz asynchronous)	5		8		10

Tab. 2.f

2.2.4 Power supply to probes and terminals

+Vdc	can be used to power any active probes using the 24/21 Vdc ± 10% (P+5*/P+3*) available at terminal +VDC (J2). The maximum current available is 150 mA, protected against short-circuits.
+5Vref	to power the 0 to 5V ratiometric probes, use the 5 Vdc (± 5%) available at terminal +5VREF(J24). The maximum current available is 60 mA.
Vterm	P+3*****: 21 Vdc ± 10%; P+5*****: 24 Vdc ± 10% Used to power an external terminal as an alternative to the one connected to J10, Pmax = 1.5 W

Important: if the length exceeds 10 m, use shielded cable with the shield connected to earth. In any case, the max length allowed is 30 m.

Tab. 2.g

2.2.5 Digital inputs ID... IDH...

Type	Optically-isolated		
Lmax	30 m		
Maximum number		no. of optically-isolated inputs, 24 Vac or 24 Vdc	no. of optically-isolated inputs, 24 Vac/Vdc or 230 Vac - 50/60 Hz
	SMALL	8	None
	MEDIUM/ BUILT-IN DRIVER	12	2
	LARGE	14	4
Minimum digital input pulse detection time	Normally open (open-closed-open)	200 ms	
	Normally closed (closed-open-closed)	400 ms	
Power supply to the inputs	External	IDH...: 230 Vac (+10/-15%) 50/60 Hz	
Classification of measuring circuits (CEI EN 61010-1)	Category I: 24 Vac/Vdc (J5, J7, J20)		
	Category III: 230 Vac (J8, J19)		
Digital input current draw at 24 Vac/Vdc	5 mA		
Digital input current draw at 230 Vac	5 mA		

Tab. 2.h



Note:

- separate as much as possible the probe and digital input cables from cables to inductive loads and power cables, so as to avoid possible electromagnetic disturbance. Never run power cables (including the electrical panel cables) and signal cables in the same conduits;
- the two 230 Vac or 24 Vac/Vdc inputs on terminals J8 (ID13, ID14) or J19 (ID15, ID16) have the same common pole and therefore both will operate at 230 Vac or 24 Vac/Vdc. There is basic insulation between the two inputs; there is reinforced insulation between the inputs and the rest of the controller;
- ID1...ID8, ID9 to ID12, ID17, ID18 have functional insulation from the rest of the controller;
- for DC voltage inputs (24 Vdc) either the + or the - can be connected to common terminal;
- the rating of the external contact connected to the digital inputs must be at least 5 mA.

2.2.6 Analogue outputs Y...

Type	0 to 10 V optically-isolated on Y1...Y6		
Lmax	30 m		
Maximum number	SMALL, MEDIUM/ BUILT-IN DRIVER	4	Y1...Y4, 0 to 10 V
	LARGE	6	Y1...Y6, 0 to 10 V
Power supply	external	24 Vac (+10/-15%) or 28 to 36 Vdc on VG(+), VG0(-)	
Precision	Y1...Y6	± 2% full scale	
Resolution	8 bit		
Settling time	Y1...Y6	from 1 s (slew rate 10 V/s) to 20 s (slew rate 0.5 V/s) selectable via SW	
Maximum load	1 kΩ (10 mA)		

Tab. 2.i



Warnings:

- for lengths > 10 m, only use shielded cable, with the shield connected to earth;
- a 0 to 10Vdc analogue output can be connected in parallel to other outputs of the same type, or alternatively to an external source of voltage. The higher voltage will be considered. Correct operation is not guaranteed if actuators with voltage inputs are connected;
- power the VG-VG0 analogue outputs at the same voltage on G-G0: Connect G0 to VG0 and G to VG. This is valid for both alternating and direct current power supplies.

2.2.7 Digital outputs NO..., NC...

Type	Relay. Minimum contact current: 50 mA.											
Maximum no	8: SMALL; 13: MEDIUM/ BUILT-IN DRIVER; 18: LARGE;											
Insulation distance	The relay outputs have different features depending on the model of controller. The outputs can be divided into groups. The relays belonging to the same group (individual cell in the table) have basic insulation and therefore must have the same voltage. Between groups (cells in the table) there is double insulation and consequently these may have different voltages. There is also double insulation between each terminal of the digital outputs and the rest of the controller.											
Relays with the same insulation												
		Group										
	Model	1	2	3	4	5	6	7	8	9	10	11
Makeup of the groups	SMALL	1-3	4-6	7	8	-	-	-	-	-	-	-
	Type of relay	Type A	Type A	Type A	Type A	-	-	-	-	-	-	-
	MEDIUM/ BUILT-IN DRIVER	1-3	4-6	7	8	9-11	12	13	-	-	-	-
	Type of relay	Type A	Type A	Type A	Type A	Type A	Type A	Type A	-	-	-	-
	LARGE NO	1-3	4-6	7	8	9-11	12	13	14-15	16-18	-	-
	Type of relay	Type A	Type A	Type A	Type A	Type A	Type A	Type A	Type A	Type A	-	-
	LARGE NC	1-3	4-6	7	8	9-11	12	13	14-15	16-18	-	-
	Type of relay	Type A	Type A	Type A	Type A	Type A	Type A	Type A	Type A	Type C	-	-
EXTRALARGE	1-3	4-6	7	8	9-11	12	13	14-16	17-20	21-24	25-29	
Type of relay	Type A	Type A	Type A	Type A	Type A	Type A	Type A	Type A	Type B	Type B	Type B	
Number of changeover contacts	1: SMALL (relay 8) 3: MEDIUM (relay 8, 12, 13) 5: LARGE NO/NC (relay 8, 12, 13, 14 e 15)											



Note: the output relays have different features, depending on the model of controller.

Switchable power	Relay type A	Rated data	SPDT, 2000 VA, 250 Vac, 8A resistive	
		Approval	UL 873	2 A 250 Vac resistive, 2A FLA, 12 LRA, 250 Vac, C300 pilot duty (30,000 cycles)
	Relay type B	Relay rated data	SPST, 1250 VA, 250 Vac, 5A resistive	
		Approval	UL 873	1 A 250 Vac resistive, 1A FLA, 6 LRA, 250 Vac, C300 pilot duty (30,000 cycles)
	Relay type C	Relay rated data	SPDT, 1250 VA, 250 Vac, 5A resistive	
		Approval	UL 873	1 A 250 Vac resistive, 1A FLA, 6 LRA, 250 Vac, C300 pilot duty (30,000 cycles)
		EN 60730-1	1 A resistive, 1A inductive, cosφ=0.6, 1(1)A (100,000 cycles)	

Tab. 2.j

2.2.8 SSR outputs (in models where featured)

Maximum number	2: SMALL (outputs 7, 8); 2: MEDIUM (outputs 7, 12); 6: LARGE (outputs 7, 8, 12, 13, 14, 15)
Working voltage	24 Vac/Vdc
Load current (MAX)	1 A
Impulsive load current (MAX)	1.2 A

Tab. 2.k



Warnings:

- if the load requires higher current, use an external SSR;
- to power external loads, use the same power supply as the pCO (connected to terminals G/G0); this must always be dedicated and not in common with the power supply to other devices on the electrical panel (such as contactors, coils, etc.);
- the groups that the digital outputs are divided into have two common pole terminals to simplify wiring;
- make sure that the current running through the common terminals does not exceed the rated current of an individual terminal, that is, 8 A.

2.2.9 Serial port

Use AWG 20-22 twisted pair shielded cable for the +/-

Use AWG20/22 shielded three-wire cable (one twisted pair plus a third wire) with a capacitance between the wires of less than 90 pF/m (example: BELDEN 3106A). The shield must be connected to earth and not to the GND terminals. Alternatively, use AWG20/22 shielded twisted pair cable with a capacitance between the wires of less than 90 pF/m (example: BELDEN 8761); use the shield to connect the GND terminals, without connecting it to earth. The maximum length of the serial network is 500 m with AWG22 cable, 1000 m with AWG20 cable.

Serial	Type/connectors	Features
Serial ZERO	pLAN/J10, J11	<ul style="list-style-type: none"> Integrated on main board HW driver: asynchronous half duplex RS485 pLAN Not optically-isolated Connectors: 6-pin telephone jack + 3-pin plug-in p. 5.08 Maximum length: 500 m Max data rate: 115200 bit/s Maximum number of connectable devices: 3
Serial ONE	BMS 1 Serial Card	<ul style="list-style-type: none"> Not integrated on main board HW driver: not featured Can be used with all pCO family optional BMS cards
Serial TWO	FieldBus 1 Serial Card	<ul style="list-style-type: none"> Not integrated on main board HW driver: not present Can be used with all pCO family optional FieldBus cards
Serial THREE	BMS 2 / J25	<ul style="list-style-type: none"> Integrated on main board HW driver: asynchronous half duplex RS485 Slave Optically-isolated 3-pin plug-in connector p. 5.08 Maximum length: 1000 m Max data rate: 384000 bit/s
Serial FOUR	FFieldBus 2 / J26 (and J23 on Large and Extralarge version)	<ul style="list-style-type: none"> Integrated on main board J23: not optically-isolated J26: optically-isolated 3-pin plug-in connector p. 5.08 J23 and J26 are independent.

Tab. 2.1

 **Note:** in industrial/residential environments, for distances > 10 m, shielded cable is required, with the shield connected to earth. In residential environments (EN 55014), irrespective of the cable length, on versions without valve driver, the connection cable between the controller and the terminal and the serial cable must be shielded and connected to earth at both ends.

2.2.10 Model with electronic expansion valve driver

Valve compatibility	CAREL: E*V**** ALCO: EX4; EX5; EX6; EX7; EX8 330 Hz (recommended by CAREL); EX8 500 Hz (from ALCO specifications) SPORLAN: SEI 0.5-11; SER 1.5-20; SEI 30; SEI 50; SEH 100; SEH175 Danfoss: ETS 12.5-25B; ETS 50B; ETS 100B; ETS 250; ETS 400 CCM 40, CCM 10-20-30, CCMT 2-4-8 CAREL: two CAREL EXV as for EVD EVOLUTION TWIN SPORLAN: SER(I) G, J, K			
Motor connection	Shielded 4-wire cable CAREL P/N E2VCAB5*00, or AWG22 shielded 4-wire cable Lmax =10 m, or AWG14 shielded 4-wire cable Lmax 50 m			
Digital input connection	Digital input to be activated with voltage-free contact or transistor to GND. Closing current 5mA; maximum length < 10 m			
Probes	Maximum length 10 m or less than 30 m with shielded cable			
	S1	ratiometric pressure probe (0 to 5 V)	resolution 0.1 % fs	measurement error: 2% fs massimo; 1% typical
		electronic pressure sensor (4 to 20 mA)	resolution 0.5 % fs	measurement error: 8% fs massimo; 7% typical
		combined ratiometric pressure probe (0 to 5 V)	resolution 0.1 % fs	measurement error: 2 % fs massimo; 1 % typical
		4 to 20 mA input (max. 24 mA)	resolution 0.5 % fs	measurement error: 8 % fs massimo; 7 % typical
	S2	low temperature NTC	10 kΩ at 25 °C, -50T90 °C	measurement error: 1°C in the range -50T50 °C; 3°C in the range +50T90 °C
		high temperature NTC	50 kΩ at 25 °C, -40T150 °C	measurement error: 1.5 °C in the range -20T115 °C, 4 °C in range outside of -20T115 °C
		combined NTC	10 kΩ at 25 °C, -40T120 °C	measurement error: 1°C in the range -40T50 °C; 3°C in the range +50T90 °C
	S3	0 to 10 V input (max 12 V)	resolution 0.1 % fs	measurement error: 9% fs massimo; 8% typical
		ratiometric pressure probe (0 to 5 V):	resolution 0.1 % fs	measurement error: 2% fs massimo; 1% typical
		electronic pressure sensor (4 to 20 mA)	resolution 0.5 % fs	measurement error: 8% fs massimo; 7% typical
		combined ratiometric pressure probe (0 to 5 V)	resolution 0.1 % fs	measurement error: 2 % fs massimo; 1 % typical
S4	4 to 20 mA input (max. 24 mA)	resolution 0.5 % fs	measurement error: 8 % fs massimo; 7 % typical	
	low temperature NTC	10 kΩ at 25 °C, -50T105 °C	measurement error: 1 °C in the range -50T50 °C; 3°C in the range 50T90 °C	
	high temperature NTC	10 kΩ at 25 °C, -40T150 °C	measurement error: 1.5 °C in the range -20T115 °C; 4 °C in range outside of -20T115 °C	
	combined NTC	10 kΩ at 25 °C, -40T120 °C	measurement error 1 °C in the range -40T50 °C; 3°C in the range +50T90 °C	
Power to active probes (VREF)	programmable output: +5 Vdc ±2% or 12 Vdc ±10%, I _{max} = 50 mA			
Emergency power supply	optional Ultracapacitor module (PCOS00UC20 or EVD0000UC0). If the controller operates constantly at temperatures near the upper limit of 60°C it's recommended to use the external module EVD0000UC0, where possible located in the coolest point of the panel. The PCOS00UC20 and EVD0000UC0 modules can be connected at the same time to the same controller, thus doubling the energy available to close the valves. Important: The module only powers the valve driver and not the controller.			

Tab. 2.m

2.2.11 Meaning of the inputs/outputs on the pRack pR300T S, M, L boards

Version	Connector	Signal	Description	
S, M, L	J1-1	G	+24 Vdc or 24 Vac power supply	
	J1-2	G0	power supply reference	
	J2-1	B1	universal analogue input 1 (NTC, 0 to 1 V, 0 to 5 V ratiometric, 0...10 V, 0...20 mA, 4...20 mA)	
	J2-2	B2	universal analogue input 2 (NTC, 0 to 1 V, 0 to 5 V ratiometric, 0...10 V, 0...20 mA, 4...20 mA)	
	J2-3	B3	universal analogue input 3 (NTC, 0 to 1 V, 0 to 5 V ratiometric, 0...10 V, 0...20 mA, 4...20 mA)	
	J2-4	GND	common for analogue inputs	
	J2-5	+VDC	21 Vdc power supply for active probes (maximum current 200 mA)	
	J3-1	B4	passive analogue input 4 (NTC, PT1000, ON/OFF)	
	J3-2	BC4	common for analogue input 4	
	J3-3	B5	passive analogue input 5 (NTC, PT1000, ON/OFF)	
	J3-4	BC5	common for analogue input 5	
	J4-1	VG	power to optically-isolated analogue output, 24 Vac/Vdc	
	J4-2	VG0	power to optically-isolated analogue output, 0 Vac/Vdc	
	J4-3	Y1	analogue output no. 1, 0...10 V	
	J4-4	Y2	analogue output no. 2, 0...10 V	
	J4-5	Y3	analogue output no. 3, 0...10 V	
	J4-6	Y4	analogue output no. 4, 0...10 V	
	J5-1	ID1	digital input no. 1, 24 Vac/Vdc	
	J5-2	ID2	digital input no. 2, 24 Vac/Vdc	
	J5-3	ID3	digital input no. 3, 24 Vac/Vdc	
	J5-4	ID4	digital input no. 4, 24 Vac/Vdc	
	J5-5	ID5	digital input no. 5, 24 Vac/Vdc	
	J5-6	ID6	digital input no. 6, 24 Vac/Vdc	
	J5-7	ID7	digital input no. 7, 24 Vac/Vdc	
	J5-8	ID8	digital input no. 8, 24 Vac/Vdc	
	J5-9	IDC1	common for digital inputs from 1 to 8 (negative pole for DC power supply)	
	M, L	J6-1	B6	universal analogue input 6 (NTC, 0 to 1 V, 0 to 5 V ratiometric, 0...10 V, 0...20 mA, 4...20 mA)
		J6-2	B7	universal analogue input 7 (NTC, 0 to 1 V, 0 to 5 V ratiometric, 0...10 V, 0...20 mA, 4...20 mA)
		J6-3	B8	universal analogue input 8 (NTC, 0 to 1 V, 0 to 5 V ratiometric, 0...10 V, 0...20 mA, 4...20 mA)
J6-4		GND	common for analogue inputs	
J7-1		ID9	digital input no. 9, 24 Vac/Vdc	
J7-2		ID10	digital input no. 10, 24 Vac/Vdc	
J7-3		ID11	digital input no. 11, 24 Vac/Vdc	
J7-4		ID12	digital input no. 12, 24 Vac/Vdc	
J7-5		IDC9	common for digital inputs from 9 to 12 (negative pole for DC power supply)	
J8-1		ID13H	digital input no. 13, 230 Vac	
J8-2		ID13	digital input no. 13, 24 Vac/Vdc	
J8-3		IDC13	common for digital inputs 13 and 14 (negative pole for DC power supply)	
J8-4		ID14	digital input no. 14, 24 Vac/Vdc	
J8-5		ID14H	digital input no. 14, 230 Vac	
S, M, L		J9		8-pin telephone connector for connecting a display terminal (not used)
	J10		6-pin telephone connector for connecting the standard pGDE user terminal	
	J11-1	RX-/TX-	RX-/TX- connector for RS485 connection to the pLAN network	
	J11-2	RX+/TX+	RX+/TX+ connector for RS485 connection to the pLAN network	
	J11-3	GND	GND connector for RS485 connection to the pLAN network	
	J12-1	C1	common for relays: 1, 2, 3	
	J12-2	NO1	normally open contact, relay no. 1	
	J12-3	NO2	normally open contact, relay no. 2	
	J12-4	NO3	normally open contact, relay no. 3	
	J12-5	C1	common for relays: 1, 2, 3	
	J13-1	C4	common for relays: 4, 5, 6	
	J13-2	NO4	normally open contact, relay no. 4	
	J13-3	NO5	normally open contact, relay no. 5	
	J13-4	NO6	normally open contact, relay no. 6	
	J13-5	C4	common for relays: 4, 5, 6	
	J14-1	C7	common for relay no. 7	
	J14-2	NO7	normally open contact, relay no. 7/ normally open contact, relay no. 7 SSR 24 Vac/Vdc (*)	
	J14-3	C7	common for relay no. 7	
	J15-1	NO8	normally open contact, relay no. 8/ only S-board: normally open contact, relay no. 8 SSR 24 Vac/Vdc, S board only (*)	
J15-2	C8	common for relay no. 8		
J15-3	NC8/---	normally closed contact relay no. 8/ only S-board: not used, S board only (*)		
M, L	J16-1	C9	common for relay: 9, 10, 11	
	J16-2	NO9	normally open contact, relay no. 9	
	J16-3	NO10	normally open contact, relay no. 10	
	J16-4	NO11	normally open contact, relay no. 11	
	J16-5	C9	common for relay: 9, 10, 11	
	J17-1	NO12	normally open contact, relay no. 12/ normally open contact, relay no. 12 SSR 24 Vac/Vdc (*)	
	J17-2	C12	common for relay no. 12	
	J17-3	NC12/---	normally closed contact relay no. 12/ not used (*)	
	J18-1	NO13	normally open contact, relay no. 13	
	J18-2	C13	common for relay no. 13	
J18-3	NC13	normally closed contact relay no. 13		
L	J19-1	ID15H	digital input no. 15, 230 Vac	
	J19-2	ID15	digital input no. 15, 24 Vac/Vdc	
	J19-3	IDC15	common for digital inputs 15 and 16 (negative pole for DC power supply)	
	J19-4	ID16	digital input no. 16, 24 Vac/Vdc	
	J19-5	ID16H	digital input no. 16, 230 Vac	
	J20-1	Y5	digital input no. 5 0...10 V	
	J20-2	Y6	digital input no. 6 0...10 V	
	J20-3	B9	passive analogue input 9 (NTC, PT1000, ON/OFF)	
J20-4	BC9	common for analogue input 9		
J20-5	B10	passive analogue input 10 (NTC, PT1000, ON/OFF)		

Version	Connector	Signal	Description
	J20-6	BC10	common for analogue input 10
	J20-7	ID17	digital input no. 17, 24 Vac/Vdc
	J20-8	ID18	digital input no. 18, 24 Vac/Vdc
	J20-9	IDC17	common for digital inputs 17 and 18 (negative pole for DC power supply)
	J21-1	NO14	normally open contact, relay no. 14/ normally open contact, relay no. 14 SSR 24 Vac/Vdc (*)
	J21-2	C14	common for relay no. 14
	J21-3	NC14/---	normally closed contact relay no. 14/ not used (*)
	J21-4	NO15	normally open contact, relay no. 15/ normally open contact, relay no. 15 SSR 24 Vac/Vdc (*)
	J21-5	C15	common for relay no. 15
	J21-6	NC15/---	normally closed contact relay no. 15/ not used (*)
	J22-1	C16	common for relay: no. 16, 17, 18
	J22-2	NO16	normally open contact, relay no. 16
	J22-3	NO17	normally open contact, relay no. 17
	J22-4	NO18	normally open contact, relay no.18
	J22-5	C16	common for relay: no. 16, 17, 18
	J23-1	E-	E- terminal for RS485 connection to the I/O expansion modules (not used)
	J23-2	E+	E+ terminal for RS485 connection to the I/O expansion modules (not used)
	J23-3	GND	GND terminal for RS485 connection to the I/O expansion modules (not used)
	J24-1	+V term	additional power supply terminal Aria (not used)
	J24-2	GND	power supply common
	J24-3	+5 Vref	power supply for 0/5 V ratiometric probes
	J25-1	E-	E- terminal for RS485 connection, BMS2
S, M, D, L	J25-2	E+	E+ terminal for RS485 connection, BMS2
	J25-3	GND	GND terminal for RS485 connection, BMS2
	J26-1	E-	E- terminal for RS485 connection, FIELDBUS 2
	J26-2	E+	E+ terminal for RS485 connection, FIELDBUS 2
	J26-3	GND	GND terminal for RS485 connection, FIELDBUS 2
	J27-1	1	ExV connection, power stepper-motor
	J27-2	2	ExV connection, power stepper-motor
	J27-3	3	ExV connection, power stepper-motor
	J27-4	4	ExV connection, power stepper-motor
	J28-1	1	ExV connection, power stepper-motor
	J28-2	2	ExV connection, power stepper-motor
	J28-3	3	ExV connection, power stepper-motor
	J28-4	4	ExV connection, power stepper-motor
	J29-1	GND	Signals-ground
	J29-2	VREF	Active probe power supply
	J29-3	S1	Probe 1 (pressure) or external-signal 4...20mA
	J29-4	S2	Probe 2 (temperature) or external-signal 0...10V
	J29-5	S3	Probe 3 (pressure) or external-signal 4...20mA
	J29-6	S4	Probe 4 (temperature)
	J29-7	DI1	Digital input 1
	J29-8	DI2	Digital input 2
	J30-1	VBAT	Emergency power supply
	J30-2	G0	Power supply
	J30-3	G	Power supply

(*) depending on model

Tab. 2.n

2.3 pRack pR300T S, M, D, L board dimensions




Fig. 2.e

	Small	Medium	Buit-in driver	Large
A	227,5	315	315	315
B	60	60	60	60
B - with USB port and/or built-in terminal	70	70	70	70
B - with Ultracap module	-	-	75	-

Tab. 2.o

Medium





Fig. 2.g

Large



*NON USATO Per altri tipi di sensori 4-20 mA fare riferimento al relativo foglio di istruzioni

Fig. 2.h

■ Driver integrato




Fig. 2.i

■ Driver esterno (applicabile a S/M/L/D)




Fig. 2j

2.5 Expansion card

From version 3.3.0, an I/O expansion card can be used to provide additional analogue and digital channels, ideal when there is a high number of compressors and corresponding alarms, or with complex heat recovery systems that require of numerous temperature sensors in the water and CO2 circuits (see technical leaflet +0500059IE for the product's electrical and physical specifications). The universal inputs/outputs (marked U on the connection diagram) can be configured by pRack pR300T to connect active and passive probes, digital inputs, analogue and PWM outputs, up to a total of 10. A further 6 digital outputs are also available.




Fig. 2.k

Key:

- 1 | Power connector [G(+), G0(-), Vbat]
- 2 | Universal inputs/outputs
- 3 | +Vdc power supply for active probes
- 4 | +5V power supply for ratiometric probes
- 5 | Relay digital outputs
- 6 | BMS connector
- 7 | Communication indicator LED
- 8 | Configuration indicator LED
- 9 | Configuration dipswitches

For correct communication with pRack pR300T, the dipswitches on the expansion card should be configured as follows:

- Address: 15
- Ext: no off set
- Baud: 19.2 K
- Prot: CAREL






Fig. 2.l

The pRack pR300T software (version 3.3.0 and higher) offers the possibility to extend the number of I/Os by expansion card directly from the Wizard, in screen lb1f:




Additional configuration of the expansion card is possible on Fda01, under PROGRAMMING → F.Settings → d.FIELDDBUS:



When enabling "Offline pattern", the status of the outputs can be configured if the card is offline from the pRack.

Both the digital (Fda01) that analogue outputs (Fda02) can be configured



Notice: Carel does not recommend using the expansion card for configuring control probes (suction pressure probes, including backup probes), modulation signals for the inverters, serious alarm signals and pressure switches.

The expansion card is connected to the pRack pR300T via port J26 FBus on the pRack, the same used for connecting an external driver, and port J6BMS on the expansion card via RS485




Fig. 2.m

Only one expansion card can be used for each compressor rack and the expansion card can only be connected to the board with pLAN address 1:



Fig. 2.n

3. INSTALLATION

3.1 General installation instructions

3.1.1 Installation procedure

Environmental conditions

Avoid assembling the pRack PR300T and the terminal in environments with the following characteristics:

- temperature and humidity that do not conform to the rated operating data of the product;
- strong vibrations or knocks;
- exposure to aggressive and polluting atmospheres (e.g.: sulphur and ammonia fumes, saline mist, smoke) so as to avoid corrosion and/or oxidation;
- strong magnetic and/or radio frequency interference (therefore avoid installing the units near transmitting antennae);
- exposure of the pRack PR300T to direct sunlight and to the elements in general;
- large and rapid fluctuations in the room temperature;
- environments containing explosives or mixes of flammable gases;
- exposure to dust (formation of corrosive patina with possible oxidation and reduction of insulation).

Positioning the instrument inside the panel

The position of the instrument in the electrical cabinet must be chosen so as to guarantee correct physical separation of the instrument from the power components (solenoids, contactors, actuators, inverters, ...) and the connected cables. Proximity to such devices/cables may create random malfunctions that are not immediately evident.

The structure of the panel must allow the correct flow of cooling air.

3.1.2 Wiring procedure

When laying the wiring, "physically" separate the power part from the control part. The proximity of these two sets of wires will, in most cases, cause problems of induced disturbance or, over time, malfunctions or damage to the components. The ideal solution is to house these two circuits in two separate cabinets. Sometimes this is not possible, and therefore the power part and the control part must be installed inside the same panel. For the control Signals, it is recommended to use shielded cables with twisted wires.

If the control cables have to cross over the power cables, the intersections must be as near as possible to 90 degrees, always avoiding running the control cables parallel to the power cables.

- Use cable ends suitable for the corresponding terminals. Loosen each screw and insert the cable ends, then tighten the screws. When the operation is completed, slightly tug the cables to check they are sufficiently tight;
- separate as much as possible the sensor Signal, digital input and serial line cables from the cables carrying inductive loads and power cables to avoid possible electromagnetic disturbance. Never insert power cables (including the electrical cables) and probe Signal cables in the same conduits. Do not install the sensor cables in the immediate vicinity of power devices (contactors, circuit breakers or similar);
- reduce the path of the sensor cables as much as possible, and avoid spiral paths that enclose power devices;
- avoid touching or nearly touching the electronic components fitted on the boards to avoid electrostatic discharges (extremely damaging) from the operator to the components;
- if the power transformer secondary is earthed, check that the earth wire corresponds to the wire that runs to the controller and enters terminal G0; this applies to all the devices connected to the pRack PR300T;
- do not secure the cables to the terminals by pressing the screwdriver with excessive force, to avoid damaging the pRack PR300T;
- for applications subject to considerable vibrations (1.5 mm pk-pk 10/55 Hz), secure the cables connected to the pRack PR300 around 3 cm from the connectors using clamps;
- if the product is installed in industrial environments (application of the EN 61000-6-2 standard) the length of the connections must be less than 30 m;

- all the very low voltage connections (analogue and 24 Vac/Vdc digital inputs, analogue outputs, serial bus connections, power supplies) must have reinforced or double insulation from the mains network;
- in residential environments, the connection cable between the pRack PR300T and the terminal must be shielded;
- there is no limit to the number of cables that can be connected to an individual terminal. The only limitation concerns the maximum current crossing each terminal: this must not exceed 8 A;
- the maximum cross-section of the cable that connected to a terminal is 2.5 mm² (12 AWG);
- the maximum value of the twisting torque to tighten the screw on the terminal (torque tightening) is 0.6 Nm;



Important:

- Installation must be performed according to the standards and legislation in force in the country where the device is used;
- for safety reasons the equipment must be housed inside an electrical panel, so that the only accessible part is the display and the keypad;
- in the event of malfunctions, do not attempt to repair the device, but rather contact the CAREL service centre;
- the connector kit also contains the stick-on labels.

3.1.3 Anchoring the pRack PR300T

The pRack PR300T is installed on a DIN rail. To fasten the unit to the DIN rail, press it lightly against the rail. The rear tabs will click into place, locking the unit to the rail. Removing the unit is just as Simple, using a screwdriver through the release slot to lever and lift the tabs. The tabs are kept in the locked position by springs.

3.2 Power supply

Power supply to the pRack PR300T	28...36 Vdc +10/-20% or 24 Vac +10/-15% 50...60 Hz;
S, M, D, L (controller with terminal connected)	Maximum current P= 15 W (power supply Vdc) P=40 VA (Vac)

Tab. 3.a



Important:

- power supplies other than those specified seriously damage the system;
- a Class II safety transformer, must be used in the installation to supply just one pRack PR300T controller, rating 30 VA for pRack Compact and 50 VA for pRack S, M, L;
- the power supply to the pRack PR300T controller and terminal (or pRack PR300T controllers and terminals) should be separated from the power supply to the other electrical devices (contactors and other electromechanical components) inside the electrical panel;
- if the power transformer secondary is earthed, check that the earth wire corresponds to the wire that runs to the controller and enters terminal G0. This applies to all the devices connected to the pRack PR300T;
- a yellow LED indicates that power is connected to the pRack PR300T.

3.3 Connecting the analogue inputs

The analogue inputs on the pRack PR300T can be configured for the most common sensors on the market: 0 to 1 V, 0...10 V, 0...20 mA, 4...20 mA. The different types of sensors for each input can be selected by setting a parameter on the user terminal.

3.3.1 Connecting universal NTC temperature sensors

The analogue inputs are compatible with 2-wire NTC sensors. The inputs must be set for NTC Signals from the user terminal or using the default value installation procedure. The connection diagram is shown below:




Fig. 3.a

Hardware versions	Terminals	NTC probe cable
S, M, D, L	GND	1
	U1...U10, S2, S4	2

Tab. 3.b

Note: the two wires of the NTC sensors are equivalent, as they have no polarity, therefore it is not necessary to follow any specific order when connecting to the terminal block.

3.3.2 Connecting PT1000 temperature sensors

The pRACK PR300T can be connected to 2-wire PT1000 sensors for all high temperature applications; the operating range is: -100 to 200 °C. The inputs must be pre-configured for PT1000 Signals from the user terminal or using the default value installation procedure. The connection diagram is shown below:




Fig. 3.b

Hardware versions	Terminals	PT1000 probe cable
S, M, D, L	GND	1
	U1...U10	2

Tab. 3.c

Important: for correct measurement by the PT1000 sensor, each sensor wire needs to be connected to a dedicated terminal, as shown in Fig. 3.b.

Note: the two wires of the PT1000 sensors are equivalent, as they have no polarity, therefore it is not necessary to follow any specific order when connecting to the terminal block.

3.3.3 Connecting current pressure probes

pRACK PR300T can be connected to all CAREL SPK* series active pressure probes or any other pressure sensors available on the market with 0...20 mA or 4...20 mA Signal.

The inputs must be set for 0...20 mA or 4...20 mA Signals from the user terminal or using the default value installation procedure. The connection diagram is shown below:




Fig. 3.c

Hardware versions	Terminals	Probe cable colour	Description
S, M, D, L	+VDC	brown	Power supply
	U1...U10, S1, S3	white	Signal

Tab. 3.d

Important: do not connect the green wire.

3.3.4 Connecting 0 to 5 V ratiometric pressure probes

pRACK PR300T can be connected to any other pressure probes available on the market with 0 to 5 V ratiometric sensor.

The inputs must be set for 0 to 5 V Signals from the user terminal or using the default value installation procedure. The connection diagram is shown below:




Fig. 3.d

Hardware ver.	Terminals	Probe cable colour	Description
S, M, D, L	+5 V ref	black	Power supply
	GND	green	Power reference
	U1...U10, S1, S3	white	Signal

Tab. 3.e

3.3.5 Connecting 0...10 V active probes

PRack PR300T can be connected to 0...10 V sensors. The inputs must be set for 0...10 V Signals from the user terminal or using the default value installation procedure. The connection diagram is shown below:




Fig. 3.e

Hardware versions	Terminals	Description
S, M, L, D	+VDC	Power supply (if used)
	GND	Reference
	U1...U10	Signal

Tab. 3.f

3.3.6 Connecting the analogue inputs selected as ON/OFF

The pRack PR300T allows some analogue inputs to be configured as voltage-free digital inputs, not optically-isolated. The inputs must be pre-configured as voltage-free digital inputs from the user terminal or using the default value installation procedure.




Fig. 3.f

Hardware Version	Terminals	Digital input cable
S, M	BC4, BC5	1
	U4, U5	2
S, M, L	U4, U5, U9, U10	1
	U4, U5, U9, U10	2

Tab. 3.g

Important: the maximum current available at the digital input is 5 mA (thus the rating of the external contact must be at least 5 mA). These inputs are not optically-isolated.

3.3.7 Remote connection of the analogue inputs

The Sizes of the cables for the remote connection of the analogue inputs are shown in the following table:

Type of input	Size [mm ²] for length up to 50 m	Size [mm ²] for length up to 100 m
NTC	0.5	1.0
PT1000	0.75	1.5
current	0.25	0.5
voltage	0.25	0.5

Tab. 3.h

If the product is installed in industrial environment (in compliance for the EN 61000-6-2 standard) the length of the connections must be less than 30m. In any case you should never exceed this length to have no measurement errors.

3.4 Connecting the digital inputs

The pRack PR300T features digital inputs for connecting safety devices, alarms, device status and remote switches. These inputs are all optically isolated from the other terminals. They can work at 24 Vac, 24 Vdc and some at 230 Vac for S, M, L models.

Note: separate the sensor Signal and digital input cables as much as possible from the inductive load and power cables, to avoid possible electromagnetic disturbance.

Important:

- if the control voltage is drawn in parallel with a coil, fit a dedicated RC filter in parallel with the coil (the typical ratings are 100 Ω, 0.5 μF, 630V).
- If connecting the digital inputs to safety systems (alarms), remember that: the presence of voltage across the contact must be the normal operating condition, while no voltage must represent an alarm situation. This will ensure that any interruption (or disconnection) of the input will also be Signalled. Do not connect the neutral in place of an open digital input. Always interrupt the phase. The 24 Vac/Vdc digital inputs have a Resistance of around 5 kΩ.

All pRack digital inputs can be powered at 24 Vac and 24 Vdc, while for models M, L only 230 Vac inputs are also available.

To maintain the optical isolation of the digital inputs, a separate power supply must be used just for the digital inputs.

The connection diagrams shown in these figures, which while being the more common and the more convenient, do not exclude the possibility of powering the digital inputs independently from the power supply to the pRack PR300T.

In any case, the inputs only have functional insulation from the rest of the controller.

24 Vac digital inputs

The following figure represents an example for connecting the 24 Vac digital inputs on pRack models S, M, L.




Fig. 3.g

24 Vdc digital inputs

The following figure represents an example for connecting the 24 Vdc digital inputs on pRack models S, M, L.




Fig. 3.h

230 Vac digital inputs

pRack M, L models have up to two groups of inputs powered at 230 Vac 50/60 Hz +10/-15%; each group features two inputs (see paragraph 2.2.1 for details). The groups have double insulation between them and can have different voltages.

! Important: within each group the inputs must be powered at the same voltage to avoid short-circuits or powering lower voltage inputs at 230 Vac.

The following figure represents an example for connecting the 230 Vac digital inputs on pRack models S, M, L.




Fig. 3.i

3.4.1 Remote connection of the digital inputs

! Important note: do not connect other devices to the digital inputs IDn inputs.

The Sizes of the cables for the remote connection of the digital inputs are shown in the following table:

Size (mm ²) for length up to 50 m	Size (mm ²) for length until 100 m
0,25	0,5

If the product is installed in industrial environments (application of the EN 61000-6-2 standard) the length of the connections must be less than 30 m. This length shouldn't be exceeded in any case, to avoid measurement errors.

3.5 Connecting the analogue outputs

3.5.1 Connecting 0...10 V analogue outputs

The pRack PR300T provides 0...10 V optically-isolated analogue outputs, powered externally at 24 Vac/Vdc. The figure below shows the electrical connection diagram; the 0V (zero) of the power supply is also the reference for the output voltage:




Fig. 3.j

Hardware Version	Terminals	Reference
S, M	Y1, Y2, Y3, Y4	VG0
L	Y1, Y2, Y3, Y4, Y5, Y6	VG0

Tab. 3.i

3.5.2 Optional modules

Module for converting a PWM analogue output to a liner 0...10 V and 4...20 mA analogue output (code CONV0/10A0)

The module is used to convert a PWM output (5 V pulses) to a liner 0...10 V and 4...20 mA analogue output (code CONV0/10A0). The control Signal (at the input terminals optically-isolated from the rest of the module) must have a maximum amplitude of 5V and a period between 8 ms and 200 ms. The 0...10 V output voltage can be connected to a maximum load of 2 kΩ, with a maximum ripple of 100 mV. The 4...20 mA current output can be connected to a maximum load of 280 Ω, with maximum overshoot of 0.3 mA.

The mechanical dimensions of the module are 87x36x60 mm (2 DIN modules) with IP20 index of protection.

Module for converting a 0...10 V analogue output to an SPDT digital output (code CONVONOFF0)

The module is used to convert a 0...10 V analogue output to an ON/OFF relay output. The control Signal (at the input terminals, optically-isolated from the rest of the module), to ensure the switching of the relay from OFF to ON, must have a maximum amplitude of 3.3 V. The relay is SPDT, with max current of 10 A and max inductive load of 1/3 HP. The mechanical dimensions of the module are 87x36x60 mm (2 DIN modules) with IP20 index of protection.

3.6 Connecting the digital outputs

3.6.1 Electromechanical relay digital outputs

The pRack PR300T features digital outputs with electromechanical relays. For ease of installation, the common terminals of some of the relays have been grouped together. The following figure illustrates a connection example. If the following this diagram is used, the current at the common terminals must not exceed the rating (nominal current) of a single terminal (8 A).




Fig. 3.k

The relays are divided into groups, according to the degree of insulation. Inside each group, the relays have just basic insulation and thus must have the same voltage (generally 24V ac or 110 to 230 Vac). Between the groups there is double insulation and thus the groups can have different voltages. There is also double insulation from the rest of the controller.

Changeover outputs

Some relays feature changeover outputs, the number of changeover outputs depends on whether or not there are solid state relays (SSR) and consequently varies depending on the models.

Hardware Version	Changeover relay reference, without SSR model	Terminal
PRK30T**F* models		
S	8	J15
M	8, 12, 13	J15, J17, J18
L	8, 12, 13, 14, 15	J15, J17, J18, J21
PRK30T**E* models		
S	-	-
M	8, 13	J15, J18
D	8, 13	J15, J18
L	6	

Tab. 3.j

CAREL

3.6.2 Solid state relay (SSR) digital outputs

The pRack PR300T also features a Version with solid state relays (SSR) on some models for controlling devices that require an unlimited number of switching cycles and thus would not be supported by electromechanical relays.

! Important: the SSRs can control resistive loads powered at 24 Vac/Vdc, maximum power Pmax= 10 W. For details see paragraph 2.2.2. The figure shows a connection example for resistive loads.

An example of resistive loads is illustrated in the the following figure:




Fig. 3.l

The following figure illustrates correct applications for inductive loads.




Fig. 3.m




Fig. 3.n

The table below shows the reference outputs for pRack models fitted with SSR outputs.

Hardware Version	Reference Relay SSR	Terminal
S	7, 8	J14, J15
M	7, 8, 12, 13	J14, J15, J17, J18
L	7, 8, 12, 13, 14, 15	J14, J15, J17, J18, J21

Tab. 3.k

! Important: the SSR relay load is powered at 24 Vac/Vdc, thus all the other terminals in the group must be powered at 24 Vac/Vdc due to the absence of double insulation within the group.

3.6.3 Summary table of digital outputs according to the Versions available

Hardware Version	NO contacts	NC contacts	changeover contacts	total no. of outputs	SSR relays
Models PRK100**A* and PRK100**B*					
Compact	5	-	-	7	2 (1, 2)
S	6	-	-	8	2 (7, 8)
M	9	-	2 (8, 13)	13	2 (7, 12)
L	12	-	2 (8, 13)	18	4 (7, 12, 14, 15)

Models PRK100**C* and PRK100**D*					
Compact	6	-	1 (1)	7	-
S	7	-	1 (8)	8	-
M	10	-	3 (8, 12, 13)	13	-
L	13	-	5 (8, 12, 13, 14, 15)	18	-

Tab. 3.l

3.6.4 Remote connection of the digital outputs

The Sizes of the cables for the remote connection of the digital outputs are shown in the following table:

AWG	Size [mm ²]	Current [A]
20	0,5	2 A
15	1,5	6 A
14	2,5	8 A

Tab. 3.m

If the product is installed in industrial environments (application of the EN 61000-6-2 standard) the length of the connections must be less than 30 m. This length shouldn't be exceeded in any case, to avoid measurement errors.

3.7 pLAN electrical connections

If the selected system configuration involves the connection of more than one pRack PR300T board in a pLAN, AWG20/22 twisted pair shielded cable must be used, with capacitance between the wires less than 90 PF/m. The maximum length of the pLAN network is 500 m with AWG22 twisted pair shielded cable. The boards should be connected in parallel with reference to plug-in connector J5 (pRack Compact) or J11 (Versions S, M, L).

! Important: follow the network polarity: RX/TX+ on one board must be connected to RX/TX+ on the other boards; the same applies to RX/TX-.

The figure shows the diagram for more than one board connected in a pLAN network powered by the same transformer; this is a typical application with more than one board connected inside the same electrical panel.




Fig. 3.o

Important: pLAN connections are also possible with multiple boards powered by different transformers, for further details see the pCO Sistema manual, code: +030220335.

3.7.1 Connecting the terminals

pRack PR300T features PGDE terminals, both built-in and external connected via pLAN. Up to two external terminals can be connected, with pLAN addresses 31 and 32. The connection can be made using 6-wire telephone cables (connector J10 for S, M, L models) or shielded pair cables with 3-pin plug-in connectors (J11 for S, M, L models), as shown in the table:

Type of cable	Power supply distance	Power supply
6-wire telephone (J10)	10 m	Taken from pRack (150 mA)
AWG24	200 m	Taken from pRack (150 mA)
AWG20/22	500 m	Separate, from TCONN6J000

Tab. 3.n

4. START UP

4.1 Starting the first time

After having correctly installed pRack, a number of preliminary operations are required to configure the installation.

Tutorial: the pRack PR300 configuration procedure varies according to the complexity of the installation:

- A. **systems with only one board and maximum one external terminal.** In this case, simply connect the terminal (if not built-in), power up the board and select one of the configuration solutions described below.
- B. **systems with more than one board in pLAN or two external terminals.** In this case, the additional operations described in Appendix A. 2 need to be completed before proceeding with configuration.

The procedure for configuring an installation described below is the same for all system configurations that feature just one pRack PR300 board, and for system configurations with more than one board connected in a pLAN.

When first starting the pRack PR300 board, after waiting around 1 minute, a screen is shown for choosing the language used to display the program (English or Italian). Press ENTER (↵) to change the language displayed, while pressing ESC displays the following screen.

Note: If no option is chosen within a time set by parameter and visible on the screen, the current language remains selected.

After having selected the user interface language, the pRack PR300 software shows a screen for choosing between three possible system configuration solutions, as follows:

- Wizard
- Advanced configuration.

Important: after having configured the system, the configuration can be modified, it can be modified by repeating the same procedure, making sure the Carel default values have been reset. After having restored the defaults, the 7 segment display will show the number 88, the same as when first starting the controller. This means that the DEFAULT values have been restored correctly.





Fig. 4.a

Important: after having configured the system, power down the controller and power up again.

4.2 Wizard



This solution is for obtaining the recommended configuration for the system. By responding to a series of questions, from screen to screen, the user is guided in choosing the devices that are present. Once the guided procedure is finished, the final obtainable results can be viewed (report) and, if the configuration is correct, direct installation can be performed of the parameters for pRack pR300T operation, including those associated with the inputs and outputs as described in paragraph 4.4.

Note: after having configured the parameters using the Wizard, the configuration can be modified manually, within the context of the selected system configuration.

Important: before starting the pRack PR300T, carefully check the settings made automatically by the software.

Tutorial: the following paragraph shows a configuration example using the Wizard for an installation with two suction lines.

4.3 Example of system configuration using the Wizard

This describes a possible example of Wizard-led configuration for a type of system like the one shown in the figure, with 2 suction lines and part in high pressure (gas cooler and HPV, RPRV valves) on 3 different control boards:




Fig. 4.b

The preliminary operations to be performed before configuration are:

1. with the boards not connected to the pLAN, power up the second and third pRack board and set the pLAN address to 2 and 3 (for details, refer to Appendix A.1)
2. remove power and connect the boards and any terminal to the pLAN as described in paragraph 3.7.
3. power the board and wait for the Wizard selection to appear

At this point, select the type of installation as SUCTION+CONDENSER:



Set the type of compressors and regulation of suction line 1 by answering the questions asked by the pRack pR300T software, for example:

```
Wizard 1b03
Compressors conf19.
Compressors type:
    RECIPROCATING
Compressors number:
    3
```

```
Wizard 1b40
Compressors conf19.
Regulation by:
    PRESSURE
Measure unit:
    bar9
Refrigerant:
    R744
```

```
Wizard 1b41
Compressors conf19.
Regulation type:
    PROPORTIONAL BAND
Enable integral time
action:
    YES
```

After having configured suction line 1, the unit asks if another suction line needs to be configured, which must be answered YES:

```
Wizard 1b43
Compressors conf19.
Configure another
suction line:
    YES
```

Answer YES to the next question which asks if a dedicated pRack board is present; this way the pRack pR300T software is ready to configure the board with address 2 in pLAN:

```
Wizard 1b45
Compressors conf19.
Dedicated pRack
board for
suction line:
    YES
```

After having answered the question to configure the second suction line, the software asks if there is a dedicated pLAN board for condensing line 1. In this example, answer YES.

```
Wizard 1b90
Gas cooler conf19.
Dedicated pRack
board for
gas cooler line:
    YES
```

```
Wizard 1b99
Gas cooler conf19.
EEVS Management
HPV valve:
    ENABLE (*)
RPRV valve:
    ENABLE (*)
Valves routing:
    TWIN A->HPV, B->RPRV
Status:
    Disconnected
```

Note: (*) ENABLE, for valves driven directly by Carel driver, if you need 0-10V (as described in page 49, paragraph 6.15.1...), please set DISABLE

After having configured condensing line 1, the software asks if there is a condensing line 2; answer NO to this question:

```
Wizard 1b98
Configure intercooler
between the suction
lines?
    YES
```

At this point, the software asks if you wish to view a report of the settings performed:


```
Wizard report 1b2a
Enable IO config:
    YES
Visualize report?
    NO
(Push [DOWN]
to continue)
```

If the settings are correct, you can proceed to install the set values:

```
Wizard 1b3a
Boards necessary
1
All boards present
[ENTER] to continue
```

After a few seconds, the unit can be started.


```
Wizard
Successfully completed
Press [ENTER] to
continue
```

 **Note:** after having configured pRack pR300T, the power must be turned off and back on in order to confirm that the data is saved.

4.4 Advanced configuration

```
Start up
Select config.item:
ADVANCED CONFIGURATION
It only defines the
structure of the plant
For very expert users
```

This solution allows you to establish the configuration for the pLAN structure needed for correct operation of the system. Once the procedure for choosing the various factors that influence the final configuration is completed, the pRack pR300T software verifies if the pLAN configuration is exact and shows the user interface for configuring the parameters that must be manually performed by the user.

 **Attention:** this configuration method is recommended only for expert users, since all system parameters must be manually configured.

4.4.1 Associating the inputs and outputs

When using pre-configurations and the wizard, pRack PR300T can automatically associate the board's inputs and outputs with the various functions.

For the wizard only, after having configured the lines, automatic association can be chosen as an option. If choosing not to use this function, the I/Os need to be configured manually, according to requirements.

The criteria applied for automatic association are described below.

Digital outputs

pRack PR300T assigns in order:

- Compressor outputs
- Fan outputs
- Global alarm.

Digital inputs

pRack PR300T assigns in order:

- High and low pressure switches (HP and LP)
- Compressor alarms
- Fan alarms

Note: pRack PR300T can also use certain analogue inputs as digital inputs, nonetheless the common HP and LP pressure switches are always associated with actual digital inputs.

Analogue inputs

pRack PR300T assigns in order:

- Pressure or temperature control probes for 1 or 2 lines, according to the settings made. The types of probe assigned as default are 4...20 mA or 0 to 5 V (first 4...20 mA, then 0 to 5 V if necessary) for the pressure probes, NTC for the suction temperature probes and HTNTC for the condensing temperature probes;
- Suction temperature probe on line 1: if possible this is associated with input U3, otherwise the first free input;
- Discharge temperature probe on line 1;
- Suction temperature probe on line 2;
- Discharge temperature probe on line 2.

Analogue outputs

pRack PR300T assigns in order:

- Compressor inverters for 1 or 2 lines;
- Fan modulating devices.

5. USER INTERFACE

5.1 Graphic terminal

The pRack PR300T user interface is represented by the pGDE terminal, panel or built-in versions. The functions associated with the 6 buttons on the pGDE terminal are the same on all the screens and are described in the table below.

Functions of the 6 buttons

Button	Function associated
(ALARM)	displays the list of active alarms and accesses the alarm log
	used to enter the main menu tree
	returns to the higher level screen
(UP)	scrolls a list upwards or increases the value highlighted by the cursor
(DOWN)	scrolls a list downwards or decreases the value highlighted by the cursor
(ENTER)	enters the selected submenu or confirms the set value.

Tab. 5.a

The LEDs associated with the buttons have the following meanings.

Meaning of LEDs

LED	Button	Meaning
Red		Flashing: active alarms present and not acknowledged Steady: alarms present and acknowledged
Yellow		pRack PR300T on
Green		pRack PR300T powered

Tab. 5.b

5.2 Description of the display

There are three fundamental types of screens shown to the user:

- Main screen
- Menu screen
- Screen for displaying/setting the parameters

Main screen

The main screen is the screen that the software on board pRack PR300T automatically returns to 5 minutes after the last button was pressed.

An example of the main screen is shown in the figure, highlighting the fields and icons used:





Fig. 5.a

- 1 Time and date
- 2 Main values.
- 3 Unit status (unit off) or compressor and fan status (unit on)
- 4 Active alarm Signal and manual operation
- 5 Access further information screens (menu branch A.a) by pressing button


The information relating to the main values (Fig. 5.a) shown on the main screen when first starting vary according to the system configuration (one line, two lines, two lines with shared condenser) and the type of control value (pressure, temperature).

Note: The other information shown in menu branch A.a. varies according to the system configuration. For two line systems, pressing from the main screen accesses a different screen based on the starting point (line 1, line 2).


Starting in version 3.3.0, the main screen can be modified, both in terms of the probe displayed and the value used, from the menu at: F.SETTINGS → b.Language → Fb04





After having set the “probe configurations” (screen Fb04) under “CONFIGURE” and having pressed “ENTER” button, screen Fb05 can be accessed:



Here, for example, the receiver pressure can be entered (rather than the discharge or intercooler temperature), the order of the probes shown can be reversed, and the saturated values of the probe readings displayed. In the same way, the position of the compressor or fan status information in the unit status display (3, Fig.5.a) can be changed, accessing “CONFIGURE” for the “Info Configuration” field on screen Fb04:



Once again, pressing “ENTER” accesses screens Fb09 and Fb10:



In this way, for example, the backpressure or flash gas valve opening percentage can be entered

Menu screen

An example of a menu screen is shown in the figure below:




Fig. 5.b

The top right corner shows the selected item and the current password level (for details see the following paragraph). The ↑ and ↓ buttons are used to select the desired menu item, while ↵ accesses the selected item.

Screen for displaying/setting the parameters

An example of a screen for displaying/setting the parameters is shown in the figure, also highlighting the fields and icons used:




Fig. 5.c

- 1 Menu branch identifier
- 2 Screen identifier
- 3 Parameter

The screen identifier uniquely identifies the menu branch and the screen: the first characters indicate the menu branch, while the last two alphanumeric digits identify the order of the screen inside the menu, for example screen Bab01 is the first screen in menu B.a.b.

Note: The information on the screens may vary according to the password level used to access the menu.

5.3 Password

pRack PR300T manages three levels of password:

- User
- Maintenance
- Manufacturer

Each level includes the same rights as the lower levels, that is, the Manufacturer can access all the screens and parameters, the Maintenance can access the screens and parameters available in the Maintenance and User levels, while the User can only access the screens and parameters available in the User level.

Note: All levels display the main screens and the other information screens.

When pressing Ⓞ a prompt is shown to enter the password, which remains active for 5 minutes after the last button is pressed.

The menu screens show their own password level using an icon at the top right: ■ 1 line: user, ■ 2 lines: maintenance, ■ 3 lines: manufacturer.

The password level can be changed from menu branch F.c. at any time. The password can also be changed in the corresponding menu branch.

5.4 Menu description



U	A . Unit status	a . Main info b . Set Point c . On/off	
I/O	B . INPUTS/OUTPUTS	a . Status b . Manual Manag. c . Test	a . Digital inputs b . Analogue inputs c . Digital outputs d . Analogue outputs a . Digital Out b . Analogue out c . Vacuum a . Digital Out b . Analogue Out
C	C . COMPRESSORS	a . Line 1 b . Line 2 (*) c . Parallel COMP.	a . I/O Status b . Control c . OP. hours d . EN. saving e . Alarms f . Configuration g . Advanced
W	D . Condensers	a . Gas cooler b . Intercooler (**)	a . I/O status b . Control c . EVO driver d . EN. saving e . Alarms f . Configuration g . Advanced a . I/O status b . Control c . EVO driver d . EN. saving e . Alarms f . Configuration g . Advanced
☰	E . Other functions	a . Oil b . Subcooling c . Economizer d . Liquid inh. e . Heat recovery f . generic functions g . Chillerbooster h . DSS i . Transcritical	a . Line 1 b . Line 2 (*) a . Line 1 b . Line 2 (*) a . Line 1 b . Line 2 (*) a . I/O status b . Settings a . Stages b . Modulation c . Alarms d . Time bands e . I/O status a . I/O status b . Settings a . I/O status b . Settings c . EVO settings
⌚	F . Settings	a . Clock b . Languages c . BMS d . Fieldbus e . Passwords	a . I/O status b . Settings a . I/O status b . Settings a . I/O status b . Settings
A	G . Safety	a . Alarm log b . Prevent. c . Alarm Config.	a . Line 1 b . Line 2 (*) a . Line 1 b . Line 2 (*)
?	H . Info		
⚙	I . Setup	a . Pre-configurations b . Wizard c . Advanced config. d . Default	

(*) this menu level is only visible for system configurations with two lines.

Note:

- The figure illustrates the maximum menu configuration visible with the Manufacturer password. If accessing with the User or Maintenance password, only the menu items available are visible
- For some menu items, access is possible with different password levels (e.g. I/O status), but the information available on the screens changes.

6. FUNCTIONS

6.1 Schematic diagram and system configurations used

The schematic diagram of a transcritical system is shown in the figure:




Fig. 6.a

This shows the two medium and low temperature lines, the HPV valve, which separates the high pressure part of the circuit from the medium pressure part, and the RPRV valve which regulates the pressure in the receiver. Both valves can be managed directly by the controller with built-in driver (PRK30TD*).

Management of the system can be performed using one of the system configurations described hereafter.

Configuration 1: a pRack pR300T board for managing both suction lines and control of the high pressure part (this configuration can be used also as a backup controller):




Fig. 6.b

Configuration 2: 1 a pRack pR300T board for each suction line and 1 pRack pR300T board for control of the high pressure part (gas cooler and HPV, RPRV valves):




Fig. 6.c

Configuration 3: a pRack pR300T board to manage the medium temperature suction line and control of the high pressure part and a board for managing the low temperature suction line:




Fig. 6.d

Configuration 4: a pRack pR300T board for managing the two suction lines and a board for control of the high pressure part:




Fig. 6.e

6.2 Unit On-Off

The unit can be switched on and off from:

- User terminal
- Supervisor
- Digital input

On-off from the user terminal and the configuration parameters are available under the main menu, branch A.c, and are differentiated based on the access level; the User password allows display only.

On-off from the supervisor and from the digital input and start-up after a blackout (with specific delay, to avoid continuous starts and stops in the event of instability in the power supply) must be enabled using the parameters visible only with the Manufacturer password.

On-off from the digital input is equivalent to an enabling Signal, that is, if the digital input is Off the unit cannot be switched on in any other way, while if is On, the unit can be switched on or off in any other way, with the same priority (the most recent control has precedence, whatever the origin), as shown in the figure:




Fig. 6.f

When there are two suction lines and condenser lines, on-off is independent for each line, while when there are two suction lines and one condenser line, it is independent for the suction lines, while the condenser line stops when both suction lines are off, and starts when at least one suction line is ON.



Note: certain special conditions or functions in the pRack software cause the unit to shutdown:

- Configuration of some parameters: e.g. inputs/outputs, configuration of compressors, inverter parameters.
- Installation of default parameters
- Manual management

6.3 Control

pRack PR300T can manage two types of control:

- Proportional band (P, P+I);
- Neutral zone (fixed times, variable times).

Both types of control can be applied to both compressors and condensers, according to the settings defined during start-up or in main menu branches C.a.b/C.b.b and D.a.b/D.b.b.

The type of control chosen is independent for each line present, either suction or condenser. In addition, pRack PR300T can use as the reference for control either the pressure or the converted temperature, or the temperature read by probe if there is no pressure probe, even if reference is only made to pressure below.

The control set point can be compensated by an offset linked to digital inputs, probes, supervisor or time bands, for details see paragraph 6.5 relating to compressor and fan energy saving. Both types of control are described below, and are valid for both control of suction pressure and condensing pressure, and operation with backup probes and/or probes not working.

6.3.1 Proportional band

The operating principle is normal proportional or proportional + integral control (P, P+I).

The control set point is central, consequently - for proportional control only - operation is schematised in the following figure:




Fig. 6.g

For example, for 4 devices with the same capacity and proportional only control, start-up occurs as shown in the figure:




Fig. 6.h

CAREL

With P+I control, added to the effect of the proportional action described above is the integral action, used to achieve a null control error in steady operation, as shown in the figure:




Fig. 6.i

The integral action depends on the time and the deviation from the set point. This modifies the request if the control value does not approach the set point for some time.

The integral time setting represents how fast integral control is implemented:

- low values determine fast and intense control action
 - high values determine slower and more stable control action
- It is recommended to not set a value that is too low for the integral time, to avoid instability.

Note: the set point is in the centre of the activation band, therefore when reaching the set point some devices are on, even with purely proportional control.

6.3.2 Neutral zone

The operating principle is schematised in the following figure:




Fig. 6.j

Inside the neutral zone the capacity request sent by the controller is constant (except when there is a modulation device and modulation is enabled inside the neutral zone, as described in the following paragraph) and the value satisfies the temperature control request in those specific operating conditions, therefore within this zone no device is stopped or started.

In the decrease zone, the request also decreases at a rate that depends on the deviation from the set point, and vice-versa in the increase zone the request increases proportionally to the deviation.

- For the increase and decrease zones, the following can be used:
- Fixed times: the request decreases or increases constantly as time elapses.
 - Variable times: the request decreases or increases more quickly (according to the settings) as the deviation from the set point increases.

Note: The previous figure shows the increase and decrease with fixed times.

For control in Neutral zone, the parameters shown in the figure must be set:




Fig. 6.k

As well as the decrease and increase differentials, 4 times need to be set, two for each zone, which represent the maximum and minimum time to reach the request, equal to 0% or 100%, for the decrease and increase respectively.

Tutorial: the decrease/increase times (minimum and maximum) represent the time needed to change from maximum to minimum capacity and vice-versa, and not the time between the deactivation/activation of the individual device. For example, in the case of 4 devices with the same capacity, an increase time of 180 s means that one device is activated every 45 s.

In the situation shown in the figure, the request sent by the controller decreases/increases slowly as soon as the controlled value is outside of the Neutral zone, while it decreases/increases quickly the further the controlled value moves away from the Neutral zone; in this way the response of the system is faster when further from steady conditions.

Note: When using fixed times, the maximum and minimum must be set to the same value. In this case, the request sent by the controller decreases/increases constantly inside the deactivation/activation differential.

6.3.3 Modulation in Neutral zone

pRack PR300T can activate a specific function inside the Neutral zone if modulating devices are used (e.g.: inverters). This function can be enabled in main menu branch C.a.g/C.b.g or D.a.g/D.b.g.

Modulation in Neutral zone is used to vary the request sent by the controller inside the Neutral zone so as to enter the decrease zone with the minimum request and the increase zone with the maximum request, meaning a device can be immediately deactivated/activated when exiting the Neutral zone.

This makes it possible to remain longer inside the neutral zone without starting or stopping any device.

An example of this operation is shown in the figure:




Fig. 6.l

When entering the Neutral zone, the pRack PR300T software calculates how the request needs to change in order to exit the Neutral zone at minimum or maximum output, and applies one of the two values according to the trend in variation in the control variable. For example, at point P1 in the figure, the trend of the two requests is represented by the segments with thin lines, and the request 'reverses' because at that point the control variable has started increasing in value again.

Note: When exiting the Neutral zone, it is possible that the request is not at the minimum or maximum value, where limitation is enabled for of the modulating device variation speed.

6.3.4 Control with backup probes and/or probes not working

pRack PR300T can use backup control probes that are activated when the normal control probes are not working.

The backup probes must be enabled in main menu branch C.a.g/C.b.g or D.a.g/D.b.g.

When different pRack boards are used to manage the suction and condenser lines, the backup suction pressure probe must be connected to the board that manages the suction line, while the backup condensing pressure probe can be connected either to the board that manages the suction line or the board that manages the condenser line.

If the main control probes are not working and no backup probes are fitted, or the backup probes are also not working, or the corresponding temperature probes are also not working, fixed values are used for the control request, set in main menu branch C.a.g/C.b.g or D.a.g/D.b.g.

6.4 Compressors

pRack PR300T can manage up to 2 suction lines with different types of compressors and capacity modulation devices, applying common types of device rotation and controlling both the start mode and the safety times for each type of compressor, as well as a number of accessory functions. The compressor functions and related parameter settings are enabled from main menu branch C.a/C.b. These features and functions are described in detail in the following paragraphs.

6.4.1 Possible compressor configurations

pRack PR300T can manage different types of compressors:

- Reciprocating
- Scroll

Moreover, a capacity modulation device is allowed for each suction line, which may be one of the following, according to the type of compressor:

Compressors and modulation devices

Compressors	modulation devices
Reciprocating	Inverter
Scroll	Inverter Digital Scroll™

Tab. 6.a

Note: The same modulation device is used on each line.

The maximum number of compressors and load stages per line varied according to the type of compressor:

Compressors and modulation devices

Compressors	Maximum No.	Load stages
Reciprocating	12	24 total
Scroll	12	24 total

Tab. 6.b

The compressor size refers to its capacity and number of load stages or to the inverter presence, therefore different sizes need to be defined for compressors with the same capacity yet a different number of load stages. The inverter is always associated to size 1.

- Tutorial:** below is one example of some possible configurations:
- One line, 4 reciprocating compressors with the same capacity, the first with inverter (2 sizes).
 - One line, 4 scroll compressors with the same capacity, the first Digital Scroll™ (1 sizes).
 - One line, 4 reciprocating compressors with the same capacity, the first two with 4 load stages, the other two not capacity-controlled (2 sizes).
 - One line, 4 reciprocating compressors with the same capacity and 4 load stages each (1 size).
 - Two lines, line 1 with 4 scroll compressors, the first Digital Scroll™, line 2 with 4 reciprocating compressors, the first with inverter (1 size line 1, 2 sizes line 2).

6.4.2 Rotation

pRack PR300T can manage 4 different types of device rotation:

- FIFO (First In First Out): the first device to start is also the first to stop
- LIFO (Last In First Out): the last device to start is the first to stop
- By time: the device with the least number of operating hours starts and the device with highest number of operating hours stops
- Custom: the on/off sequences are defined by the user

NB: Different Sizes of compressors can only be managed with Custom rotation.

The type of rotation is selected and the corresponding parameters set during the start-up procedure or in main menu branch C.a.f/C.b.f. The activation thresholds are calculated differently depending on whether FIFO, LIFO, time or Custom rotation is used:

Device activation threshold calculation

Rotation	Threshold calculation
FIFO	Static: the range of variation of the control request is divided equally between the number of stages available
LIFO	
By time	
Custom	Dynamic: the thresholds are calculated depending on the capacity effectively available

Tab. 6.c

Example 1: FIFO rotation, 4 compressors of the same capacity without load stages.

The activation thresholds are 25, 50, 75 and 100 %.




Fig. 6.m

Example 2: Custom rotation, 4 compressors with capacities of 10, 20, 30 and 40 kW. The activation thresholds with all the compressors available are 10, 30, 60, 100 %.




Fig. 6.n

CAREL

If an alarm is active on compressor 3, the recalculated activation thresholds are 10, 30, 70 %.




Fig. 6.o

Activation of the compressors and load stages may be:

- Grouped (Cpccpp): first all the load stages are activated on one compressor before starting the next one
- Balanced (CCppppp): first all the compressors are started at minimum capacity and then the corresponding load stages are activated, one for each compressor, in sequence.

6.4.3 Rotation with modulation devices

pRack PR300T can also manage compressor rotation when a capacity modulation device is fitted (inverter, Digital Scroll™ or continuous control). The type of modulating device is selected and the corresponding parameters set during the start-up procedure or in main menu branch C.a.f/C.b.f and C.a.g/C.b.g

The modulating device is always the first to start and the last to stop irrespective of the type of rotation, the other devices start or stop according to the type of rotation selected.

Note: The compressor with modulation device is also assumed to be the first.

The trend in capacity delivered by the modulation device depends on the capacity of the compressor with the modulating device compared to the other compressors available.

Three cases can be identified:

- compressors all with the same capacity and range of capacity variation of the modulating device greater than or equal to the capacity of the compressors
- compressors all with the same capacity and range of capacity variation of the modulating device less than the capacity of the compressors
- compressors with different capacities

In the first case, the modulating device manages to continuously cover the range of variation of the control request, while in the second case some discontinuous variations remain. The behaviour in the third case varies according to the capacities involved, and in any case reflects one of the two previous cases.

To configure the compressor capacity when an inverter is used, the minimum and maximum operating frequencies need to be set relating to the minimum and maximum value of the analogue output and the rated capacity delivered at rated frequency (50 Hz), so that the pRack PR300T software can calculate the capacity the compressor can deliver with the inverter and use this value for control. In addition, for inverters the variation in capacity delivered can be limited by setting the increase and decrease times. If these times have already been configured on the inverter, the higher time set has priority.

Example 1: range of modulating device capacity variation higher than the capacity of the compressors:

Two compressors without capacity control, with the same capacity, 20 kW each, modulating device with variable capacity between 30 and 60 kW. The figure shows the trend when the request sent by the controller increases and then decreases continuously between 0 and 100 %.

It can be seen that the capacity delivered exactly follows the required capacity, except when below the minimum capacity of the modulating device.




Fig. 6.p

Example 2: range of modulating device capacity variation lower than the capacity of the compressors: two compressors without capacity control, with the same capacity, 30 kW each, modulating device with variable capacity between 20 and 40 kW.

It can be seen that the capacity delivered does not exactly follow the required capacity, rather acts in steps, so as to avoid swings.




Fig. 6.q

Example 3: range of modulating device capacity variation in between the capacity of the compressors, all different sizes: two compressors without capacity control, capacities 15 kW and 25 kW, modulating device with variable capacity between 10 and 30 kW.




Fig. 6.r

6.4.4 Starting

pRack PR300T can manage different types of compressor starting:

- Direct
- Part-winding
- Star/delta

The type of starting can be selected and the related parameters set in main menu branch C.a.f./C.b.f.

For part-winding starting, the delay in activating the digital output that controls the second winding needs to be set:




Fig. 6.s

For star/delta starting, the star time, the delay between the activation of the line and star digital input, and between the delta and star digital input all need to be set, as shown in the figure:




Fig. 6.t

6.4.5 Safety times

pRack PR300T can manage common safety times for each compressor:

- Minimum on time
- Minimum off time
- Minimum time between consecutive starts

The related parameters can be set in main menu branch C.a.f./C.b.f.

Note: for two lines, a further delay can be set between starts of the compressors on different lines, so as to avoid Simultaneous starts. See paragraph 6.6.6 for the detailed description of the synchronisation function for two lines (DSS).

The minimum ON time is always considered, with the exception of when an alarm is activated that is configured to stop the compressor

6.4.6 Balancing

pRack PR300T can control any balance valves in parallel with the compressors.

This function can be used to activate a communicating solenoid valve between compressor suction and discharge, for a set time, before each individual compressor starts. In this way, the suction and discharge pressure can be balanced and the compressor can be started in more favourable conditions.

The balancing function can be enabled and the related activation time set in main menu branch C.a.f./C.b.f.

6.4.7 Economizer

pRack PR300T can activate the economizer function to boost compressor efficiency by injecting vapour. Some of the liquid is taken from the condenser, expanded through a valve and then sent to a heat exchanger to cool the liquid leaving the condenser. The resulting superheated vapour is injected into a special section of the compressor.

The function can be enabled and the related parameters set in main menu branch E.c.a.b.

The economizer is only efficient for high compressor activation capacities, typically over 75 %, therefore the economizer function control valve is only activated when exceeding a set threshold.

As the economizer tends to increase the condensing pressure, this needs to be controlled to ensure the high condensing pressure alarm is not generated. In addition, the injection of vapour decreases the discharge temperature and so this value also needs to be monitored.

Consequently, the three conditions for activation of the economizer function are:

- Capacity above a set threshold
- Condensing pressure below a set threshold (with reset differential)
- Discharge temperature above a set threshold (with reset differential)

Note: the function can be activated on a maximum of 6 compressors.

6.4.8 Liquid injection

As an alternative to the economizer, pRack PR300T can manage the injection of liquid into the compressors (the two functions are alternative, as the point of vapour injection into the compressor is the same).

The function can be enabled and the related parameters set in main menu branch E.d.a.b./E.d.b.b.

Liquid injection is used to protect the compressor, and in fact decreases the discharge temperature. Operation is similar to the economizer function, with the difference that the expanded liquid is not sent to a heat exchanger, but rather directly into the compressor. The function is only activated when the compressor is on and the discharge temperature exceeds a set threshold (with differential).

Note: the function can be activated on a maximum of 6 compressors.

6.4.9 Manual operation

pRack PR300T can manage 3 different compressor manual operating modes:

- Enabling / disabling
- Manual management
- Output test

Enabling / disabling is managed in main menu branch C.a.f./C.b.f., while manual management and the output test can be activated in main menu branch B.b or B.c.

Enabling / disabling is used to temporarily exclude the compressors from operation, to allow, for example, repair or replacement. The disabled compressors are also excluded from rotation.

Note: enabling is the only compressor manual operating mode that can be activated when the unit is on.

Both manual management and the output test are enabled by parameter and remain active for a set time after the last button is pressed, after which the unit returns to normal operating mode.

Manual management is used to switch the compressors on or off without observing the control needs, however still considering any safety devices (alarms, safety times, starting procedures) and respecting the set configuration of the inputs/outputs.

CAREL

The activation screen resembles the one shown in the figure and is used to override the outputs relating to the operation of the selected device, e.g. compressor 1:




Fig. 6.u

The output test is used to activate or deactivate the outputs (where necessary setting an output percentage for the analogue outputs), without observing any type of safety feature.

The activation screen resembles the one shown in the figure and is used to override the outputs on the pRack boards, in the order they physically appear on the board (without links to the devices):




Fig. 6.v

Important: manual mode and the output test can only be activated with the unit off. Both manual mode and above all the output test must be used with special care and by expert personnel to avoid damage to the devices.

Digital Scroll™ compressors

pRack PR300T can use a Digital Scroll™ compressor as the modulating device for suction lines (one for each line). This type of compressor features special operation, and is controlled by pRack PR300T as follows.

The related parameters can be set in main menu branch C.a.f/C.b.f. The capacity is modulated by opening/closing a valve with PWM; when the valve is ON the compressor delivers minimum capacity, while when the valve is off the compressor delivers maximum capacity. In the following description and figure, ON and OFF refer to the status of the compressor, while operation of the valve is the exact opposite:




Fig. 6.w

The following data are provided by the manufacturer of the compressor:

- minimum ON time 2 s
- maximum cycle time 20 s
- optimum cycle time 12 s

There are three possible operating modes:

- Fixed cycle time
- Variable cycle time
- Optimised cycle time

Based on the operating mode selected, pRack PR300T calculates the valve activation percentage that satisfies the required capacity.

Fixed cycle time

The compressor ON time is calculated as the percentage of the cycle time corresponding to the required capacity:

$$T_{ON} = \% \text{ Richiesta} * \text{Tempo di ciclo}$$

The cycle time can be set to the optimum value suggested by the manufacturer to achieve maximum COP, or to a higher value to increase resolution of the capacity delivered (a higher cycle time implies greater continuity in the effective capacity that can be delivered).

Variable cycle time

The compressor ON time is set to 2 s and the cycle time is calculated based on the required capacity:

$$T_{CICLO} = T_{ON} / \% \text{ Richiesta}$$

Optimised cycle time

The compressor ON time is set to 2 s and the cycle time is calculated based on the required capacity for capacities less than 17 %, after which the cycle time is set to 12 s and the ON time varies. In essence, this mode is a combination of the previous two. This guarantees the maximum possible COP and control rate (obtained with the 12 s cycle time) and the maximum control range (starting from 10 %).

Note: the minimum capacity that can be delivered by Digital Scroll™ compressors is Minimum ON time/Maximum cycle time = 2/30 = 6.7 %, which also depends on the selected control mode (for example, in the first case shown in the figure the minimum capacity delivered is Minimum ON time/Cycle time = 2/15 = 13%).

Note: if high pressure prevention is enabled with activation/deactivation of the devices, the Digital Scroll™ compressor delivers the minimum possible capacity.

Starting procedure

pRack PR300T can manage the specific starting procedure for Digital Scroll™ compressors, as represented as in the following figure:




Fig. 6.x

There are three stages:

1. balance: the PWM valve is activated for 4 s, so that the compressor delivers minimum capacity;
2. compressor activation with 50 % capacity for 3 minutes;
3. forced operation at 100 % for 1 minute.

During the starting procedure, the request sent by the controller is ignored and only at the end of the procedure does the capacity delivered start reflecting the request. If the request is cancelled during the starting procedure, the compressor stops at the end, then the minimum ON time for these types of compressors is set to 244 s.

The starting procedure is performed when the compressor is started, while it can be disabled for a set time by parameter for subsequent starts, if the compressor has not remained off for a minimum set time. After this time has elapsed the procedure is performed again during the following start.

Note: the safety times for Digital Scroll™ compressors are established by the manufacturer, and are as follows:

- Minimum ON time: 244 s (starting procedure)
- Minimum OFF time: 180 s
- Minimum time between restarts: 360 s

Alarms

pRack PR300T can manage, in addition to the common alarms for all types of compressors (see chapter 8 for details), some specific alarms for Digital Scroll™ compressors:

- high oil temperature
- oil dilution
- high discharge temperature

These alarms are managed as specified by the manufacturer of the compressor, and therefore pRack PR300T can only enable or disable them. Activation of these alarms requires an oil temperature probe, which can also be the common probe (see the paragraph relating to oil management) and the compressor discharge temperature probe.

Note: pRack PR300T does not manage the envelope for Digital Scroll™ compressors and consequently there is no corresponding alarm when operating outside the envelope.

6.5 Gas cooler

pRack PR300T manages the gas cooler in a manner that is completely similar to the pRack PR300T for the condensers, with the only difference being that in transcritical conditions, as there is no longer correspondence between pressure and saturated temperature, temperature control is active by default, but starting from version 3.1.5, pressure control is also available for the fans. The regulation variable, therefore, is the output temperature from the gas cooler.

Up to 16 fans can be managed, also with inverter modulation. In the event of modulation, the modulating output 0...10 V is unique while an input can be managed for each fan for signalling the alarms.

The functionalities can be enabled and the relative parameters can be set from main menu branch D.a.

6.5.1 Control

pRack PR300T can manage proportional band and Neutral zone control, by pressure or temperature.

For details on the control modes, see the corresponding paragraph, while below is the description only of the features relating to the fans.

Fan operation depending on the compressors

The operation of the fans can be bound to the operation of the compressors by setting a parameter in main menu branch D.a.b/D.b.b, in this case the fans only start if at least one compressor is on. This setting is ignored if the fans are controlled by a dedicated pRack PR300T board and the pLAN network is disconnected.

Fan operation with modulating device

If the fans are controlled by a modulating device, the meaning of the parameters that associate the minimum and maximum values of the device's modulating output and the minimum and maximum capacity of the modulating device on screens Dag02 and Dbg02 is illustrated in the following examples.

Example 1: minimum modulating output value 0 V, maximum value 10 V, minimum modulating device capacity 0 %, maximum 100 %.




Fig. 6.y

Example 2: minimum modulating output value 0 V, maximum value 10 V, minimum modulating device capacity 60 %, maximum 100 %.




Fig. 6.z

Example 3: minimum modulating output value 2 V, maximum value 10 V, minimum modulating device capacity 60 %, maximum 100 %.




Fig. 6.aa

Cut-off

pRack PR300T manages a control cut-off for the fans; functions and related parameter settings can be enabled from main menu branch D.a.b/D.b.b. The operating principle of the cut-off function is shown in the figure:




Fig. 6.ab

A percentage of the control request and a cut-off set point can be set. When the control request reaches the set cut-off value, this value is kept constant until the control value falls below the cut-off set point, after which it falls to 0 % and remains there until the request exceeds the cut-off value again.

6.5.2 Rotation

pRack PR300T can manage rotation of the fans, much in the same way as described for the compressors, therefore:

- LIFO, FIFO, time, Custom rotation
- Management of a modulation device on each line

The substantial difference compared to the compressors concerns the possibility to manage different capacities and load stages, which are obviously not featured for the fans. In addition, pRack PR300T can specially manage inverter driven fans. In fact, a multiple number of inverter driven fans can be set.

If there is more than one fan, however the number of inverter driven fans is set to 1, the fans are started and stopped at the same time, and the fans will always all be at the same power.

If there is more than one inverter driven fan, as well as being able to use an alarm digital input for each, it is assumed that the weight of the modulating device is proportional to the number of fans, therefore the first case is applied, as described previously: fans all with the same power and modulating device power variation range greater than or equal to the capacity of the other devices.

Example 1: 4 fans all controlled by the same inverter correspond to 1 fan with four times the power.

Note: some fans can be excluded from the rotation, for example in the winter; to do this use the split condenser function.

The table shows some examples of fan configurations on pRack300T, based on the number of fixed and variable-speed fans in the system.

CASE	Inverter	N. fans (Wizard or Condensing/Config): number of fans physically present on the unit	N. fans mng (Condensing/Advanced): number of fans connected to the 1st modulating 0-10V signal	Diagram	VERS.<=3.2.8			VERS >=4.0.1			Notes	Changed	Backward compatibility
					Fan1 Overload	Fan2 Overload	Fan3 Overload	Fan1 Overload	Fan2 Overload	Fan3 Overload			
0	NO	3	N.O.		OFF F1	OFF F2	OFF F3	OFF F1	OFF F2	OFF F3		NO	OK
1	YES	1	1		ONLY F1 warning, no actions	N.O.	N.O.	OFF F1 AOUT F1=0	N.O.	N.O.	fix of the claim	YES	OK, fixed a problem
2	YES	1	3		ONLY F1 warning, no actions	ONLY F2 warning, no actions	ONLY F3 warning, no actions	ONLY F1 warning, no actions	ONLY F2 warning, no actions	ONLY F3 warning, no actions	config. suggested by Carel	NO	OK
3A	YES	3	1		ONLY F1 warning, no actions	OFF F2	OFF F3	OFF F1 AOUT F1=0	OFF F2	OFF F3		YES	OK, fixed a problem
3B	YES	3	1		ONLY F1 warning, no actions	OFF F2	OFF F3	OFF F1 AOUT F1=0	OFF F2	OFF F3	(1*)	YES	OK, fixed a problem
4A	YES	3	3		ONLY F1 warning, no actions	OFF F2	OFF F3	ONLY F1 warning, no actions	OFF F2	OFF F3	(2*)	NO	OK
4B	YES	3	3		ONLY F1 WARNING, NO ACTIONS	OFF F2	OFF F3	ONLY F1 WARNING, NO ACTIONS	OFF F2	OFF F3	(3*)	NO	OK

Tab. 6.d

(1*) = PAY ATTENTION: for this config., fan 1 overload alarm forces off ALL the other fans. WORKAROUND: don't configure fan 1 overload but inverter warning

(2*) = CONFIGURATION NOT SUGGESTED BY CAREL. Some extra fan overload digital inputs (in the example fan 4 and fan 5 overload) will be available for the fans linked to the 0-10V signal (in the example F1.4 and F1.5) and will follow the behaviour of the first fan (warning only).

(3*) = CONFIGURATION NOT SUPPORTED. Some extra fan overload digital inputs (in the example fan 4 and fan 5 overload) but these don't have to be configured. NOTE: A wrong calculation for the 0-10V signal is provided

6.5.3 Fast start (speed up)

pRack PR300T can manage the fast start function (speed up), used to overcome the initial inertia of the fans. The function can be enabled and the related parameters set in main menu branch D.a.g. If speed up is enabled, a start time can be set in which the fan speed is forced to 100%. If the outside temperature sensor is used, moreover, a threshold can be set (with reset differential) below which speed up is disabled, so as to not drastically lower the condensing pressure at start-up.

Note: speed up has lower priority than the Silencer function (see the following paragraph for the details), therefore if the Silencer function is active, this is disabled.

6.5.4 Silencer

pRack PR300T can manage the Silencer function, used to limit fan speed at certain times of the day or in specific conditions, enabled by digital input.

The function can be enabled and the related parameters set in main menu branch D.a.g.

Enabling fan speed limitation from the digital input or based on time bands is independent, consequently the speed is limited to the set value when at least one of the two conditions is active. Up to 4 activation bands can be set for each day of the week.

6.5.5 Split condenser

pRack PR300T can manage the possibility to exclude some fans from operation, for example to reduce gas cooler operation in winter, using the split condenser function.

The function can be enabled and the related parameters set in main menu branch D.a.g.

Split condenser can be used to exclude from rotation fans whose index is:

- even
- odd
- higher than a settable value
- lower than a settable value

The function can be activated by:

- time bands (winter/summer seasons)
- digital input
- supervisor
- outside temperature (set threshold and differential)

Note:

- the split condenser function can be disabled by parameter if the high pressure prevention function is activated. If split condenser is disabled due to activation of the high pressure prevention function, it remains disabled for a set time, after which it is reactivated.
- split condenser cannot be enabled if there is a speed modulation device that controls all the fans.

6.5.6 Manual operation

pRack PR300T can also manage the same three manual operating modes for the fans as described for the compressors:

- Enabling
- Manual management
- Output test

Enabling is managed in main menu branch D.a.f/D.b.f., while manual management and the output test can be activated in main menu branch B.b or B.c. For the detailed description of the three modes, see paragr. 6.3.9.

6.5.7 Alarms

pRack PR300T can manage both a common alarm for the fans and separate alarms for each fan.

When the common alarm is active the alarm is signalled, but no fan is stopped, while for separate alarms the fan that the alarm refers to is stopped.

6.6 HPV valve management

Management of the HPV valves, which separates the high pressure part of the system from the medium pressure part, determines the transcritical and subcritical operation mode of the unit. In transcritical mode, valve regulation is done to obtain maximum yield while in subcritical mode, regulation controls the subcooling. The HPV valve has a proportional + integral (PI) type of regulation which uses an optimal pressure value of the gas cooler calculated on the basis of the gas cooler pressure and temperature as a regulation setpoint, as described hereafter. Enabling HPV valve management coincides with enabling the transcritical system management mode. The HPV valve can be managed directly by pRack PR300T with built-in driver (PRK30TD***) or with external EVD EVO driver. Both solutions are compatible with the majority of valves available on the market. Direct control via serial connection is enabled under EEVS (electronic expansion valve settings), accessible from the main menu, branch E.i.c. The configuration parameters, on the other hand, are accessible from the main menu, branch E.i. The algorithm for calculating the regulation setpoint of the HPV valve can be optimized or customized by the user according to what was set by the parameter.

Calculation of the optimized setpoint

The calculation of the optimized setpoint is illustrated in the figure.




Fig. 6.a.c

The HPV valve is managed according to the zone identified based on the output temperature and gas cooler pressure.

In order to define the zones, it is necessary to set the two pressure values $P_{100\%}$ and P_{max} , the two temperatures T_{12} , T_{23} related to points B and C in the figure and the two temperatures T_{min} and $T_{100\%}$.

In the following, with T_{gc} and P_{gc} , the temperature and pressure of the gas cooler will be indicated.

The behaviour of the HPV valve in the various zones is as follows:

- **Transcritical zone**, identified by $T_{gc} \geq T_{12}$ and $P_{gc} \leq P_{max}$: the valve works with proportional + integral (PI) type integration in order to maintain the maximum COP given by the optimal pressure P_{opt} calculated as a function of the output temperature from the gas cooler T_{ogc} .
- **Subcritical zone**, identified by $T_{min} \leq T_{gc} \leq T_{23}$: the valve works with PI regulation in order to maintain constant subcooling.
- **Transition zone**, identified by $T_{23} \leq T_{gc} \leq T_{12}$: the valve works with PI regulation with a pressure setpoint identified as the conjunction of points B and C in the figure, obtained by calculating the optimal pressure at the limit of the transcritical and subcritical zones. The purpose of this zone is to avoid discontinuity in passing between the two zones.
- **Upper proportional zone**, defined by $P_{max} < P_{gc} < P_{100\%}$: the valve works with only proportional regulation between the opening value reached at pressure P_{max} and the maximum opening value at pressure $P_{100\%}$. If the pressure decreases, the opening value of the HPV valve remains constant until it enters the transcritical zone, in which the regulation restarts as previously described.

- **Lower proportional zone**, defined by $T_{100\%} < T_{gc} < T_{min}$: the valve works with only proportional regulation between the opening value reached at temperature T_{min} and the maximum opening value at temperature $T_{100\%}$. If the pressure increases, the opening value of the HPV valve remains constant until it enters the subcritical zone, in which the regulation restarts as previously described. It is possible to disable operation according to this mode by parameter.

Calculation of the customized setpoint (custom)

The customized calculation differs from the optimized control due to the fact that the curve in the subcritical phase is rectilinear and defined by the user, therefore the definition of the bands and the calculation of the setpoint can be customized by the user. Behaviour in the remaining bands is as described for the optimized algorithm.

HPV valve accessory functions

HPV valve management includes some accessory functions:

- **Pre-positioning**: entering the unit ON status, the HPV valve remains at a fixed position that can be set by a parameter for a fixed time, which is also settable by a parameter, in order to be able to quickly raise the pressure in the tank. This procedure is reactivated whenever the unit goes into the OFF status or the HPV valve moves into the minimum position due to all of the compressors being turned off (optional).
- **Valve closure with compressors off**: if all compressors in the medium temperature unit are turned off, the HPV valve can be positioned at the minimum opening value in the OFF status, which can be set by a parameter. When a compressor is restarted, the valve restarts the regulation with the pre-positioning procedure described in the previous point.
- **Minimum and maximum opening values**: the minimum opening value in Off status and in ON status can be differentiated (by keypad, digital input or supervisor) which the maximum opening value is unique.
- **Maximum percentage variation**: the movement of the valve cannot exceed the maximum set percentage variation per second.
- **Filter on setpoint**: the calculation of the regulation setpoint of the HPV valve can be done by taking into account the averages of the last *n* samples (maximum 99) to avoid sudden variations due to high variability of the output temperature of the gas cooler.
- **Minimum setpoint**: a minimum value can be set for the HPV valve setpoint, below which the setpoint can never go regardless of the parameters entered, in order to preserve the operation of the compressors.
- **Setpoint distance alarm**: if the gas cooler pressure is too far from the calculated setpoint for too long (threshold and delay can be set), an alarm can be triggered.

6.6.8 Control of the receiver pressure through the HPV valve

If the pressure in the receiver goes below the minimum work pressure set, the dynamic calculated setpoint for the HPV valve can be changed in order to increase the pressure in the receiver.

An offset in proportion to the distance from the minimum threshold is subtracted from the calculated setpoint so that the greater opening of the HPV valve contributes to increasing the pressure in the receiver.

The offset is directly proportional to the distance from the minimum work threshold, as illustrated in the figure:




Fig. 6.ad

On the other hand, if the pressure in the receiver goes above the maximum work pressure set, the dynamic calculated setpoint for the HPV valve can be changed in order to decrease the pressure in the receiver. An offset in proportion to the distance from the maximum threshold is added to the calculated setpoint so that the lesser opening of the HPV valve contributes to decreasing the pressure in the receiver. The offset is directly proportional to the distance from the maximum work threshold, as illustrated in the figure:




Fig. 6.ae

6.6.9 Summary of inputs, outputs and HPV valve par.

The following is a summary table of the inputs/outputs used and the parameters with indications of the related configuration screens. For details, refer to Appendix A.1.

Summary of inputs/outputs and HPV valve parameters

	Mask	Description	
Analog inputs	Bab04, Daa39	Gas cooler pressure	
	Bab61, Daa43	Gas cooler output temperature	
	Bab09, Daa40	Gas cooler backup pressure	
	Bab62, Daa44	Gas cooler output backup temperature	
Digital inputs	Baade, Eia04	HPV valve alarm	
Analog outputs	Bad14, Eia06	HPV valve output	
Digital outputs	---	---	
Parameters			
Settings	Eib01	HPV valve management enabled, or transcritical operation mode enabled Selecting the type of algorithm to apply to the calculation of the pressure setpoint	
	Zone definition	Eib05	$P_{100\%}$ upper pressure limit P_{max} pressure for defining the upper proportional zone P_{critic} optimal pressure calculated at the passage temperature between the intermediate zone and transcritical zone T_{12} temperature limit between the transcritical zone and intermediate zone T_{23} temperature limit between the intermediate zone and subcritical zone T_{min} temperature for defining the lower proportional zone
Eib06		$T_{100\%}$ temperature for defining the complete opening zone of the valve Subcooling delta for optimized regulation Coefficient for determining the customized line	
Regulation		Eib07	Proportional gain for the proportional + integral regulation of the HPV valve Integral time for the proportional + integral regulation of the HPV valve Proportional gain for the proportional + integral regulation of the HPV valve with heat recovery Integral time for the proportional + integral regulation of the HPV valve with heat recovery
		Eib16	Enabling the regulation of the gas cooler in the subcritical zone
		Safeties	Eib02
Eib03	Opening of the HPV valve at start-up during pre-positioning Pre-positioning duration		
Eib08	Enabling of the filter action on the HPV valve setpoint Number of samples		
Eib09	Enabling of different management of the HPV valve during heat recovery activation Setpoint regulation of the HPV valve during heat recovery Time scale for the setpoint reset procedure after heat recovery Pressure scale for the setpoint reset procedure after heat recovery		
	Eib10	HPV valve safety position	

Safeties	Eib11	Offset to be applied to the external temperature in the event of gas cooler temperature probe error
	Eib12	HPV valve safety procedure enabling
	Eib13	Receiver high pressure threshold
		Maximum allowed receiver pressure
		Maximum offset to add to the HPV setpoint when the receiver pressure exceeds the high pressure threshold
	Eib14	Receiver low pressure threshold
		Minimum allowed receiver pressure
		Maximum offset to subtract from the HPV setpoint when the receiver pressure goes below the low pressure threshold
	Eib15	Enable HPV valve closure when all compressors on line 1 are off
		Delay HPV valve closure when all compressors on line 1 are off
	Eib17	Enable warning function when the gas cooler pressure is too far from the setpoint for the set time
		Difference between the gas cooler pressure and the setpoint which generates the warning
		Delay time before generating the warning
Eib32	Maximum opening of the HPV valve	
	Maximum variation per second allowed for the HPV valve output	
Eib28	Minimum HPV valve regulation setpoint	
	Enable low temp. control (lower proportional zone)	

6.7 RPRV valve management

Management of the RPRV valve, which is a PI regulation, is to maintain the pressure inside the CO₂ receiver equal to the setpoint. The RPRV valve can be managed directly by pRack pR300T with built-in driver (PRK30TD***) or with external EVD EVO driver. Both solutions are compatible with the majority of valves available on the market. Direct control via serial connection is enabled under EEVS (electronic expansion valve settings), accessible from the main menu, branch E.i.c. The configuration parameters, on the other hand, are accessible from the main menu, branch E.i.

6.7.1 RPRV valve accessory functions

RPRV valve management includes some accessory functions:

- **Pre-positioning:** entering the unit ON status, the RPRV valve remains at a fixed position that can be set by a parameter for a fixed time, also settable by a parameter, in order to be able to quickly raise the pressure in the tank. This procedure is reactivated whenever the unit goes into the OFF status or the RPRV valve moves into the minimum position due to all of the compressors being turned off (optional).
- **Valve closure with compressors off:** if all compressors in the medium temperature unit are turned off, the RPRV valve can be positioned at the minimum opening value in the OFF status, which can be set by a parameter. When a compressor is restarted, the valve restarts the regulation with the pre-positioning procedure described in the previous point.
- **Minimum and maximum opening values:** the minimum opening value in Off status and in ON status can be differentiated (by keypad, digital input or supervisor) while the maximum opening value is unique.
- **Maximum percentage variation:** the movement of the valve cannot exceed the maximum set percentage variation per second.
- **Maximum receiver pressure:** a maximum value can be set for the receiver pressure, above which an alarm is triggered and unit operation can be blocked. The block is optional and can be enabled by a parameter.

6.7.2 Summary of inputs, outputs and RPRV valve parameters

The following is a summary table of the inputs/outputs used and the parameters with indications of the related configuration screens. For details, refer to Chapter 6 and Appendix A.1.


Summary of inputs/outputs and RPRV valve parameters

	Mask	Description
Analog inputs	Bab66, Eia01	RPRV receiver pressure probe
Digital inputs	Baadf, Eia05	RPRV valve alarm
Analog outputs	Bad15, Eia07	RPRV valve output
Digital outputs	---	---
Parameters		
Settings	Eib18	Enable RPRV valve management
Regulation	Eib22	Regulation setpoint for the CO ₂ receiver pressure
		Proportional gain for the proportional + integral regulation of the RPRV valve
	Eib19	Integral time for the proportional + integral regulation of the RPRV valve
		Minimum opening of the RPRV valve with the unit OFF
		Minimum opening of the RPRV valve with the unit ON
Eib20	Opening of the RPRV valve at start-up during pre-positioning	
	Pre-positioning duration	
Eib21	Maximum opening of the RPRV valve	
	Maximum variation per second allowed for the RPRV valve output	
Safeties	Eib23	HPV valve safety position
	Eib24	Enable RPRV valve closure when all compressors on line 1 are off
		RPRV valve closure delay when all compressors on line 1 are off
	Eib25	Receiver high pressure threshold alarm
		Receiver high pressure differential alarm
Receiver high pressure alarm delay		
		Receiver high pressure alarm reset type
		Enable compressor shutoff with receiver high pressure alarm

Tab. 6.e


6.7.3 Updated HPV and CCMT valve list

From pRack300T SW version 4.1.0 in combination with EVDevo FW version 7.8/7.9 (or higher), all of the CCM and CCMT valves are managed and selectable individually. CCMT valves are also available as both HPV and RPRV valves. Up to pRack300T SW version 4.0.2 (or lower EVDevo FW), the choice of non-Carel CCMT valves was only possible for CCMT 2-4-6 models. For higher models, the "custom" valve setting was required, with the characteristic values entered manually.



6.8 Intercooler

pRack pR300T manages the gas cooler much the same way as pRack PR300 does for the condensers on a second condenser line, and activation is only available via the Wizard:



Only temperature control is available. The control variable is therefore the intercooler outlet temperature (measured by the probe, and not a converted pressure value).




Fig. 6.af


CAREL

If the intercooler temperature probe is faulty or not fitted, the compressor discharge temperature on the low temperature line (L2) can be used, where configured. If, on the other hand, the low temperature compressor discharge temperature probe (L2) is not fitted or has an alarm, the controller can use the value converted from the suction pressure on the medium temperature line (L1). The fans can also be managed with modulating operation by inverter; in this case, there is only one 0 to 10 V modulating output, while a different input can be used for each fan as regards the alarm signal. The function can be enabled and the related parameters set from main menu branch D.b. The intercooler can be configured only if the second suction line is available (therefore on the pLAN 1 boards, if the double suction line is managed using one board, or pLAN 2 boards if the double suction line is managed using two boards).

The following functions are not available for the second line of fans (intercooler)::

- floating condensing;
- set point compensation;
- chillbooster;
- heat recovery;
- backup pressure probes;
- split condenser.

The pressure prevent function will be managed as configured on screen Gbb07:



Selecting NO means the low temperature line discharge pressure (L2) needs to be configured for managing the PREVENT function, otherwise PREVENT will not be activated. If the field is set to YES, the PREVENT function will work using the medium temperature line suction pressure (L1).

6.9 Energy saving

pRack PR300T can activate energy saving functions by adjusting the suction and condensing pressure set points. The suction and condensing pressure set points can be applied with two different offsets, one for the closing period and one for the winter period, activated by:

- Digital input
- Time band
- Supervisor

In addition, the suction pressure set point can be modified from analogue input, applying a linearly variable offset based on the value read by a probe. As well as set point compensation from digital input, scheduler, supervisor or analogue input, two further energy saving functions are available, floating suction and condensing pressure set point. The functions can be enabled and the related parameters set in main menu branch C.a.d/C.b.d and D.a.d/D.b.d.

6.9.1 Set point compensation

Compensation from digital input, scheduler or supervisor is similar for suction and condensing pressure set points, consequently the following description applies to both. Two different offsets can be defined, which apply to:

- Closing periods, defined by the scheduler, activation of a digital input or supervisor
- Winter period, defined by the scheduler

The two offsets add to the set point defined by the user when the corresponding condition is active.

Example 1: closing offset 0.3 barg, winter offset 0.2 barg, suction pressure compensation from scheduler and from digital input activated. When the digital input is activated, for example with a day/night function, 0.3 barg is added to the operating set point, and when the winter period is in progress a further 0.2 barg is added. The operation can be schematised in the following figure:




Fig. 6.ag

Note: the same digital input is used for set point compensation on each line, so if suction and condensing pressure set point compensation is activated by digital input, both compensation functions are active at the same time.

If compensation from analogue input is enabled, a offset that is linearly variable to the value read by a dedicated probe can be applied to the suction pressure set point, as shown in the figure.




Fig. 6.ah

Compensation from analogue input applies to setpoint:

- suction
- gas cooler
- HPV minimum.

These compensations can be enabled separately.

6.9.2 Floating suction set point

For the suction line, the floating set point is managed by the supervisor. The suction pressure set point set by the user is changed by the supervisor in range between a settable minimum and maximum. The operation is illustrated in the following figure:




Fig. 6.ai

The set point is calculated by the supervisor and acquired by the pRack PR300T controller at set intervals, the maximum variation allowed for the set point in each sampling period can also be set; if the value acquired differs from the previous value by more than the maximum variation allowed, the variation is limited to the maximum value. If the supervisor is disconnected, after 10 minutes (fixed) the pRack PR300T controller starts decreasing the set point with variations equal to the maximum variation allowed each sampling period, until reaching the minimum set point allowed with floating suction pressure.

Note: if set point compensation from scheduler, digital input or supervisor is also active, the offset is added to the minimum and maximum limits for the floating set point.

6.9.3 Floating condensing set point

For the condenser line, the floating set point is based on the outside temperature. The floating condensing pressure set point is achieved by adding a constant programmable value to the outside temperature and limiting the resulting value between a settable minimum and maximum, as shown in the figure:




Fig. 6.aj

Note: if set point compensation from scheduler, digital input or supervisor is also active, the offset is added to the minimum and maximum limits for the floating set point.

6.10 Accessory functions

pRack PR300T can manage several accessory functions. Of these, the economizer and liquid injection have already been described in paragraph 6.3 on compressor operation, while the others are described below.

6.11 Oil management

pRack pR300T allows some additional functionalities for oil management, per individual compressor or per line:

- Individual compressor: oil cooling, oil injection.
- Line: common oil receiver

The functionalities can be enabled and the relative parameters can be set from main menu branch E.a.a/E.a.b.

6.11.1 Individual compressor oil management

Oil cooler

An oil cooler can be managed for the first 6 compressors in line 1, in order to keep the oil temperature under constant control. For each compressor, based on the value read by the oil temperature probe, an oil cooler digital output can be activated with a settable threshold and differential, as shown in the figure.




Fig. 6.ak

For each compressor, two alarms can also be managed for high or low oil temperature, setting the threshold, differential and delay.

Oil injection

An oil injection valve can be managed for each of the first 6 compressors in each line as shown schematically for three compressors in Fig. 6.ah. Valve activation is performed when the corresponding oil level digital input is active. The valve is opened in intermittent mode with settable opening and closing times, for a total time that is also settable. Once exceeded, if the digital input is still active a low oil alarm is generated. When the oil level digital input is not active, the valve is activated with opening and closing times which can be set at a different value, in order to allow the passage of a certain quantity of oil.

6.11.2 Oil management per line

A solenoid valve can be managed which connects the oil separator to the receiver based on the digital input reading of the oil level, which can be only minimum level or minimum and maximum level. Separator, receiver and valve are illustrated schematically in Fig. 5.a. If no oil level input is present, the solenoid valve can still be activated by connecting its operation to the status of the compressors. If only the minimum level is present, activation of the solenoid valve occurs intermittently for the entire time in which the minimum level is not active. The opening and closing times of the valve during activation can be set by a parameter. If the minimum level signal deactivates again, the valve remains deactivated for at least a minimum set closure time, as shown in the figure:




Fig. 6.al

Gestione olio comune da livello minimo




Fig. 6.am

If two levels are present, activation of the solenoid valve occurs when the maximum level is activated and remains activated in intermittent mode, with settable opening and closing times, for the entire time in which the minimum level is not active. If the minimum level signal is activated, the valve remains deactivated until the maximum level is reactivated again, as shown in the figure:




Fig. 6.an




Fig. 6.a0

If no oil level input is present, activation of the solenoid valve occurs intermittently for the entire time in which at least one compressor is active. The opening and closing times of the valve during activation can be set by a parameter. In any case, if the pressure difference between the oil receiver and suction is less than a settable threshold for at least a settable time, the solenoid can be forced in intermittent mode with settable times. It is also possible to set different delay times, to be applied during normal operation, or when the pressure difference exceeds the threshold, in order to ensure pressurization of the receiver.

Common oil management based on differential pressure

pR300T also offers the possibility to configure an oil receiver pressure probe, directly from the "Inputs/Outputs" menu:

Inputs/Outputs → Status → Analog Inputs → Screen Bab63

as well as a digital output for the oil reservoir, again at the same path:

Inputs/Outputs → Status → Digital Outputs → Screen Bac71

This will manage the solenoid valve placed between the oil separator and receiver. Once these two I/Os have been enabled, a pressure differential threshold can be set between the oil receiver pressure and the suction line pressure, from the "Other functions" menu:

Other functions → Oil → Settings → Screen Eaab14

If the difference between the two pressure values is less than the threshold, the pR300T will open the pressurising solenoid valve between the separator and receiver. This activation may be delayed by a settable value in seconds. The valve will be closed immediately once the correct difference between the two pressure values has been restored.

6.11.3 Summary of inputs, outputs and oil parameters

The following are summary tables of the inputs/outputs used and the parameters with indications of the related configuration screens. For details, refer to Appendix A.1.

Summary of inputs/outputs and oil cooling parameters

	Mask	Description
Analog inputs	Bab41, Eaaa05	Oil temperature probe compressor 1 line 1
	Bab42, Eaaa06	Oil temperature probe compressor 2 line 1
	Bab43, Eaaa07	Oil temperature probe compressor 3 line 1
	Bab44, Eaaa08	Oil temperature probe compressor 4 line 1
	Bab45, Eaaa09	Oil temperature probe compressor 5 line 1
	Bab46, Eaaa10	Oil temperature probe compressor 6 line 1
Digital inputs	---	---
Analog outputs	---	---
Digital outputs	Eaaa16	Oil cooling compressor 1 line 1
	Eaaa19	Oil cooling compressor 2 line 1
	Eaaa22	Oil cooling compressor 3 line 1
	Eaaa25	Oil cooling compressor 4 line 1
	Eaaa28	Oil cooling compressor 5 line 1
	Eaaa31	Oil cooling compressor 6 line 1
Parameters	Eaab15	Enable oil cooling compressors (line 1) Oil cooling functioning only when compressor functioning
	Eaab08	Oil temperature setpoint (line 1)
		Oil temperature differential (line 1)
		Fan startup time in case of oil probe error (line 1)
		Fan shutdown time in case of oil probe error (line 1)
	Eaab16	Oil cooler high temperature alarm threshold (line 1)
		Oil cooler high temperature alarm delay (line 1)
	Eaab20	Oil cooler low temperature alarm threshold (line 1)
		Oil cooler low temperature alarm delay (line 1)

Tab. 6.f

Summary of inputs/outputs and oil injection parameters

	Mask	Description	
Analog inputs	Bab62	Oil differential pressure probe 1 line 1	
	Bab66	Oil differential pressure probe 1 line 2	
Digital inputs	Eaaa57	Oil level compressor 1 line 1	
	Eaaa58	Oil level compressor 2 line 1	
	Eaaa59	Oil level compressor 3 line 1	
	Eaaa60	Oil level compressor 4 line 1	
	Eaaa61	Oil level compressor 5 line 1	
	Eaaa62	Oil level compressor 6 line 1	
	Eaba17	Oil level compressor 1 line 2	
	Eaba18	Oil level compressor 2 line 2	
	Eaba19	Oil level compressor 3 line 2	
	Eaba20	Oil level compressor 4 line 2	
	Eaba21	Oil level compressor 5 line 2	
	Eaba22	Oil level compressor 6 line 2	
	Analog outputs	---	---
	Digital outputs	Eaaa40	Oil level valve compressor 1 line 1
Eaaa41		Oil level valve compressor 2 line 1	
Eaaa42		Oil level valve compressor 3 line 1	
Eaaa43		Oil level valve compressor 4 line 1	
Eaaa44		Oil level valve compressor 5 line 1	
Eaaa45		Oil level valve compressor 6 line 1	
Eaba40		Oil level valve compressor 1 line 2	
Eaba41		Oil level valve compressor 2 line 2	
Eaba42		Oil level valve compressor 3 line 2	
Eaba43		Oil level valve compressor 4 line 2	
Eaba44	Oil level valve compressor 5 line 2		
Eaba45	Oil level valve compressor 6 line 2		
Parameters	Eaab10	Enable oil level management (line 1)	
		Number of compressor alarms associated with the oil level (line 1)	
		Oil level valve opening time (line 1)	
	Eaab11	Oil level valve closing time (line 1)	
		Delay for oil level valve pulsing at startup (line 1)	
Parameters	Eabb10	Maximum pulsing time for the oil level valve (line 1)	
		Enable oil level management (line 2)	
		Number of compressor alarms associated to the oil level (line 2)	
	Eabb11	Oil level valve opening time (line 2)	
		Oil level valve closing time (line 2)	
Parameters	Eabb11	Delay for oil level valve pulsing at startup (line 2)	
		Maximum pulsing time for the oil level valve (line 2)	

Tab. 6.g

Summary of inputs/outputs and oil receiver level parameters

	Mask	Description
Analog inputs	Bab63	Oil separator differential pressure probe line 1
	Bab65	Oil separator differential pressure probe line 2
Digital inputs	---	---
Analog outputs	---	---
Digital outputs	Bac71	Oil separator line 1
	Baceo	Oil separator line 2
Parameters	Eaab12	Type of oil level separator control: with minimum level only, with minimum and maximum level and with compressor status (line 1)
		Minimum separator valve closing time (line 1)
		Minimum oil level detection delay (line 1)
	Eaab13	Valve opening time during oil level reset (line 1)
		Valve closing time during oil level reset (line 1)
		Valve opening time with correct oil level (line 1)
		Valve closing time with correct oil level (line 1)
	Eaab15	Oil receiver differential pressure threshold (line 1)
		Oil receiver differential pressure (line 1)
		Oil receiver differential pressure delay (line 1)

Tab. 6.h

For integrated parallel compression (single compressor), when the parallel compressor is active, the reference for calculating the delta will no longer be more the medium temperature line compressor suction pressure, but rather the (liquid) receiver pressure, which coincides with the parallel compressor suction pressure. The changeover in reference from suction to receiver pressure is automatic, and does not need to be enabled. For parallel compression enabled via pLAN, the same I/Os (oil receiver pressure probe and solenoid valve digital output) and the same settings (delta and differential) can be used as seen above, or new I/Os and new parameters can be set on the parallel compressor board (always on screen Eaab25)

6.12 Subcooling

- pRack PR300T can control subcooling in two different ways:
- with the condensing temperature and the liquid temperature
 - with the liquid temperature only

In the first case, subcooling is calculated as the difference between the condensing temperature (obtained by converting the condensing pressure) and the liquid temperature measured after the exchanger.

The corresponding output is activated below a set threshold, with fixed differential.

differential.




Fig. 6.ap

In the second case, the output is active for liquid temperature values greater than a threshold, with fixed differential.




Fig. 6.aq

The subcooling function can be enabled and the related parameters set in main menu branch E.b.a/E.b.b.

Note: the subcooling function is active when at least one compressor is on.

6.13 Heat recovery




Fig. 6.ar

pRack pR300T manages up to two heat recovery functions at the same time. The related parameters can be set from the main menu, branch E.e.a.b.01.

Activation and control of each heat recovery function will reflect the percentage of heat demand calculated based on one of the following:

- digital input
- temperature probe
- external analogue signal

In the last two cases, a digital input can still be used to enable the function. Once active, heat recovery control can act on the HPV valve set point and on the effective Gas Cooler set point, in both simultaneous mode (acting on both at the same time) and in sequential mode, based on thresholds (first acting on the HPV and then the Gas Cooler, when exceeding a certain heat demand threshold):

- action on HPV set point (in barg/psig)
- action on GC set point °C/°F)

When acting on the HPV valve set point, the heat recovery function modifies the "Minimum HPV valve control set point" parameter (screen Eib28), whose default value is 40.0 barg and used as a lower limit for calculating the dynamic pressure set point for controlling the high pressure valve.

Increasing this minimum set point from its default value (40.0 barg) to a new minimum set point (e.g. 75.0 barg) causes the system to operate in transcritical conditions, even when the Gas Cooler outlet temperature is between T_{min} and T₂₃ (see the control parameters, screen Eib05); in this zone, defined as subcritical, the HPV set point would be calculated based on subcooling.

This minimum set point can be increased further (screen Eeab28) in proportion to the heat recovery demand, up to a settable maximum limit value (e.g. 85.0 barg).

If the HPV valve set point calculated based on the Gas Cooler temperature exceeds the minimum set point modified by the heat recovery function, the controller will use the calculated set point.




Fig. 6.as

When acting on the on the Gas Cooler set point, the Gas Cooler fan temperature set point can be increased gradually to the maximum limit.

This limit is equal to the maximum allowable set point (screen Dab06) when operating in simultaneous mode, or the value set on screen Eeab29 in sequential mode.

In simultaneous mode, the increase will start at the same time as the action on the HPV valve set point, while in sequential mode the increase will start after having exceeded a settable heat demand percentage limit threshold (Eeab29).

If the floating condensing function is active (branch D.a.d), this can be disabled when heat recovery is active (Eeab04), however if it is enabled while heat recovery is active, the Gas Cooler set point increase can be added directly to the outside temperature.

- CFloating condensing without heat recovery: $SP = Tout + \Delta T$ (screen Dad06)
- Floating condensing during heat recovery (acting on GC): $SP = Tout + OffsetGC$; where $OffsetGC > \Delta T$
- As the last step of the heat recovery function, the Gas Cooler can be bypassed when the following conditions are true:
 - bypass is enabled (screen Eeab)
 - the heat demand percentage exceeds a settable limit value (e.g. 90%)
 - the bypassed gas temperature cooler is lower than a certain settable limit value (e.g. 20°C)

When these conditions are true, the bypass valve will start modulating, with its set point being calculated based on the bypassed Gas Cooler temperature, until the Gas Cooler is completely bypassed when the temperature allows.

When heat recovery is deactivated, the HPV valve set point gradually returns to the calculated value, over a settable time. The same is also true for the condenser control set point.

6.14 Generic functions

pRack pR300T allows the use of free inputs/outputs and some internal variables for generic functions.

Attention: generic functions are available on the pRack pR300T boards with pLAN address from 1 to 4, or on all boards that manage a suction or condensing line, however only the parameters related to the functions managed by boards 1 and 2 are sent to the supervisor system.

The generic functions available for each board are:

- 5 stages
- 2 modulations
- 2 alarms
- 1 scheduler

Each function can be enabled/disabled by digital input or user interface.

The functionalities can be enabled and the relative parameters can be set from main menu branch E.f.

To be able to use the free inputs they must be configured as generic probes from A to E (analog inputs) and generic inputs from F to J (digital inputs), so a maximum of 5 analog and 5 digital inputs can be used. After having configured the generic probes, the variables associated with them can be used as regulation variables and the digital inputs as enabling variables. Besides the probes and generic inputs, internal variables in the pRack pR300T software can be used, which depend upon the configuration of the system. Some examples, for analog variables, are:

- Suction pressure
- Gas cooler pressure
- Saturated suction temperature
- Gas cooler temperature
- Suction temperature
- Discharge temperature
- % of compressors active
- % of fans active
- Superheating
- Subcooling
- Liquid temperature
- % requested compressors
- % requested fans

for digital variables:

- High suction pressure alarm
- Low suction pressure alarm
- High gas cooler pressure alarm
- Low gas cooler pressure alarm
- Sign of life
- Prevent active

A unit of measure and description can be associated to each generic function. The following shows the operation of 4 types of generic functions.

Stages

pRack pR300T can manage up to 5 stage functions, with either direct or reverse operation.

In both cases a setpoint and differential can be set and the operation of the related output is illustrated in the figure for both cases:




Fig. 6.at

If an enabling value is set, the output connected to the stage is active if the enabling is also active. For each stage, a high alarm and low alarm threshold can be enabled and they are absolute. For each alarm, the activation delay and priority can be set. See Chapter 8 for details on the alarms. An example of using the generic stage functions may be the activation of the fans on the room units based on the temperature.

Modulation

pRack pR300T can manage up to 2 modulation functions, with either direct or reverse operation. In both cases a setpoint and differential can be set and the operation of the related output is illustrated in the figure for the direct mode, where the cut-off function is also enabled:




Fig. 6.au

If an enabling value is set, the output connected to the stage is active if the enabling is also active. For each modulation, a high alarm and low alarm threshold can be enabled and they are absolute. For each alarm, the activation delay and priority can be set. See Chapter 8 for details on the alarms. For modulation, a minimum and maximum value can also be set for the output and the cut-off function can be enabled, which operates as shown in the previous figure.

Generic functions

PID control on modulating function

After having chosen the corresponding variables, the type of control can be selected.

The type of PID control can be either DIRECT or REVERSE.

- In direct mode, the analogue output signal will increase proportionally to an increase in the control variable value.
- In reverse mode, the analogue output signal will decrease proportionally to a decrease in the control variable value.

```
Gen.Fun.Modul. Efb06
Gen.modulat.n.1 PLB1
Regulation variable:
SUCTION.PRESS.<L1>
Regulation variable 2:
-----
Mode: DIRECT
Reg.type: PID
```

```
Gen.Fun.Modul. Efb06
Gen.modulat.n.1 PLB1
Regulation variable:
SUCTION.PRESS.<L1>
Regulation variable 2:
-----
Mode: DIRECT
Reg.type: PROP.
```

```
Gen.Fun.Modul. Efb06
Gen.modulat.n.1 PLB1
Regulation variable:
SUCTION.PRESS.<L1>
Regulation variable 2:
-----
Mode: REVERSE
Reg.type: PID
```

The type of PID control is completed by also setting the integral time and derivative time parameters.

```
Gen.Fun.Modul. Efb06
Gen.modulat.n.1 PLB1
Setpoint: 35.0barg
Differential: 5.0barg
Integral time: 120s
Derivative time: 30s
```

- **Proportional gain:**
This indicates the percentage by which the output increases/decreases to modify the control variable by one unit. The proportional gain depends on the differential and is calculated as follows:
 $kp = 100.0 / (2 * \text{differential})$
 $P = 100.0 * \text{Reg_Var} / (2 * \text{diff}) - 100.0 * ((\text{Setpoint} - \text{Diff}) / (2 * \text{Diff}))$

- **Integral time:**
The integral action has the task of returning the controlled variable to the set point value if this remains constant (the proportional action alone may cause the controlled variable to remain at a value other than the set point).
The integral action works in addition to proportional action.

E.g.: set point = 25.0°C, reg_var=28.0°C (error= 28.0-25.0 = 3.0), kp = 5%/°C, Ti = 60s.

output (t0 @0s) = kp*error= 5*3.0= 15.0%
output (t1 @30s) = kp*error + kp*error*(t1/Ti)= 15%+15%*30/60= 27.5%
output (t2 @60s) = kp*error + kp*error*(t2/Ti)= 15%+15%*60/60= 30%
output (t3 @120s) = kp*error + kp*error*(t3/Ti)= 15%+15%*120/60= 45.0%

[DEFAULT = 0s = disabled]

- **Derivative time:**
The derivative time setting introduces an action that is proportional to the rate of change of the error before it becomes significant (proportional action) or persists for a certain period of time (integral action). The derivative action anticipates the trend in the error.

[DEFAULT = 0s = disabled]

Control with two variables

For both the thermostat functions and the modulating functions, the possibility has been introduced to activate a digital output or modulate an analogue output as the result of a mathematical operation on two variables.

Example of control with one variable

```
Gen.Fun.Modul. Efb06
Gen.modulat.n.1 PLB1
Regulation variable:
SUCTION.PRESS.<L1>
Regulation variable 2:
-----
Mode: DIRECT
Reg.type: PROP.
```

CAREL

Example of control with two variables

```
Gen.Fun.Modul. Efb06
Gen.modulat.n.1 PLB1
Regulation variable:
GAS COOL.PRESS.(L1)
Regulation variable 2:
SUCTION.PRESS.(L1)
Mode: DIRECT
Reg.type: PID
```

The second variable can only be selected after having selected the main variable, otherwise control variable 2 is automatically reset.

(*) The software verifies consistency between the type of selected variables. If the selected control variable 2 is a different type (for example, variable 1 is a temperature value and variable 2 is pressure), the software automatically resets the second variable field.

The following operations are allowed between variables:

- DIFFERENCE = Var1 - Var2 (default)
- AVERAGE = (Var1 + Var2)/2
- SUM = Var1 + Var2
- RATIO = Var1 / Var2

```
Gen.Fun.Modul. Efb07
Gen.modulat.n.1 PLB1
Function: DELTA
Enable:
-----
Description: SKIP
```

Alarms

pRack pR300T can manage up to 2 alarm functions, for which a digital variable to be monitored, activation delay, priority and any description can be set. A digital output can be associated to each general alarm function for the activation of external devices when the alarm is triggered. One example of use of the generic alarm functions is the detection of gas leaks.

Scheduler

pRack pR300T can manage a generic scheduler which activates a digital output in certain time bands. Up to 4 daily time bands can be set for each day of the week. Operation of the generic scheduler can also be linked to the common scheduler and the output activated based on:

- summer/winter
- up to 5 closing periods
- up to 10 special days

See Paragraph 6.7.2 in the pRack PR300T manual code +0300011EN for details on the time bands.

6.14.1 ChillBooster

pRack PR300T can control the Carel ChillBooster, device used for evaporative cooling of the air that flows through the condenser.

ChillBooster can be enabled and the related parameters set in main menu branch E.g.

ChillBooster is activated when two conditions exist:

- the outside temperature exceeds a set threshold
- the fan control request is at the maximum for at least a settable number of minutes

The maximum request time starts counting again whenever the request decreases, therefore the request must remain at the maximum for at least the set time. Activation ends when the request falls below a set threshold.

pRack PR300T can manage an alarm digital input from ChillBooster, the effect of which is to deactivate the device.

As the number of operating hours of ChillBooster is critical as regards formation of scale on the condenser, pRack PR300T can manage the operating hour threshold, which should be set to 200 hours.

Hygiene procedure

To avoid water stagnation in the pipes, a hygiene procedure can be enabled that activates ChillBooster every day for a set time, if the outside temperature is greater than a threshold.



Note: if the outside temperature probe is not configured or is configured but is not working, ChillBooster operates based solely on the control request, and the hygiene procedure can still be activated.

The only difference between probe not configured and probe not working concerns the ChillBooster operating without temperature probe alarm, which is only generated when the probe is configured but not working.

ChillBooster as the first stage in high pressure prevention

ChillBooster can be used to prevent high condensing pressure. The parameters relating to this function can be set in branch G.b.a/G.b.b in the main menu, after having enabled the ChillBooster function. For details on the prevent function see paragraph 8.3.3. Operation of ChillBooster as the first stage in high pressure prevention is similar to the heat recovery function described in paragraph 6.6.3. The function must be enabled and an offset must be set in relation to the prevent.

6.15 Double line synchronization (DSS)

pRack pR300T can manage some synchronization functions between the two lines:

- Inhibition of contemporary compressor starts
- Forcing the medium temperature line if the low temperature line is activated
- Turning off the low temperature line if the medium temperature line is in a serious alarm condition

The three DSS functions can be enabled independently



Attention: in the pRack pR300T software, it is assumed that the medium temperature line is line L1 while the low temperature line is L2.

DSS can be enabled and the relative parameters can be set from main menu branch E.f.

Inhibition of the contemporary starts

The inhibition of contemporary starts of the compressor can be useful for all system configurations with two separate lines and in cascading system configurations. The function that prevents contemporary starts can be enabled and a delay time can be set for compressor starts belonging to different lines.

Forcing the medium temperature line

Forcing the medium temperature line can be useful for cascading system configuration and, once enabled, can force the startup at minimum power of at least one compressor in the medium temperature L1 line if at least one compressor in the low temperature L2 line is on.

This means that before turning on the low temperature line, the DSS forces at least one of the compressors in the medium temperature L1 line to turn on at minimum power. The low temperature L2 line thus has greater priority in relation to the request coming from the regulation for the medium temperature L1 line.

Turning off the low temperature line

Turning off the low temperature line is forced by the DSS if a serious alarm occurs which turns off all of the alarms in the medium temperature line or, in general, if the medium temperature line is OFF.

Enable pump-down on medium temperature line

During normal compressor rack operation, when at least one compressor on the low temperature line is running, the medium temperature compressor control will enable pump-down. If there is demand, the minimum capacity step will be guaranteed, only if the medium temperature line suction pressure is below a set threshold.



Note: in the event of failure of the pLAN network, the DSS is disabled

6.16 EEVS: Electronic Expansion Valve Synchronization

The new software for managing transcritical systems features the possibility to manage the 2 stepper valves for high pressure and flash gas control directly from the pRack controller. The built-in driver on PRK30TD*** controllers or the external driver (EVD) is controlled via fieldbus. Direct communication between controller and driver is used to synchronise compressor rack operation and electronic expansion valve control.

Communication is managed inside the controller (on PRK30TD*** codes) or via RS485 serial for external drivers. One single interface (pRack) can thus be used to monitor / set the main parameters for the EVDEVO and view them via the supervisor (Modbus communication). The FIELDBUS DRIVER offers the possibility to use 4 additional analogue inputs (S1, S2, S3 and S4) directly from pRack.

Where:

- S1 Probe 1 (pressure) or external 4 to 20 mA signal
- S2 Probe 2 (temperature) or external 0 to 10 V signal (*)
- S3 Probe 3 (pressure)
- S4 Probe 4 (temperature)

6.16.1 HPV and RPRV valve connection

The HPV and RPRV valves can be connected:

- directly, controlling the valves using a 0-10 V output on pRack pR300T




Fig. 6.av

(*): If one of the two valves is controlled by the driver Carel, while the other, just is controlled by a signal 0...10V, remember to disable the last one from the driver with mask lb99 during Wizard operation or mask Eic01 if Wizard is completed.

- via an EVD EVO driver configured as 0 to 10 V positioner to control Carel stepper valves (pressure less than 45 barg) or third party valves (fig. 2.f)




Fig. 6.aw

- via a EVD EVO external driver (fig. 2.g) or integrated in PRK30TD*** models, in both cases using fieldbus serial.




Fig. 6.ax

6.16.2 Unit of measure

pRack PR300T can manage two units of measure, the international system and Imperial.

Note: the temperature and pressure units of measure can be changed from °C, barg to °F, psig only during start-up; mixed configurations are not allowed, for example °F and barg.

6.16.3 Sign of life

pRack PR300T can manage a digital output acting as a sign of life, activated when pRack PR300T is powered up. This output remains active while the controller is working correctly and highlights any hardware faults. The Signal can be configured in main menu branch B.a.c.

6.16.4 Liquid non-return

pRack PR300T can manage a digital output with the meaning of liquid non-return. This normally active output is deactivated when all the compressors are off and no compressor can be started due to alarms or time settings, despite the control request, or when the unit is OFF. As soon as at least one compressor is enabled to start, the output is deactivated, allowing management of a liquid non-return valve. The function can be configured in main menu branch C.a.g/C.b.g.

6.16.5 Parallel compressor

pRack pR300T can enable a line of compressors in parallel to the medium temperature suction line upstream of the RPRV valve using a dedicated board, and starting from version 3.3.0 this board can be enabled via pLAN. If managing a single parallel compressor (again starting from version 3.3.0), the main control board can be used, i.e. without requiring a dedicated board.







Fig. 6.ay

This function is configured in branch COMPRESSORS → c.Parallel compress.




If the parallel compressor line is managed using an additional board (via pLAN or connected via DI/DO):



in both cases, the board follows the configuration and relative restrictions described in the paragraphs on control 6.3 and compressors 6.4.

Consequently, the first compressor in the parallel line can be controlled by inverter. It is recommended to use a suction pressure set point value for the parallel line that is the same as the receiver pressure set point for proportional control, while the set point should be slightly lower than

the latter for neutral zone control (1 barg difference between the two set points should be sufficient). If on the other hand there is a single parallel compressor managed directly by the main board:



Compressor control is proportional with integration error, P+I, and the various settings, relating to:

- times;
 - control;
 - inverter modulation;
 - alarms;
 - analogue output configuration;
- can all be found inside the same menu: C.Compressors → c.Parallel compression → Ccaxy (see the parameter table)

The main variables used to manage activation and control of the parallel compressor are:

- gas cooler outlet temperature;
- RPRV valve opening percentage;
- receiver pressure set point.

The parallel compressor is activated when the following conditions are true:

- gas cooler outlet temperature above a settable threshold;
- RPRV valve opening percentage above a settable threshold.

At the same time as the parallel compressor is activated, the receiver pressure set point will be increased by a settable offset in a settable time.




Fig. 6.az

Increasing the receiver set point results in the flash gas valve (RPRV) closing. The parallel compressor is not affected by a decrease in the opening of the RPRV valve, however remains active until parallel compressor control reaches the set point (depending on how the controller is configured)




Fig. 6.ba

If, on the other hand, the Gas Cooler outlet temperature falls below the activation threshold, the card that manages the parallel compressor no longer receives the enabling signal and thus switches off the parallel compressor:




Fig. 6.bb

Oil differential management with parallel compression
 The parallel compression function, either integrated (single compressor) or via pLAN, can also be included in the common oil management by differential pressure (also see paragraph 6.10.2), and is enabled on screen Eaab25:

```

L1-Oil Set. Eaab25
Oil Press. management
Enable oil Press.diff.
management: YES
    
```

Differential oil pressure control by dedicated pressure probe, screen Eaa1a:

```

L1-HI Status Eaa1a
Oil reserve Pressure
PLB1 U7 4-20mA
-11.2barg
Upper value: 44.8barg
Lower value: 0.0barg
Calibration: 0.0barg
    
```

This manages the opening of the solenoid valve, screen Bac71.

```

L1-DO Status Bac71
Oil reserve
PLB 01 DO 14
Status OPEN
Logic NO
Function Not active
    
```

This digital output is dedicated to the common solenoid valve installed between the oil separator and oil receiver.
 When the oil reservoir pressure approaches the threshold (delta) set on screen Eaab14:

```

L1-Oil Set. Eaab14
Oil receiver settings
Threshold: 1.0barg
Differential: 0.5barg
Delay: 30s
    
```

This will trigger the opening of the valve so as to pressurise the oil reservoir and ensure correct oil flow to the compressors.
 The delta is calculated based on the difference between the medium temperature compressor suction pressure and the oil receiver pressure.
 The status of the function can be checked on screen Aa61:

```

Main info Aa61
L1-Suction
Reg.Press.: -9.9barg
Oil Press.: -11.2barg
Delta: -1.3barg
Act.setp.: 1.0barg
Diff.: 0.5barg
Status: NO
    
```

For integrated parallel compression (single compressor), when the parallel compressor is active, the reference for calculating the delta will no longer be more the medium temperature line compressor suction pressure, but rather the (liquid) receiver pressure, which coincides with the parallel compressor suction pressure
 The changeover in reference from suction to receiver pressure is automatic, and does not need to be enabled.

For parallel compression enabled via pLAN, the same I/Os (oil receiver pressure probe and solenoid valve digital output) and the same settings (delta and differential) can be used as seen above, or new I/Os and new parameters can be set on the parallel compressor board (always on screen Eaab25)

6.16.6 Set point compensation on parallel compressor

Background

In a transcritical CO2 booster system, the parallel compressor allows system COP to be increased compared to when only using the flash gas valve. Specific tests have shown that it is possible to improve COP by increasing the liquid receiver set point (parallel compressor suction set point) in proportion to the increase in the gas cooler outlet temperature. The graph below shows the increase in COP considering the effects of the increase in receiver pressure (t0 - parallel compressor saturated suction temperature) and the gas cooler outlet temperature/pressure.




Fig. 6.bc

Description of the algorithm

Parallel compressor set point optimisation is designed to make the parallel compressor work with the highest possible suction pressure in proportion to the gas cooler outlet temperature.

NB: this function is only available for managing the internal parallel compressor. In order to keep the system stable, the parallel compressor set point is periodically updated, with times and incremental pressure values that can be modified by parameter (default 30 sec, pressure 0.1 bar).

```

Parallel compr. Cca17
Optimized medium Press
setpoint calc.: YES
Min.GC temp.: 20.0°C
Max.GC temp.: 30.0°C
Max.setpoint: 45.0barg
    
```

From the graph it can be seen that the optimal set point is calculated defined between two gas cooler temperatures, and the maximum calculation pressure is limited to a settable value.




Fig. 6.bd

CAREL

In order to avoid premature shutdown of the parallel compressor, the minimum operating frequency inside which the set point compensation function applies can also be defined (default 40 Hz).

```
Parallel compr. Cca19
Max delta: 0.1bar9
Update every: 30s
Min.frequency to allow
setp.to change: 40Hz
```

The graph shows the behaviour of the compensation function according to inverter frequency.




Fig. 6.be

6.17 Settings

6.17.1 Clock

pRack PR300T features an internal clock with backup battery that keeps the time and date for all related functions (see Chapter 2 for details relating to the hardware). The date on pRack PR300T can be set as follows:

- day, month, year (dd/mm/yy)
- month, day, year (mm/dd/yy)
- year, month, day (yy/mm/dd)

The current date and time can be set, the day of the week corresponding to set date displayed, plus changeover to daylight saving can be enabled by setting the changeover date and the deviation.

The related parameters can be set during start-up or in main menu branch Fa.

Note: the date and time are managed on pRack boards with addresses 1 and 2; on power-up and whenever the pLAN network is reconnected, the software on pRack synchronises the settings on board 2, sending the date and time set on board 1.

If the clock card is not operating, an alarm is generated and the functions relating to the time bands described in the following paragraph are not available.

6.17.2 Time bands

pRack PR300T allows the operating seasons, the closing periods and weekends to only be set once, and consequently these are common to all the system functions. As well as these settings, each function can be associated with a weekly scheduler, setting up to 4 different daily activation bands for each day of the week. For each time band, the start and end time can be set and settings made can be copied to the others days of the week.

The priority of the schedulers, from lowest to highest, is:

- weekly scheduler
- closing periods
- special days

For example, if the weekly scheduler requires activation of a function, yet a closing period is in progress, and requires deactivation of the same function, then the function is deactivated.

The following functions allow the setting of time bands:

- Split-condenser: the function is active only based on the operating seasons, and consequently special days, closing periods and daily time bands are ignored.
- Silencer: the function is only active with daily time bands, there is no link to operating seasons, special days and closing periods
- Heat recovery: the function is active with daily time bands, special days and closing periods, no link to operating seasons. The link to the general scheduler can be disabled, considering the time bands only.
- Set point compensation: active with operating seasons, special days, closing periods and daily time bands (two different offsets).
- Generic functions: the generic scheduling function is active with the operating seasons, special days, closing periods and daily time bands. Operation of the generic functions can be separated from the generic scheduler, considering the daily time bands only.

For details on the functions that use time bands, see the corresponding paragraphs.

6.18 Managing the default values

pRack PR300T can manage two different sets of default values:

- user defaults
- Carel defaults

The two functions can be activated in main menu branch I.d.

Important: after having reset the default values, the pRack PR300T board need to be switched off and on again.

6.18.1 Saving and resetting the user default values

pRack PR300T can save the exact configuration set by the user inside the instrument, allowing it to be recalled at any time.

All the set values are saved, therefore loading user defaults restores the exact same conditions that the pRack PR300T controller was in when the data were saved.

Note: only one user default configuration can be saved, therefore when the data is next saved, this overwrites the previous data.

Important:

- the Carel default reset procedure totally deletes the pRack PR300T permanent memory, and consequently is an irreversible operation;
- the user values cannot be reset after updating the software on the pRack PR300T (see Chapter 10).

6.18.2 Resetting the Carel default values

The Carel default values are shown in the Parameters table.

The values pre-set by Carel can be installed at any time, restoring the pRack PR300T default settings, and requiring the startup procedure described in Chapter 4 to be repeated.

Important: the Carel default reset procedure totally deletes the pRack PR300T permanent memory, and consequently is an irreversible operation; nonetheless, the user settings can still be restored if these have already been saved. Given that pRack PR300T, following the installation of the Carel default values requires the startup procedure to be repeated, select the first pre-configuration and then restore the user defaults.

Note: to complete a new configuration procedure (refer to Chapter 4), first restore the Carel default values.

6.19 Water chiller function

Introduction

The pR300T is designed to manage transcritical CO2 systems. However, the growing interest in the market towards natural gas solutions also requires the implementation of new operating logic for other applications. The following paragraphs describe the main functions implemented on the pR300T in order to manage a chiller application.




Fig. 6.bf

6.19.1 Transcritical CO2 water chiller

With the "water chiller" function, a pR300T can be used for a chiller application to control the compressors using the heat exchanger water inlet and outlet temperature probes. The function can be enabled during the wizard or subsequently in the compressor menu

```
COMP.Regul. Cab22
Enable Chill.reg: YES
Probe reg.type:
    Temperature
Reg.prb.type.:
    WATER OUTLET T
```

Inlet and outlet temperature probes

In order for the function to work, new temperature probes need to be added to the system. After enabling the "water chiller" function, the following probes will be made available:

- Water inlet temperature probe
- Water outlet temperature probe
- Frost temperature probe

```
AI Status Bab79
Chiller water out.t.
PLB1 U5 NTC
0.0°C
Calibration: 0.0°C
```

```
AI Status Bab59
Chiller water in.t.
PLB1 U5 NTC
0.0°C
Calibration: 0.0°C
```

```
AI Status Bab97
Chiller anti-freeze t.
PLB1 U6 NTC
0.0°C
Calibration: 0.0°C
```

It is also possible to set a high and low temperature alarm for these probes under the Safety - alarms menu (GCA09 and GCA10).

```
Alarms GCA09
Warning high/low w.out
temperature: ABSOLUTE
High t.thresh.: 30.0°C
High t.diff.: 2.0°C
Low t.thresh.: 5.0°C
Low t.diff.: 2.0°C
Delay: 120s
```

Operating logic

Many of the available software applications offer the following operating modes:

- At start-up, control is based on the water inlet temperature probe, using the three PID variables.
- Control then gradually begins to switch to the water outlet probe reading, while continuing to use the three PID variables.

The water chiller function on pRack allows the choice of the following types of control:

- Control based on heat exchanger water outlet probe
- Control based on heat exchanger water inlet probe
- Optimised control, using the inlet probe at start-up + outlet probe after a certain time.

With control based on the water inlet or outlet probe, the following can be set in the software:

- Control set point (default: 7°C / 45°F)
- KP (default 10%/°C)
- Ti (default 60sec)

```
COMP.Regul. Cab23
Chiller regulation
Setpoint: 26.0°C
KP: 10%/°C
Integral time: 60s
```

For optimised control, in addition to the previous parameters, the following can be set:

- Control set point during the start-up phase (default: 7°C / 45°F)
- KP during the start-up phase (default 10%/°C)
- Ti during the start-up phase (default 60 sec.)
- Duration of the start-up phase (default 180 sec.)

```
COMP.Regul. Cab24
Chiller reg.start-up
Setpoint: 12.0°C
KP: 10%/°C
Integral time: 60s
Start-up duration: 180s
```

Probe fault and auto switch backup sensors

In order to keep the system operating at all times, in the event of fault on the main control probe, the system can switch to the other temperature probe (water inlet temperature probe if the outlet probe fails and vice-versa). To compensate for the different temperatures between the two probes and keep the same control set point, an offset can be added to or subtracted from the set point.

```
Manz.Comp. Cab17
Sonda backup chiller
Passa a sonda aspiraz.
se tutte le sonde sono
rotte: SI
Offset : 0.0°C
```

In the event of a fault on both temperature probes, control can switch to the suction pressure probe (temperature calculated from the suction pressure probe reading).

CAREL

In this case too, an offset can be added to or subtracted from the set point.

```
Comp.Advan. Ca917
Chiller Probe backup
Auto switch to suct.
Probe if all chiller
Probes are broken: YES
Offset : 0.0°C
```

If both "auto switch sensor" functions are disabled, in the event of an auxiliary probe alarm, the system will stop the compressors and the probe fault or not present alarm will be shown.

6.19.2 Expansion valve control

Superheat at the evaporator can be controlled by thermostatic expansion valves (TXV) or by electronic expansion valves (EXV).

Stand-alone EXV control

When using an electronic expansion valve, superheat modulation can be managed using an EVD driver in stand-alone mode. In this case, a pressure transducer and an additional temperature probe are required for calculating superheat. Superheat and valve control are not directly managed by the pRack300T controller

EVD external enabling signal

To activate control via the EVD driver, a digital output contact needs to be configured. This output contact is always active if at least one compressor is running, except during pump-down mode. The diagram below shows how the digital output contact behaves during pump-down mode.




Fig. 6.bg

6.19.3 Frost protection

To avoid damage to the evaporator due to the formation of ice, a frost protection function has been added, based on the reading of a dedicated temperature probe. The frost protection probe is usually installed in the coldest measurable point of the evaporator. This point is usually identified near the evaporator water outlet (or inside the evaporator itself, using a dedicated socket on some models). Once the probe has been configured, this option allows the compressors to be stopped immediately, ignoring their timings, when reaching a certain set temperature threshold (the activation differential and delay can also be set). It is also possible to choose whether the compressors continue to operate in the event of a frost protection probe failure, always considering the risk this entails.

```
Alarms Gc011
Anti-Freeze alarm
Max.delay: 60s
Alarm thr: 3.0°C
Differential: 2.0°C
Continue working if
anti-freeze probe is
broken: NO
```

There is also a frost protection prevention function available (configurable under "Safety - Prevent").

This function, if enabled (Gba01), uses a set minimum temperature threshold (plus differential) below which, after an evaluation time (Gba07), the unit gradually reduces capacity to the minimum available step so as to increase the temperature read by the frost protection probe. If the read temperature exceeds the prevent set + differential, the system returns to normal operation.

If the prevent function is activated a certain number of times in a defined period (both can be set), the compressors are stopped.

```
Prevent Gba01
High Pressure
Prevent enable: NO
High Temperature
Prevent enable: NO
Chiller anti-freeze
Prevent enable: YES
```

```
2-Prevent Gbb07
Booster system
Use L1 suct.probe for
condensing line 2:
(Prevent disabled:
disch.press.needed)
```

```
Prevent Gba05
Prevent max.number
evaluation time: 60min
Reset counter of
prevent number: NO
```

6.19.4 Pump management

The water chiller function can directly manage an ON/OFF pump for water flow inside the evaporator. The pump can be managed using two types of operating logic:

1. Always on: the pump is started when the unit is switched on and is switched off (settable deactivation delay) when the unit is switched off
2. With compressor request: the pump is activated at a certain % of compressor request (settable) and is deactivated (settable deactivation delay) when all the compressors are switched off.

In the latter case, while the compressors are off, the pump is cyclically activated at regular intervals (settable on and off times). In the I/O menu, a DO is available to manage the pump, plus a DI to manage an optional flow switch.

```
DO Status Bacet
Chiller water PUMP
PLB 01 DO 03
Status OPEN
Logic NO
Function Not active
```

```
DI Status Baadt
Chill.water flowswitch
PLB 1 FCU ID07
Status Close
Logic NO
Function Not active
```

Flow switch

The water chiller function on pRack300T can manage an optional mechanical flow switch to check the flow of water to the evaporator. With the pump running, if there is no flow, after an evaluation time the pump and compressors are stopped in order to avoid damage. When the pump is started, the flow switch check is ignored for a settable time, so as to avoid any instability of flow inside the heat exchanger during start-up from causing false flow alarms. pRack300T features a functional check on the flow switch; every time the pump is stopped, the system expects the flow switch contact to change status. If this does not happen, a flow warning will be signalled with the pump off.

Pump operation based on compressor request




Fig. 6.bh

6.19.5 Alarms

The water chiller system can identify several alarm conditions. The following alarms are managed, in addition to those described in the previous chapters

Delta temperature alarm

This function, which can be enabled under the Safety - alarm menu, checks the differential temperature between the water inlet and the chiller, and if this exceeds a certain threshold, a warning is generated. If the value is higher than design conditions, it means there is low water flow through the evaporator. A differential and an evaluation time can also be set for this alarm.

```
Alarms Gca08
Delay Flow Switch
start-up alarm: 60s
running alarm: 20s
Delta t.win-wout: EN
Threshold: 10.0°C
Delta t.delay: 60s
Differential: 2.0°C
```

High/low probe temperature alarm

For each temperature probe, a high temperature and low temperature threshold can be set, with corresponding differential. In both cases, an evaluation time can be set before verifying the alarm.

```
Alarms Gca09
Warning high/low w.out
temperature: ABSOLUTE
High t.thresh.: 30.0°C
High t.diff.: 2.0°C
Low t.thresh.: 5.0°C
Low t.diff.: 2.0°C
Delay: 120s
```

```
Alarms Gca10
Warning high/low w.in
temperature: ABSOLUTE
High t.thresh.: 30.0°C
High t.diff.: 2.0°C
Low t.thresh.: 5.0°C
Low t.diff.: 2.0°C
Delay: 120s
```

6.20 Maximum capacity limit

This function is used to limit the maximum capacity delivered to a certain percentage, so as to reduce compressor rack power consumption. The option is available for both suction lines and can be activated under the compressor energy saving menu. The function is activated by configuring a digital input; the maximum operating percentage can be:

- A fixed percentage value, set directly on the activation screen

```
Comp.Energy Cad13
Freeze maximum power
Enable by: Fixed thr.
Threshold: 100.0%
```

- A variable percentage in proportion to a set 0-10V analogue signal. If the analogue input is not configured, the system shows an alarm.

```
Comp.Energy Cad13
Freeze maximum power
Enable by: Analog input
```

```
Gas C.1/U Caaa8
Percentage Max Power
PLB1 U5 0-10V
0.0%
Upper value: 100.0%
Lower value: 0.0%
Calibration: 0.0%
```

- A percentage value that can be set via the supervisory system.

```
Comp.Energy Cad13
Freeze maximum power
Enable by: Supervision
```

For fixed or variable values based on an analogue signal, the function is always activated via a set digital input.

```
Comp.1/U Caaa7
Enable max power
PLB 1 200 1007
Status Close
Logic NO
Function Not active
```

6.21 Valve backup function

On pRack300T, the backup function can be used to manage a second CO₂ HPV and/or RPRV valve in the event of a fault on the primary valve. The system also allows the backup valves to be used to supplement the primary valves if these are unable to keep the pressure at the set point.

pRack configuration for backup/supplementary function




Fig. 6.bi

The pair of backup valves must be controlled by a second EVD driver, as on pRack these can only be managed via a 0-10 V signal.

The primary valves, on the other hand, can be managed by drivers both with Fieldbus connection and with 0-10 V signal. A mixed configuration is also allowed, with one valve connected to a driver via Fieldbus and a second valve managed with a 0-10 V signal.

The hardware configuration for the backup and supplementary functions is the same, and at a software level the two functions can be enabled and disabled independently.

6.21.1 Backup function settings

The HPV or RPRV valve backup function can be activated when:

- Primary HPV/RPRV valve not working (primary EVD alarm)
- Digital input for manual activation is closed

In both cases, the system closes the faulty valve and activates the related digital + analogue outputs to manage the EVD driver used for the backup valve.

```

Trans.I/O Eia19
HPV backup consent
PLB 01 DO --

Status OPEN
Logic NO

Function Not active
    
```

```

Trans.I/O Eia21
HPV valve backup
PLB 01 AO --

Status 0.0%
    
```

If the primary valves are managed via Fieldbus, the corresponding backup valve can be activated with the following alarms:

- Valve motor alarm only
- Driver disconnected alarm only
- All EVD alarms

```

EVD Settings Eic22
Enable back.HPV: YES
Enable back.RPRV: YES
Switch HPV by DI: YES
Switch RPRV by DI: YES
Switch HPR / RPRV by:
Function disabled
    
```

If the primary valves are managed by a 0-10 V signal, the corresponding backup valve must be activated via a dedicated digital input on pRack300T

```

EVD Settings Eic22
Enable back.HPV: NO
Enable back.RPRV: NO
Switch HPV by DI: NO
Switch RPRV by DI: NO
    
```

The same digital input can be used to activate the backup valves in manual mode.

```

Trans.I/O Eia17
Enable backup HPV
PLB 01 --

Status Close
Logic NO

Function Not active
    
```

Primary driver forced closing

Failure of the primary driver may not guarantee closure of the corresponding valve and consequently a malfunction of the backup valve. To avoid this problem, the system provides for the configuration (optional) of a digital output that can be used to isolate the primary valve from the fluid circuit.




Fig. 6.bj

This output is deactivated when the backup valve is activated.

```

Trans.I/O Eia23
HPV force closing
PLB 01 DO --

Status OPEN
Logic NO

Function Not active
    
```

6.21.2 Supplementary function settings

The supplementary function uses the same backup valves to assist the primary valves if these are unable to maintain the set pressure (e.g. primary valve does not open completely).

The supplementary function can be enabled independently for the HPV/RPRV valve and can also be either exclusive or in addition to the backup function.




Fig. 6.bk

As shown in the graph, the supplementary function will be activated when:

- The pressure does not reach a certain set point
- The primary valve opening percentage does not reach a certain set point
- Both of these conditions described above are active for a certain period

In addition to the pressure and the opening of the primary valve for activating the supplementary valve, it is also possible to limit the opening of the latter.

The supplementary valve is deactivated when the opening of the primary valve subsequently falls below a certain value for a certain time; both parameters can be set freely.

```

EEUS Settings E1c24
en.RPRV integr: NO
Max % normal RPRV: 100%
Rec.thr.pres: 50.0barg
Delay on: 5s
Max % back.RPRV: 30.0%
Delay off: 20s
Min % normal RPRV: 75%
    
```

As the supplementary function is considered an emergency situation, after a certain number of activations within a certain period, an alarm is generated.

```

EEUS Settings E1c25
Integration counter
HPV/RPRV maximum
integration activ: 10
Maximum evaluation
time HPV / RPRV: 60min
    
```

For these functions, the alarms can be reset and the primary valves restored only by manually accessing a specific menu screen

```

EEUS Settings E1c26
Restore condition:
-HPV: NO
-RPRV: NO
    
```

6.22 Double line inverter management

Starting from software version 4.2.0, pRack can manage two inverter-driven compressors on each line.

The number of compressors managed by the inverter can be selected both during the wizard and after the wizard has been completed.

The configuration of the two inverters is the same in both case; the operating frequency range, operating times, nominal frequency and power, up and down ramps can all be configured independently.

Operation

When the request exceeds the minimum capacity of the inverter compressor, the first available inverter is switched on.

If the first inverter reaches 100%, the second is activated and the request is shared between the two compressors, which will now operate at the same frequency.

If both inverters reach 100%, the system starts the fixed compressors, in the usual mode.

If the request increases quickly, the controller can activate the second inverter compressor without waiting for the first to reach 100% capacity. If the request decreases, the controller switches off, in sequence, first the fixed-speed compressors (if present), then decreases the speed of both inverters to the minimum frequency, switches off one inverter compressor and then adjusts the speed of the first inverter based on the request.






Fig. 6.bl

7. PARAMETERS AND ALARMS TABLE


7.1 Parameter table

 "Mask index": indicates the unique address of each screen and therefore the path for reaching the parameters in that screen. For example, to reach the parameters related to the suction pressure probe with mask index Bab01, proceed as follows:

 Main Menü **I/O** E. IN./OUT. → a. STATUS → b. ANALOG. IN.

Below is the table of parameters that can be displayed on the terminal.

The values indicated with '---' are not significant or are not set, while the values indicated with '!' may vary according to the configuration and the possible options are visible on the user terminal. A line of '!' means that there are a series of parameters similar to the previous ones.

 **Note:** not all of the screens and parameters in the table are always visible/settable, the visible/settable screens and parameters depend upon the configuration and access level.

Mask index	Display description	Description	Def.	U. of M.	Values
MAIN MASK	---	Hour and minutes	---	---	---
	---	Date	---	---	---
	Suction	Suction pressure or temperature	---	---	... (**)
	Gas cool.	Gas cooler pressure or temperature	---	---	... (**)
	Superheat	Superheating	---	---	... (**)
	Suc.Temp.	Suction temperature	---	---	... (**)
	Disch.Temp.	Discharge temperature	---	---	... (**)
Main mask for individual suction line and individual condensing line (display only)	---	Unit status (with unit OFF)	---	---	Unit OFF due to Alarms Unit OFF due to black out Unit OFF from supervisor Unit OFF from default Unit OFF from digital input Unit OFF from keypad Unit OFF from manual mode
	---	Number compressors on (with unit ON)	---	---	0...12
	---	Compressor activation percentage (with unit ON)	---	%	0...100
	---	Number of fans on (with unit ON)	---	---	0...16
	---	Fan activation percentage (with unit ON)	---	%	0...100
	---	Hour and minutes	---	---	---
	---	Date	---	---	---
	L1-Suction	Suction pressure or temperature (line 1)	---	---	... (**)
	L1-Gas cool.	Gas cooler pressure or temperature (line 1)	---	---	... (**)
	L1-Superheat	Superheating (line 1)	---	---	... (**)
	L1-Suc.Temp.	Suction temperature (line 1)	---	---	... (**)
	L1-Disch.Temp.	Discharge temperature (line 1)	---	---	... (**)
Main mask for double suction line and double condensing line, masks separated per each line (display only)	---	Unit status (with unit OFF)	---	---	See individual line mask values
	---	Number compressors on (with unit ON, line 1)	---	---	0...12
	---	Compressor activation percentage (with unit ON, line 1)	---	%	0...100
	---	Number of fans on (with unit ON, line 1)	---	---	0...16
	---	Fan activation percentage (with unit ON, line 1)	---	%	0...100
	L2-Suction	Suction pressure or temperature (line 2)	---	---	... (**)
	L2-Condens.	Condensing pressure or temperature (line 2)	---	---	... (**)
	L2-Superheat	Superheating (line 2)	---	---	... (**)
	L2-Suc.Temp.	Suction temperature (line 2)	---	---	... (**)
	L2-Disch.Temp.	Discharge temperature (line 2)	---	---	... (**)
	---	Unit status (with unit OFF)	---	---	See individual line mask values
	---	Number compressors on (with unit ON, line 2)	---	---	0...12
	---	Compressor activation percentage (with unit ON, line 2)	---	%	0...100
	---	Number of fans on (with unit ON, line 2)	---	---	0...16
	---	Fan activation percentage (with unit ON, line 2)	---	%	0...100
	---	Hour and minutes	---	---	---
	---	Date	---	---	---
	L1-Suction	Suction pressure or temperature (line 1)	---	---	... (**)
	L1-Gas cool.	Gas cooler pressure or temperature (line 1)	---	---	... (**)
	L2-Suction	Suction pressure or temperature (line 2)	---	---	... (**)
	L2-Condens.	Condensing pressure or temperature (line 2)	---	---	... (**)
	L1-Suc.Temp.	Suction temperature (line 1)	---	---	... (**)
	L1-Superheat	Superheating (line 1)	---	---	... (**)
	L2-Suc.Temp.	Suction temperature (line 2)	---	---	... (**)
	L2-Superheat	Superheating (line 2)	---	---	... (**)
	L1-Disch.Temp.	Discharge temperature (line 1)	---	---	... (**)
	L2-Disch.Temp.	Discharge temperature (line 2)	---	---	... (**)
	---	Unit status (with unit OFF)	---	---	See individual line mask values
	---	Compressor activation percentage (with unit ON, line 1)	---	%	0...100
	---	Compressor activation percentage (with unit ON, line 2)	---	%	0...100
	---	Fan activation percentage (with unit ON, line 1)	---	%	0 to 100
	---	Fan activation percentage (with unit ON, line 2)	---	%	0...100
	---	Hour and minutes	---	---	---
	---	Date	---	---	---
	Suction: L1	Suction pressure or temperature (line 1)	---	---	... (**)
	L2	Suction pressure or temperature (line 2)	---	---	... (**)
	Gas cooler	Gas cooler pressure or temperature	---	---	... (**)
	L1-Suc.Temp.	Suction temperature (line 1)	---	---	... (**)
	L1-Disch.Temp.	Discharge temperature (line 1)	---	---	... (**)
	L1-Superheat	Superheating (line 1)	---	---	... (**)
	L2-Suc.Temp.	Suction temperature (line 2)	---	---	... (**)
	L2-Disch.Temp.	Discharge temperature (line 2)	---	---	... (**)
	L2-Superheat	Superheating (line 2)	---	---	... (**)
	---	Unit status (with unit OFF)	---	---	See individual line mask values
	---	Compressor activation percentage (with unit ON, line 1)	---	%	0...100
	---	Compressor activation percentage (with unit ON, line 2)	---	%	0...100
	---	Fan activation percentage (with unit ON, line 1)	---	%	0...100

Tab. 7.a

Mask index	Display description	Description	Def.	U. of M.	Values
A. Unit Status					
Aa01 (display only)	Pressure	Suction pressure (line 1)	---	---	... (**)
	Sat.Temp.	Suction saturated temperature (line 1)	---	---	... (**)
	ActualSet	Actual setpoint for pressure regulation (with compensations applied, line 1)	---	---	... (**)
	Differen.	Regulation differential for pressure regulation (line 1)	---	---	... (**)
Aa02 (display only)	Pressure	Suction pressure (line 1)	---	---	... (**)
	Sat.Temp.	Suction saturated temperature (line 1)	---	---	... (**)
	ActualSet	Actual setpoint for temperature regulation (with compensations applied, line 1)	---	---	... (**)
	Differen.	Regulation differential for temperature regulation (line 1)	---	---	... (**)
Aa03 (display only)	Act/Req.	Power delivered/Power requested per suction line (line 1)	---	%	0 0 ... 100 100
	Reg. Status	Regulation status (according to the type of regulation set, line 1)	---	---	Stop Increase Decrease Stand-by Functioning Timings Alarms
	Reg. Type	Compressor regulation type (line 1)	---	---	Proportional Band Dead Zone
Aa04 (display only)	Setpoint	Actual suction setpoint (with compensations applied, line 1)	---	---	... (**)
	C01, C02, ... C12	Time remaining for next compressor startup (line 1)	---	s	0...32000
	C01	Power delivered from compressor 1 of line 1 (a "!" to the right of the value means that some form of compressor power forcing is active, e.g., safety times, alarms, startup procedure)	---	%	0...100
	C12	Power delivered from compressor 12 (line 1)	---	%	0...100
Aa05 (display only)	Temperature	Suction temperature (line 1)	---	---	... (**)
	Superheat.	Superheating (line 1)	---	---	... (**)
Aa11 (display only)	Disch. 1	Discharge temperature compressor 1 (line 1)	---	---	... (**)
	Disch. 6	Discharge temperature compressor 6 (line 1)	---	---	... (**)
Aa12 (display only)	Oil Temp 1	Oil temperature compressor 1 (line 1)	---	---	... (**)
	Oil Temp 6	Oil temperature compressor 6 (line 1)	---	---	... (**)
Aa13 (display only)	In.liq.1: DO	Digital output number associated and liquid injection/economizer (*) status compressor 1 (line 1)	---	---	0...29
	In.liq.6: DO	Digital output number associated and liquid injection/economizer (*) status compressor 6 (line 1)	---	---	0...29
Aa15 (display only)	Discharge temperature	Discharge temperature Digital Scroll™ compressor (line 1)	---	---	... (**)
	Cap.Reduction	Capacity reduction Digital Scroll™ compressor (line 1) in progress	---	---	NO YES
	Oil sump T.	Oil sump temperature Digital Scroll™ compressor (line 1)	---	---	... (**)
	Oil status	Oil dilution status Digital Scroll™ compressor (line 1)	---	---	OK Diluted
Aa16 (display only)	Status	Operational status Digital Scroll™ compressor (line 1)	---	---	OFF Start ON Alarm
	Count	Safety time count Digital Scroll™ compressor (line 1)	---	s	0...999
	Compr.	Status Digital Scroll™ compressor (line 1)	---	---	ON OFF
	Valve	Status Digital Scroll™ valve (line 1)	---	---	ON OFF
	Cap.Reg.	Capacity requested Digital Scroll™ compressor (line 1)	---	%	0...100
	ActualCapac.	Actual capacity Digital Scroll™ compressor (line 1)	---	%	0...100
Aa20 (display only)	Pressure	Condensing pressure (line 1)	---	---	... (**)
	Sat.Temp.	Condensing saturated temperature (line 1)	---	---	... (**)
	ActualSet	Actual setpoint for pressure regulation (with compensations applied, line 1)	---	---	... (**)
	Differen.	Regulation differential for pressure regulation (line 1)	---	---	... (**)
Aa21 (display only)	Pressure	Condensing pressure (line 1)	---	---	... (**)
	Sat.Temp.	Condensing saturated temperature (line 1)	---	---	... (**)
	ActualSet	Actual setpoint for temperature regulation (with compensations applied, line 1)	---	---	... (**)
Aa22 (display only)	Differen.	Regulation differential for temperature regulation (line 1)	---	---	... (**)
	Act/Req.	Power delivered/Power requested per condensing line (line 1)	---	%	0 0 ... 100 100
	Reg. Status	Regulation status (according to the type of regulation set, line 1)	---	---	Stop Increase Decrease Stand-by Functioning Timings Alarms
Aa23 (display only)	Reg. Type	Gas cooler regulation type (line 1)	---	---	Proportional Band Dead Zone
	Setpoint	Actual setpoint gas cooler (line 1)	---	---	... (**)
	F1	Power delivered from fan 1 of line 1 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
Aa24 (display only)	F8	Power delivered from fan 8 of line 1 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
	F9	Power delivered from fan 9 of line 1 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
Aa25 (display only)	F16	Power delivered from fan 16 of line 1 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
	Discharge temperature	Discharge temperature (line 1)	---	---	... (**)
Aa31 (display only)	External temperature	External temperature (line 1)	---	---	... (**)
	Pressure	Suction pressure (line 2)	---	---	... (**)
	Sat.Temp.	Suction saturated temperature (line 2)	---	---	... (**)
	ActualSet	Actual setpoint for pressure regulation (with compensations applied, line 2)	---	---	... (**)
Aa32 (display only)	Differen.	Regulation differential for pressure regulation (line 2)	---	---	... (**)
	Pressure	Suction pressure (line 2)	---	---	... (**)
	Sat.Temp.	Suction saturated temperature (line 2)	---	---	... (**)
Aa33 (display only)	ActualSet	Actual setpoint for temperature regulation (with compensations applied, line 2)	---	---	... (**)
	Differen.	Regulation differential for temperature regulation (line 2)	---	---	... (**)
	Act/Req.	Power delivered/Power requested per suction line (line 2)	---	%	0 0 ... 100 100
Aa34 (display only)	Reg. Status	Regulation status (according to the type of regulation set, line 2)	---	---	Stop Increase Decrease Stand-by Functioning Timings Alarms
	Reg. Type	Compressor regulation type (line 2)	---	---	Proportional Band Dead Zone
	Setpoint	Actual suction setpoint (with compensations applied, line 2)	---	---	... (**)
	C01, C02, ... C12	Time remaining for next compressor startup (line 2)	---	s	0...32000
Aa34 (display only)	C01	Power delivered from compressor 1 from line 2 (a "!" to the right of the value means that some form of compressor power forcing is active, e.g., safety times, alarms, startup procedure)	---	%	0...100
	C12	Power delivered from compressor 12 (line 2)	---	%	0...100

Mask index	Display description	Description	Def.	U. of M.	Values
Aa35 (display only)	Temperature	Suction temperature (line 2)	---	---	...(**)
	Superheat.	Superheating (line 2)	---	---	...(**)
Aa41 (display only)	Disch. 1	Discharge temperature compressor 1 (line 2)	---	---	...(**)
	Disch. 6	Discharge temperature compressor 6 (line 2)	---	---	...(**)
Aa43 (display only)	In.liq.1: DO	Digital output number associated and liquid injection status compressor 1 (line 2)	---	---	0...29 ON OFF
	In.liq.6: DO	Digital output number associated and liquid injection status compressor 6 (line 2)	---	---	0...29 ON OFF
Aa45 (display only)	Discharge temperature	Discharge temperature Digital Scroll™ compressor (line 2)	---	---	...(**)
	Cap.Reduction	Capacity reduction Digital Scroll™ compressor (line 2) in progress	---	---	NO YES
	Oil sump T.	Oil sump temperature Digital Scroll™ compressor (line 2)	---	---	...(**)
	Oil status	Oil dilution status Digital Scroll™ compressor (line 2)	---	---	Ok Diluted
Aa46 (display only)	Status	Operational status Digital Scroll™ compressor (line 2)	---	---	OFF start ON Alarm OFF for time ON for time manual mode in pump down
	Count	Safety time count Digital Scroll™ compressor (line 2)	---	s	0...999
	Compr.	Status Digital Scroll™ compressor (line 2)	---	---	ON OFF
	Valve	Status Digital Scroll™ valve (line 2)	---	---	ON OFF
	Cap.Reg.	Capacity requested Digital Scroll™ compressor (line 2)	---	%	0...100
	ActualCapac.	Actual capacity Digital Scroll™ compressor (line 2)	---	%	0...100
	Pressure	Condensing pressure (line 2)	---	---	...(**)
	Sat.Temp.	Condensing saturated temperature (line 2)	---	---	...(**)
	ActualSet	Actual setpoint for pressure regulation (with compensations applied, line 2)	---	---	...(**)
	Differen.	Regulation differential for pressure regulation (line 2)	---	---	...(**)
Aa51 (display only)	Pressure	Condensing pressure (line 2)	---	---	...(**)
	Sat.Temp.	Condensing saturated temperature (line 2)	---	---	...(**)
	ActualSet	Actual setpoint for temperature regulation (with compensations applied, line 2)	---	---	...(**)
	Differen.	Regulation differential for temperature regulation (line 2)	---	---	...(**)
Aa52 (display only)	Act/Req.	Power delivered/Power requested per condensing line (line 2)	---	%	0 0...100 100
	Reg. Status	Regulation status (according to the type of regulation set, line 2)	---	---	stop increase decrease stand-by functioning timings alarms
	Reg. Type	Condenser regulation Type (line 2)	---	---	Proportional Band Dead zone
	Setpoint	Actual condensing setpoint (with compensations applied, line 2)	---	---	...(**)
Aa53 (display only)	F1	Power delivered from fan 1 of line 2 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
	F8	Power delivered from fan 8 of line 2 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
Aa54 (display only)	F9	Power delivered from fan 9 of line 2 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
	F16	Power delivered from fan 16 of line 2 (a "!" to the right of the value means that some form of power forcing is active)	---	%	0...100
Aa55 (display only)	Discharge temperature	Discharge temperature (line 2)	---	---	...(**)
	External temperature	External temperature (line 2)	---	---	...(**)
Aa61 (display only)	Suct Press	Suction pressure value in the medium temperature compressor line	---	---	...(**)
	Oil Press	Oil receiver pressure value	---	---	...(**)
	Delta	Difference between receiver oil pressure and suction pressure (medium temperature compressors or liquid receiver when integrated parallel compressor activated or in pLAN when using the same I/Os)	---	---	...(**)
	Actual Setp	Pressure differential set point (receiver - suction)	1.0	barg/psig	...
Aa65	Differential	Return differential for deactivation of the oil differential function	0.5	barg/psig	...
	State	Oil differential function status (YES→ ACTIVE, NO→ INACTIVE)	NO	---	YES NO
	S1 probe	Driver pressure probe S1 (driver connected in Fieldbus)	---	bar	-290...2900
	S2 probe	Driver pressure probe S2 (driver connected in Fieldbus)	---	°C	-870...2900
	S3 probe	Driver pressure probe S3 (driver connected in Fieldbus)	---	bar	-290...2900
	S4 probe	Driver pressure probe S4 (driver connected in Fieldbus)	---	°C	-870...2900
	Digital input staus 1	Driver digital input 1 (driver connected in Fieldbus)	---	---	Open Closed
Aa77 (display only)	Digital input staus 2	Driver digital input 2 (driver connected in Fieldbus)	---	---	Open Closed
	Parallel compressor status:	Parallel compressor status	ON/OFF	---	ON OFF not active
	GC out.temp.:	Gas Cooler Outlet temperature	---	°C/°F	...
	RPRV opening:	RPRV valve opening	---	%	...
Aaa76 (display only)	RPRV setp.:	RPRV Setpoint	---	barg	...
	HR Total Request:	Percentage of heat reclaim used to activate different actions. It can refer to HR1 or HR2 or HR1+HR2	---	%	...
	Status:	Detailed description of current running action	---	---	...
	Run actions:	Run actions presence	---	---	YES No
	Min HPV set.:	Current minimum HPV setpoint	40	barg	...
	Offset GC:	Current temperature GC offset (to increase GC setpoint)	---	°C/°F	...
Aaa77 (display only)	HR prevent:	HR configured as prevent and active	---	---	ON OFF
	HR Total Request:	Percentage of heat reclaim used to activate different actions. It can refer to HR1 or HR2 or HR1+HR2	---	%	...
	Bypass Allowed	Status of bypass allowed	---	---	...
	GC out. Temp:	Current GC out temperature	---	°C/°F	...
	GC byp. Temp:	Current GC baypassed temperature	---	°C/°F	...
	GC reg. temp:	Current regulation temperature: Tgc out if bypass off, Tgc byp if bypass on	---	°C/°F	...
	Gas Cooler byp:	Opening percentage of bypass valve	---	%	...
	Req.var.	Value of the regulation variable for the generic function in stage 1	---	---	...(**)
Aaan (display only)	Enable	Status of the enabling variable for the generic function in stage 1	---	---	Not active Active
	Setpoint	Regulation setpoint for the generic function in stage 1	---	---	...(**)
	Differen.	Regulation differential for the generic function in stage 1	---	---	...(**)
	Mode	Regulation mode for the generic function in stage 1 (direct or reverse)	---	---	D, R
	Status	Status of the generic function in stage 1	---	---	Not active Active
...	---	---	...

Mask index	Display description	Description	Def.	U. of M.	Values
Aaar (display only)	Reg.var.	Value of the regulation variable for the generic function in stage 5	---	---	... (**)
	Enable	Status of the enabling variable for the generic function in stage 5	---	---	Not active Active
	Setpoint	Regulation setpoint for the generic function in stage 5	---	---	... (**)
	Differen.	Regulation differential for the generic function in stage 5	---	---	... (**)
	Mode	Regulation mode for the generic function in stage 5 (direct or reverse)	---	---	D, R
	Status	Status of the generic function in stage 5	---	---	Not active Active
Aaas (display only)	Reg.variab.	Value of the regulation variable for generic modulating function 1	---	---	... (**)
	Enable	Status of the enabling variable for generic modulating function 1	---	---	Not active Active
	Setpoint	Regulation setpoint for generic modulating function 1	---	---	... (**)
	Differen.	Regulation differential for generic modulating function 1	---	---	... (**)
	Mode	Regulation mode for generic modulating function 1 (direct or reverse)	---	---	D, R
	Status	Status of generic modulating function 1	---	%	0.0...100.0
Aaat (display only)	Reg.variab.	Value of the regulation variable for generic modulating function 2	---	---	... (**)
	Enable	Status of the enabling variable for generic modulating function 2	---	---	Not active Active
	Setpoint	Regulation setpoint for generic modulating function 2	---	---	... (**)
	Differen.	Regulation differential for generic modulating function 2	---	---	... (**)
	Mode	Regulation mode for generic modulating function 2 (direct or reverse)	---	---	D, R
	Status	Status of generic modulating function 2	---	%	0.0...100.0
Aaau (display only)	Reg.variab.	Value of the regulation variable for generic alarm function 1	---	---	Not active Active
	Enable	Status of the enabling variable for generic alarm function 1	---	---	Not active Active
	Type	Type of alarm for generic alarm function 1	---	---	Normal Serious
	Delay	Regulation differential for generic alarm function 1	---	s	0...9999
	Status	Status of generic alarm function 1	---	---	Not active Active
	Aaav (display only)	Reg.variab.	Value of the regulation variable for generic alarm function 2	---	---
Enable		Status of the enabling variable for generic alarm function 2	---	---	Not active Active
Type		Type of alarm for generic alarm function 2	---	---	Normal Serious
Delay		Regulation differential for generic alarm function 2	---	s	0...9999
Status		Status of generic alarm function 2	---	---	Not active Active
Aaaw (display only)		Day	Day of the week	---	---
	F1: ---:--> --:--	Enabling and definition of time band 1: start hour and minute, end hour and minute for the generic scheduling function	---	---	...

	F4: ---:--> --:--	Enabling and definition of time band 4: start hour and minute, end hour and minute for the generic scheduling function	---	---	...
	Status	Status of the general scheduling function	---	---	Not active Active
	Aaax (display only)	HR 1 Request:	Percentage of first heat reclaim request	---	%
HR 1 Status:		Status of first heat reclaim request	---	---	ON OFF
Water temp.:		Water temperature with HR1 regulated by temperature	---	°C/°F	
Valve:		Status of first heat reclaim valve	---	---	Open Closed
Pump:		Status of first heat reclaim pump	---	---	ON OFF
Pump An. Out:		Running percentage of first heat reclaim pump	---	%	
Aaay (display only)	HR 2 Request:	Percentage of second heat reclaim request	---	%	
	HR 2 Status:	Status of second heat reclaim request	---	---	ON OFF
	Water temp.:	Water temperature with HR2 regulated by temperature	---	°C/°F	
	Valve:	Status of second heat reclaim valve	---	---	Open Closed
	Pump:	Status of second heat reclaim pump	---	---	ON OFF
	Pump An. Out:	Running Percentage of second heat reclaim pump	---	%	
Aaaz (display only)	Status	Status of the ChillBooster device (line 1)	---	---	ON OFF
	Ext.Temp.	External temperature (line 1)	---	---	... (**)
	Thresh.est.t.	Threshold for activating the ChillBooster device (line 1)	---	---	... (**)
	F.Time100%	Number of minutes passed with fan at 100/number of minutes allowed (line 1)	---	min	0...999 0...999
Aaba (display only)	Status	Status of the ChillBooster device (line 2)	---	---	ON OFF
	Ext.Temp.	External temperature (line 2)	---	---	... (**)
	Thresh.est.t.	Threshold for activating the ChillBooster device (line 2)	---	---	... (**)
	F.Time100%	Number of minutes passed with fan at 100/number of minutes allowed (line 2)	---	min	0...999 0...999
Aabb (display only)	Cond.Temp.	Condensing saturated temperature (line 1)	---	---	... (**)
	LiquidTemp	Liquid temperature (line 1)	---	---	... (**)
	Subcool	Subcooling (line 1)	---	---	... (**)
	Status	Status of the subcooling function (line 1)	---	---	Open Closed
Aabc (display only)	Cond.Temp.	Condensing saturated temperature (line 2)	---	---	... (**)
	LiquidTemp	Liquid temperature (line 2)	---	---	... (**)
	Subcool	Subcooling (line 2)	---	---	... (**)
	Status	Status of the subcooling function (line 2)	---	---	Open Closed
Ab01 (display only)	UserSetp.	Setpoint set by the user for suction regulation under pressure, proportional regulation (line 1)	---	---	... (**)
	ActualSetp.	Actual setpoint for suction regulation under pressure, proportional regulation (with compensations applied, line 1)	---	---	... (**)
	Diff.	Suction regulation under pressure differential, proportional regulation (line 1)	---	---	... (**)
Ab02 (display only)	UserSetp.	Setpoint set by the user for suction regulation under pressure, proportional regulation (line 1)	---	---	... (**)
	ActualSetp.	Actual setpoint for suction regulation under pressure, proportional regulation (with compensations applied, line 1)	---	---	... (**)
	Dead zone	Dead zone for suction regulation under pressure (line 1)	---	---	... (**)
	Incr.Diff.	Increase differential for suction regulation under pressure, regulation in dead zone (line 1)	---	---	... (**)
	Decr.Diff.	Decrease differential for suction regulation under pressure, regulation in dead zone (line 1)	---	---	... (**)
	Ab03 (display only)	UserSetp.	Setpoint set by the user for suction regulation under pressure, proportional regulation (line 2)	---	---
ActualSetp.		Actual setpoint for suction regulation under pressure, proportional regulation (with compensations applied, line 2)	---	---	... (**)
Diff.		Suction regulation under pressure differential, proportional regulation (line 2)	---	---	... (**)
UserSetp.		Setpoint set by the user for suction regulation under pressure, proportional regulation (line 2)	---	---	... (**)
ActualSetp.		Actual setpoint for suction regulation under pressure, proportional regulation (with compensations applied, line 2)	---	---	... (**)
Dead zone		Dead zone for suction regulation under pressure (line 2)	---	---	... (**)
Ab04 (display only)	Incr.Diff.	Increase differential for suction regulation under pressure, regulation in dead zone (line 2)	---	---	... (**)
	Decr.Diff.	Decrease differential for suction regulation under pressure, regulation in dead zone (line 2)	---	---	... (**)
	UserSetp.	Setpoint set by the user for gas cooler regulation under pressure, proportional regulation (line 1)	---	---	... (**)
	ActualSetp.	Actual setpoint for gas cooler regulation under pressure, proportional regulation (with compensations applied, line 1)	---	---	... (**)
	Diff.	Gas cooler regulation under pressure differential, proportional regulation (line 1)	---	---	... (**)

Mask index	Display description	Description	Def.	U. of M.	Values
Ab06 (display only)	UserSetp.	Setpoint set by the user for gas cooler regulation under pressure, proportional regulation (line 1)	---(**)
	ActualSetp.	Actual setpoint for gas cooler regulation under pressure, proportional regulation (with compensations applied, line 1)	---(**)
	Dead zone	Dead zone for gas cooler regulation under pressure (line 1)	---(**)
	Incr.Diff.	Increase differential for gas cooler regulation under pressure, regulation in dead zone (line 1)	---(**)
	Decr.Diff.	Decrease differential for gas cooler regulation under pressure, regulation in dead zone (line 1)	---(**)
Ab07 (display only)	UserSetp.	Setpoint set by the user for condensing regulation under pressure, proportional regulation (line 2)	---(**)
	ActualSetp.	Actual setpoint for condensing regulation under pressure, proportional regulation (with compensations applied, line 2)	---(**)
	Diff.	Condensing regulation under pressure differential, proportional regulation (line 2)	---(**)
Ab08 (display only)	UserSetp.	Setpoint set by the user for condensing regulation under pressure, proportional regulation (line 2)	---(**)
	ActualSetp.	Actual setpoint for condensing regulation under pressure, proportional regulation (with compensations applied, line 2)	---(**)
	Dead zone	Dead zone for condensing regulation under pressure (line 1)	---(**)
	Incr.Diff.	Increase differential for condensing regulation under pressure, regulation in dead zone (line 2)	---(**)
	Decr.Diff.	Decrease differential for condensing regulation under pressure, regulation in dead zone (line 2)	---(**)
Ab12	Setpoint	Setpoint without compensation (suction line 1)	26.0 barg(**)
Ab13	Setpoint	Setpoint without compensation (gas cooler line 1)	12.0 °C(**)
Ab14	Setpoint	Setpoint without compensation (suction line 2)	12.0 barg(**)
Ab15	Setpoint	Setpoint without compensation (condens. line 2)	12.0 barg(**)
Ac01	Status	Unit status (display only)	OFF from keypad	---	Wait... Unit ON OFF from Alarm OFF from blackout OFF from BMS OFF from default OFF from DIN OFF from keypad Manual Funct. work Prevent from HP
	---	On-off from keypad (line 1)	OFF	---	OFF ON
Ac02	L1:	Unit status (display only)	OFF da tastiera	---	... (see Ac01 above)
	L2:	On-off from keypad (line 2)	OFF	---	OFF ON
Ac03	---	On-off from keypad (line 1)	OFF	---	OFF ON
	---	On-off from keypad (line 2)	OFF	---	OFF ON
Ac03	Enable unit On/Off from digital input	Enable unit On/Off from digital input (line 1)	NO	---	NO YES
	From supervisor	Enable on-off from supervisor (line 1)	NO	---	NO YES
Ac04	Due to black out	Enable on-off due to black out (line 1)	NO	---	NO YES
	Delay unit startup after blackout	Delay unit startup after blackout (line 1)	0	s	0...999
Ac06	Enable unit On/Off from digital input	Enable unit On/Off from digital input (line 2)	NO	---	NO YES
	From supervisor	Enable on-off from supervisor (line 2)	NO	---	NO YES
	Due to black out	Enable on-off due to black out (line 2)	NO	---	NO YES
Ac07	Unit startup delay after blackout	Unit startup delay after blackout (line 2)	0	s	0...999

Tab. 7.b

Mask index	Display description	Description	Def.	U. of M.	Values
<p>I/O B. INF. / OUT.</p> <p>The I/Os depend on the configuration selected, the following are only examples. See Appendix A.1 for the complete list and position of available I/Os.</p>					
Baa02	DI	Alarm 1 compressor 1 DI position (line 1)	03	---	---, 01...18, U1...U10 (****)
	Status (display only)	Status Alarm 1 compressor 1 DI (line 1)	---	---	Closed Open
	Logic	Logic alarm 1 compressor 1 DI (line 1)	NC	---	NC NO
	Function (display only)	Alarm 1 compressor 1 function status (line 1)	---	---	Not active Active
Baacf	---	---	---
	DI	Heat recovery from digital input DI position (line 1)	---	---	--- 01...18 U1...U10 (****)
	Status	Heat recovery from digital input DI status (line 1)	---	---	Closed Open
	Logic	Heat recovery from digital input DI logic (line 1)	NC	---	NC NO
...	Function	Heat recovery from digital input function status (line 1)	---	---	Not active Active
	---	---	---
	---	---	---
	---	---	---
Bab01	---	Suction pressure probe position (Line 1)	B1	---	---, U1...U10 (****)
	---	Suction pressure probe type (Line 1)	4...20mA	---	0-1V 0-10V 4...20mA 0-5V
	---	Suction pressure value (line 1)	---	---	...(**)
	Max limit	Suction pressure maximum value (line 1)	44.8 barg(**)
	Min limit	Suction pressure minimum value (line 1)	0.0 barg(**)
	Calibrat.	Suction pressure probe calibration (Line 1)	0.0 barg(**)
	---	Common oil receiver pressure probe position (line 1)	---	---	U1...U10 (****)
Bab63	---	Common oil receiver pressure probe type (line 1)	4...20mA	---	--- 0-1V 0-10V 4...20mA 0-5V
	---	Common oil receiver pressure value (line 1)	---	---	...(**)
	Max limit	Maximum common oil receiver pressure value (line 1)	44.8 barg(**)
	Min limit	Minimum common oil receiver pressure value (line 1)	0.0 barg(**)
	Calibrat.	Common oil receiver pressure probe calibration (line 1)	0.0 barg(**)
	---	Common oil receiver pressure probe position (line 2)	---	---	U1...U10 (****)
	---	Common oil receiver pressure probe type (line 2)	4...20mA	---	---, 0-1V 0-10V 4...20mA 0-5V
Bab65	---	Common oil receiver pressure value (line 2)	---	---	...(**)
	Max limit	Maximum common oil receiver pressure value (line 2)	44.8 barg(**)
	Min limit	Minimum common oil receiver pressure value (line 2)	0.0 barg(**)
	Calibrat.	Common oil receiver pressure probe calibration (line 2)	0.0 barg(**)

Mask index	Display description	Description	Def.	U. of M.	Values
Bab75	---	Discharge pressure probe position (line 1)	---	---	U1...U10 (****)
	---	Discharge pressure probe type (line 1)	4...20mA	---	---, 0-1V, 0-10V 4...20mA, 0-5V
	---	Discharge pressure value (line 1)	---	---	...(**)
	Max limit	Maximum discharge pressure value (line 1)	44.8 barg	---	...(**)
	Min limit	Minimum discharge pressure value (line 1)	0.0 barg	---	...(**)
	Calibrat.	Discharge pressure probe calibration (line 1)	0.0 barg	---	...(**)
Bac02	Line relay DO	Compressor 1 line relay DO position and status (On/Off) display (line 1)	---	---	--- 01...18 (****)
	Part winding DO/Star relay DO (*)	Compressor 1 part winding or star DO position and status (On/Off) display (line 1)	---	---	--- 01...18 (****)
	---/Delta relay DO (*)	Compressor 1 delta DO position and status (On/Off) display (line 1)	---	---	--- 01...18 (****)
Bac03	Logic DO	Logic for compressor 1 power supply DO (line 1)	NO	---	NC NO
	Status (display only)	Compressor 1 unloader 1 DO position (line 1)	---	---	--- 01...18 (****)
	Logic	Status for compressor 1 unloader 1 DO (line 1)	---	---	Closed Open
	Function (display only)	Logic for compressor 1 unloader 1 DO (line 1)	NO	---	NC NO
	Function (display only)	Compressor 1 unloader 1 function status (line 1)	---	---	Not active Active
Bac71	DO	Solenoid valve DO position for managing common oil differential	---	---	--- 01...18 (****)
	Status (display only)	Solenoid valve DO status for managing common oil differential	---	---	Closed Open
	Logic	Solenoid valve DO logic for managing common oil differential	NC	---	NC NO
	Function	Status of the solenoid valve for managing common oil differential	---	---	Not active Active
Bacef	DO Line relay	DO position and On/Off Status Parallel compressor consent	---	---	--- 01...18 (****)
	Logic:	Logic Parallel compressor consent DO:	NA	---	NC NA
Bad01	AO	Compressor modulating device AO position (line 1)	0	---	--- 01...06 (****)
	Status (display only)	Modulating device output value (line 1)	0	%	0.0...100.0
Bb01	Suction L1	Suction line 1 in manual mode	Disabled	---	Disabled abled
	Suction L2	Suction line 2 in manual mode	Disabled	---	Disabled abled
	Condenser L1	Condenser line 1 in manual mode	Disabled	---	Disabled abled
	Condenser L2	Condenser line 2 in manual mode	Disabled	---	Disabled abled
	Timeout	Manual mode duration after last key pressed	10	min	0...500
Bba02	Compressor 1 Force to	Manual stages request for compressor 1 (line 1)	OFF	---	OFF ON 2 STAGES (*) 3 STAGES (*) 4 STAGES (*)
Bba16	Compressor 12 Force to	Manual stages request for compressor 12 (line 1)	OFF	---	OFF ON 2 STAGES (*) 3 STAGES (*) 4 STAGES (*)
Bba17	Oil Cool. pump 1 Force to	Manual operation status for oil cooling pump 1 (line 1)	OFF	---	OFF ON
	Oil cool pump 2 Force to	Manual operation status for oil cooling pump 2 (line 1)	OFF	---	OFF ON
Bba18	Oil cool fan 1 Force to	Manual operation status for oil cooling fan 1 (line 1)	OFF	---	OFF ON
Bba20	Compressor 1 Force to	Manual stages request for compressor 1 (line 2)	OFF	---	OFF ON 2 STAGES (*) 3 STAGES (*) 4 STAGES (*)
Bba34	Compressor 12 Force to	Manual stages request for compressor 12 (line 2)	OFF	---	OFF ON 2 STAGES (*) 3 STAGES (*) 4 STAGES (*)
Bba35	Oil Cool. pump 1 Force to	Manual operation status for oil cooling pump 1 (line 2)	OFF	---	OFF ON
	Oil Cool. pump 2 Force to	Manual operation status for oil cooling pump 2 (line 2)	OFF	---	OFF ON
Bba37	Oil cool fan 1 Force to	Manual operation status for oil cooling fan (line 2)	OFF	---	OFF ON
Bba38	Fan 1 Force to	Manual operation status for fan 1 (line 1)	OFF	---	OFF ON
Bba53	Fan 16 Force to	Manual operation status for fan 16 (line 1)	OFF	---	OFF ON
Bba54	Heat rec.pump Force to	Manual operation status for heat recovery pump (line 1)	OFF	---	OFF ON
Bba55	ChillBooster Force to	Manual operation status for ChillBooster (line 1)	OFF	---	OFF ON
Bba57	Fan 1 Force to	Manual operation status for fan 1 (line 2)	OFF	---	OFF ON
Bba72	Fan 16 Force to	Manual operation status for fan 16 (line 2)	OFF	---	OFF ON
Bba73	Heat rec.pump Force to	Manual operation status for heat recovery pump (line 2)	OFF	---	OFF ON
Bba74	ChillBooster Force to	Manual operation status for ChillBooster (line 2)	OFF	---	OFF ON
Bbb05	Compressor 1 Force to	Manual request for continuous capacity for compressor 1 (line 1)	0.0	%	0.0...100.0
Bbb06	Oil cool. pump Force to	Manual request for oil cooling pump (line 1)	0.0	%	0.0...100.0
Bbb07	Compressor 1 Force to	Manual request for continuous capacity for compressor 1 (line 2)	0.0	%	0.0...100.0
Bbb08	Oil cool. pump Force to	Manual request for oil cooling pump (line 2)	0.0	%	0.0...100.0
Bbb09	Fan 1 Force to	Manual request for continuous capacity for fan 1 (line 1)	0.0	%	0.0...100.0
Bbb10	Heat recovery pump Force to	Manual request for heat recovery pump (line 1)	0.0	%	0.0...100.0
Bbb11	Fan 1 Force to	Manual request for continuous capacity for fan 1 (line 2)	0.0	%	0.0...100.0
Bbb12	Heat recovery pump Force to	Manual request for heat recovery pump (line 2)	0.0	%	0.0...100.0

Mask index	Display description	Description	Def.	U. of M.	Values
Bbb75	---	Discharge pressure probe position (line 2)	---	---	U1...U10 (****)
	---	Discharge pressure probe type (line 2)	4...20mA	---	---, 0-1V, 0-10V 4...20mA, 0-5V
	--- (display only)	Discharge pressure value (line 2)	---	---	... (**)
	Max limit	Maximum discharge pressure value (line 2)	44.8 barg	---	... (**)
	Min limit	Minimum discharge pressure value (line 2)	0.0 barg	---	... (**)
	Calibrat.	Common oil receiver pressure probe calibration (line 2)	0.0 barg	---	... (**)
Bc01	Test DO	Enable DO test mode	NO	---	NO YES
	Timeout	Duration of test mode after last key pressed	10	min	0...500
Bc02	Test AO	Enable AO test mode	NO	---	NO YES
	Timeout	Duration of test mode after last key pressed	10	min	0...500
Bca10	DO1	DO 1 test logic	NO	---	NO NC
	---	DO 1 test value	OFF	---	OFF ON
	---	---	---	---	---
Bca26	D29	DO 29 test logic	NO	---	NO NC
	---	DO 29 test value	OFF	---	OFF ON
Bcb10	AO1	AO 1 test value	0.0	---	0.0...100.0
	---	---	---	---	---
Bcb12	AO6	AO 6 test value	0.0	---	0.0...100.0

Tab. 7.c

Mask index	Display description	Description	Def.	U. of M.	Values
 C. COMPRESSORS					

The I/Os depend on the configuration selected, the following are only examples. See Appendix A.1 for the complete list and position of available I/Os.

Caa01	DI	Alarm 1 compressor 1 DI position (line 1)	03	---	--- 01...18 U1...U10 (****)
	Status (display only)	Status Alarm 1 compressor 1 DI (line 1)	---	---	closed open
	Logic	Logic alarm 1 compressor 1 DI (line 1)	NC	---	NC NO
	Function (display only)	Alarm 1 compressor 1 function status (line 1)	---	---	not active active
	---	---	---	---	---
Caa08	Line relay DO	Compressor 1 line DO position and status (On/Off) display (line 1)	---	---	---, 01...18 (****)
	Part winding DO/Star relay DO (*)	Compressor 1 part winding/star DO position and status (On/Off) display (line 1)	---	---	---, 01...18 (****)
	---/Delta relay DO (*)	Compressor 1 DO position and status (On/Off) display (line 1)	---	---	---, 01...18 (****)
	Logic	Logic for compressor 1 power supply DO (line 1)	NC	---	NC NO
Caa09	DO	Compressor 1 unloader 1 DO position (line 1)	---	---	---, 01...18 (****)
	Status (display only)	Status for compressor 1 unloader 1 DO (line 1)	---	---	closed open
	Logic	Logic for compressor 1 unloader 1 DO (line 1)	NC	---	NC NO
	Function (display only)	Compressor 1 unloader 1 function status (line 1)	---	---	not active active
	---	---	---	---	---
Caa14	AO	Compressor modulating device AO position (line 1)	0	---	---, 01...06 (****)
	Status (display only)	Modulating device output value (line 1)	0	%	0.0...100.0
	---	---	---	---	---
Caal	---	Suction pressure probe position (Line 1)	B1	---	--- U1...U10 (****)
	---	Suction pressure probe type (Line 1)	4...20 mA	---	---, 0-1 V, 0-10 V 4...20 mA, 0-5 V
	--- (display only)	Suction pressure value (line 1)	---	---	... (**)
	Max limit	Suction pressure maximum value (line 1)	44.8 barg	---	... (**)
	Min limit	Suction pressure minimum value (line 1)	0.0 barg	---	... (**)
	Calibrat.	Suction pressure probe calibration (Line 1)	0.0 barg	---	... (**)
	---	---	---	---	---
Cab01	Regulation	Compressor control by temperature or pressure (line 1)	pressure	---	pressure / temperature
	Reg. Type	Compressor regulation type (line 1)	dead zone	---	proportional Band dead Zone
Cab02	Minimum	Compressor setpoint lower limit (line 1)	0.0 barg	---	... (**)
	Maximum	Compressor setpoint upper limit (line 1)	40.0 barg	---	... (**)
Cab03	Setpoint	Compressor setpoint (line 1)	26.0 barg	---	... (**)
Cab04/Cab6 (**)	Reg. Type	Proportional regulation type (line 1)	proporz.	---	proportional / proport.+int.
	Integral time	Integral time for proportional regulation (line 1)	300	s	0...999
Cab05/Cab7 (**)	Differential	Differential for proportional regulation (line 1)	0.5 barg	---	... (**)
Cab08/Cab10 (**)	NZ diff.	Dead zone regulation differential (line 1)	0.5 barg	---	... (**)
	Activ.diff.	Dead zone regulation differential for device activation (line 1)	0.7 barg	---	... (**)
	Deact.diff.	Dead zone regulation differential for device deactivation (line 1)	0.7 barg	---	... (**)
Cab09/Cab11 (**)	En.force off	Enable capacity immediate decreasing to 0 (line 1)	NO	---	NO YES
	Setp. force off	Threshold for capacity decreasing to 0 (line 1)	0.0 barg	---	... (**)
Cab12	Power to 100% min time	Minimum time to increase capacity request to 100%, dead zone regulation (suction line 1)	15	s	0...9999
	Power to 100% max time	Maximum time to increase capacity request to 100%, dead zone regulation (suction line 1)	90	s	0...9999
Cab13	Power reduction to 0% min time	Minimum time to decrease capacity request to 0%, dead zone regulation (suction line 1)	30	s	0...9999
	Power reduction to 0% max time	Maximum time to decrease capacity request to 0%, dead zone regulation (suction line 1)	180	s	0...9999
Cac01	Compressor 1 operating hours (Check in...)	Compressor 1 operating hours (line 1)	---	h	0...999999
	Compressor (Check in...)	Compressor 1 remaining operating hours (line 1)	---	h	0...999999
	Compressor (Check in...)	Compressor 2 operating hours (line 1)	---	h	0...999999
	Compressor (Check in...)	Compressor 2 remaining operating hours (line 1)	---	h	0...999999
	---	---	---	---	---
Cac11	Compress 11 operating hours (Check in...)	Compressor 11 operating hours (line 1)	---	h	0...999999
	Compressor 12 (Check in...)	Compressor 11 remaining operating hours (line 1)	---	h	0...999999
	Compressor 12 (Check in...)	Compressor 12 operating hours (line 1)	---	h	0...999999
	Compressor 12 (Check in...)	Compressor 12 remaining operating hours (line 1)	---	h	0...999999
Cac13	Compressor threshold operating hours	Compressor maintenance threshold hours (line 1)	88000	h	0...999999
Cac14	Compressor hours reset	Reset compressor operating hours (line 1)	N	---	N S
Cad01	Enable suction setpoint compensation	Enable setpoint compensation (suction line 1)	NO	---	NO YES
Cad02	Winter offset	Offset applied for the Winter period	0.0	---	-999.9...999.9
	Closing offset	Offset applied for closing period	0.0	---	-999.9...999.9
Cad03	Enable setpoint compensation by scheduler	Enable scheduler setpoint compensation (suction line 1)	NO	---	NO YES

Mask index	Display description	Description	Def.	U. of M.	Values
Cad04	Day	Day of the week			MON,TUE,...SUN
	TB1: --- -> ---	Enabling and definition of time band 1: start hour and minute, end hour and minute (suction line 1)	---
	---	---	---	---	---
	TB4: --- -> ---	Enabling and definition of time band 4: start hour and minute, end hour and minute (suction line 1)	---
	Change	Time band change action	---	---	Save changes Load previous Clear all
	Copy to	Copy settings to other days	0	---	Monday...Sunday; Mon-Fri; Mon-Sat; Sat&Sun; All
Cad05	Change set by DI	Enable setpoint compensation by digital input (suct/cond line 1)	NO	---	NO YES
Cad08	Enable floating suction setpoint	Enable floating setpoint (suction line 1)	NO	---	NO YES
Cad09	Maximum floating setpoint	Max settable floating setpoint (line 1)	... (**) (**)
	Minimum floating setpoint	Minimum settable floating setpoint (line 1)	... (**) (**)
Cad10	Max setpoint variation accepted	Maximum variation allowed for floating setpoint (suction line 1)	... (**) (**)
	Offline decreasing time	Reduction time when supervisor is offline for floating setpoint (suction line 1)	0	min	0...999
Cae01	Number of alarms for each compressor	Number of alarms for each compressor (line 1)	1/4 (*)	---	0...4 7 (*)
Cae02	Alarm 1 descr.	Selection of first compressor alarm description: Generic, Overload, High pressure, Low pressure, Oil (line 1)	...	---	<input checked="" type="checkbox"/> (Not available) <input type="checkbox"/> (Not selected) <input checked="" type="checkbox"/> (Selected)
Cae03	Alarm 1 descr. (*)	Selection of first compressor alarm description: Rotation, Oil warning (line 1)	...	---	<input checked="" type="checkbox"/> (Not available) <input type="checkbox"/> (Not selected) <input checked="" type="checkbox"/> (Selected)
Cae04	Activ. delay	Activation delay for alarm 1 during operation (line 1)	0	s	0...999
	Startup delay	Activation delay for alarm 1 at startup (line 1)	0	s	0...999
	Reset	Type of reset for compressor alarm 1 (line 1)	automatic	---	automatic manual
	Priority	Type of priority for compressor alarm 1 (line 1)	serious	---	Normal Serious
	---	---	---	---	---
Cae24	High suction pressure/temperature alarm	Type of high suction pressure/temperature alarm threshold	absolute	---	absolute relative
	Threshold	High suction pressure/temperature alarm threshold	... (**) (**)
	Differen.	High suction pressure/temperature alarm differential	... (**) (**)
	Delay:	High suction pressure/temperature alarm delay	120	s	0...999
Cae26	Low suction pressure/temperature alarm	Type of low suction pressure/temperature alarm	absolute	---	absolute relative
	Threshold	Low suction pressure/temperature alarm threshold	... (**) (**)
	Differen.	Low suction pressure/temperature alarm differential	... (**) (**)
	Delay	Low suction pressure/temperature alarm delay	30	s	0...999
Cae28	Enable oil temp alarm mgmt. (*)	Enable Digital Scroll™ oil temperature alarm (line 1)	NO	---	NO YES
	Enable discharge temp alarm mgmt. (*)	Enable Digital Scroll™ discharge temperature alarm (line 1)	NO	---	NO YES
Cae29	Low superheat alarm threshold	Threshold for low superheat alarm (line 1)	3.0	K	0.0...99,9
	Differen.	Low superheat alarm differential (line 1)	1.0	K	0.0...9,9
	Switch OFF comp.	Enable compressor shutdown for low superheat alarm (line 1)	NO	---	NO YES
	Reset	Type of alarm reset for low superheat alarm (line 1)	manual	---	manual automatic
	Alarm delay	Low superheat alarm delay (line 1)	30	s	0...999
Cae31	Alarm setpoint	Discharge temperature alarm threshold	... (**) (**)
	Differential	Discharge temperature alarm differential	... (**) (**)
	Switch off compressor with alarm	Enable shutdown of compressors with discharge temperature alarm	disabled	---	Disabled abled
Cae40	Comp 1 off	Enable shutdown of compressor 1 for compressor warning inverter (line 1)	NO	---	NO YES
	Reset	Type of reset for compressor warning inverter (line 1)	manual	---	manual automatic
	Alarm delay	Delay for compressor warning inverter (line 1)	0	s	0...999
Caf02	Compressor type	Type of compressors (line 1)	Reciproc.	---	Reciprocating scroll
Caf03	Number of compressors	Number of compressors (line 1)	2/3 (*)	---	1...6 12 (*)
	Cmp1,...	Enable compressors (line 1)	abled	---	Disabled abled
Caf04	Refrigerant type	Type of refrigerant (suction line 1)	R744	---	R22 R134a R404A R407C R410A R507A R290 R600 R600a R717 R744 R728 R1270 R417A R422D R413A R422A R423A R407A R427A R245Fa R407F R32
Caf05	Min.time on	Minimum compressor on time (line 1)	30	s	0...999
	Min.time off	Minimum compressor off time (line 1)	120	s	0...999
	Minimum time to start same comp.	Minimum time between starts of same compressor (line 1)	360	s	0...999
Caf06	Startup	Type of compressor startup	direct	---	Direct Part winding Star delta
Caf07	Star time	Star relay run time	0	ms	0...9999
	Star delay/line	Delay between star and line relay	0	ms	0...9999
	Star delta delay	Delay between star and delta relay	0	ms	0...9999
Caf08	Partwinding delay	Partwinding delay	0	ms	0...9999
Caf09	Equalization	Enable compressor equalization at startup	NO	---	NO YES
	Equal. time	Equalization duration	0	s	0...999
Caf10	Device rotation type	Type of rotation	FIFO	---	---
					FIFO LIFO TIME CUSTOM
Caf11	Device sequence	Unloader sequence in relation to compressor activation (C=compressor, P=unloader)	CpppCppp	---	---
					CCpppppp CpppCppp


Mask index	Display description	Description	Def.	U. of M.	Values
Caf12	Load up time	Delay between different compressor starts	10	s	0...999
	Shutdown time	Delay between different compressor shutdowns	0	s	0...999
	Unloader delay	Delay between stages	0	s	0...999
Caf13	Custom rotation on order	Order of startup for compressor custom rotation	1	---	1...16
Caf14	Custom rotation off	Order of shutdown for compressor custom rotation	1	---	1...16
Caf15	Modulation device	Compressor modulating device type (line 1)	None	---	None Inverter Digital scroll
Caf16	Min frequency	Minimum inverter frequency	30	Hz	0...150
	Max frequency	Maximum inverter frequency	60	Hz	0...150
Caf17	Min.time on	Minimum time compressor controlled by inverter on (line 1)	30	s	0...999
	Min.time off	Minimum time compressor controlled by inverter off (line 1)	60	s	0...999
	Minimum time to start same comp.	Minimum time compressor controlled by inverter startup (line 1)	180	s	0...999
Caf18	Digital comp. valve regulation	Digital Scroll™ compressor valve control type (line 1)	Optimized regulation	---	Optimized regulat. Variable cycle time Fixed cycle time
Caf19	Cycle time	Cycle time (line 1)	13	s	12...20
	Oil dilution	Enable Digital Scroll™ oil temperature alarm (line 1)	enable	---	disable enable
	Discharge temp	Enable Digital Scroll™ discharge temperature alarm (line 1)	enable	---	disable enable
...
Caf90	Different sizes	Enable compressors of different sizes (line 1)	NO	---	NO YES
...	Different number of valves	Enable compressor partialization (line 1)	NO	---	NO YES
Caf91	S1	Enable size and size for compressor group 1 (line 1)	YES'	---	NO YES
	10.0	kW	0.0...500.0
...
...	S4	Enable size and size for compressor group 4 (line 1)	NO	---	NO YES
...	kW	0.0...500.0
Caf92	S1	Enable stages and stages for compressor group 1 (line 1)	YES'	---	NO YES
...	100	%	100 50 100 50 75 100 25 50 75 100 33 66 100
...	---	...
...	S4	Enable stages and stages for compressor group 4 (line 1)	NO	---	NO YES
...	---	kW	S1...S4
Caf93	C01	Size group for compressor 1 (line 1) or presence of inverter (line 1)	S1	---	S1...S4 INV
...	---	...
...	C12	Size group for compressor 6 (line 1)	S1	---	S1...S4
Caf95	Min.time on	Minimum time on for Digital Scroll™ compressor (line 1)	60	s	0...999
	Min.time off	Minimum time off for Digital Scroll™ compressor (line 1)	180	s	0...999
	Minimum time to start same comp.	Minimum time between startups for Digital Scroll™ compressor (line 1)	360	s	0...999
...	Reactivate startup procedure after	Time for reactivation of startup procedure for Digital Scroll™ compressor (line 1)	480	min	0...9999
Cag01	Minimum voltage	Voltage corresponding to the minimum capacity of the inverter (line 1)	0.0	V	0.0...10.0
	Maximum voltage	Voltage corresponding to the maximum capacity of the inverter (line 1)	10.0	V	0.0...10.0
	Nominal freq.	Nominal frequency (frequency at nominal capacity) (line 1)	50	Hz	0...150
...	Nominal power	Nominal capacity for compressor managed by inverter at nominal frequency (line 1)	10.0	kW	0.0...500.0
Cag02	Rising time	Time to pass from minimum to maximum capacity for modulating device (line 1)	90	s	0...600
	Falling time	Time to pass from maximum to minimum capacity for modulating device (line 1)	30	s	0...600
Cag03	Enable compressor modul. in dead zone	Enable compressor 1 modulation inside dead zone (line 1)	AB	---	Disabled abled
Cag04	Enable suction press.backup probe	Enable screens for the configuration of the suction pressure backup probe (line 1)	NO	---	NO YES
Cag05	Request in case of regulation probe fault	Compressor forcing value in case of suction probe fault (line 1)	50.0	%	0.0...100.0
...	Pumpdown	Enable pumpdown function (line 1)	Disabled	---	disabled abled
...	Threshold	Pumpdown end threshold (line 1)	1.5 barg	---	... (**)
Cag06	Enable anti return of liquid	Enable liquid non return function (line 1)	NO	---	NO YES
...	Delay	Delay liquid non return function (line 1)	0	min	0...15

The following parameters refer to line 2, for details, see the corresponding parameters for line 1 above

Cba01	DI	Alarm 1 compressor 1 DI position (line 2)	03	---	--- 01...18 U1...U10 (***)
	Status (display only)	Status Alarm 1 compressor 1 DI (line 2)	---	---	closed open
	Logic	Logic alarm 1 compressor 1 DI (line 2)	NC	---	NC NO
	Function (display only)	Alarm 1 compressor 1 function status (line 2)	---	---	not active active
...
Cbb01	Regulation	Compressor control by temperature or pressure (line 2)	pressure	---	pressure temperature
	Reg. Type	Compressor regulation type (line 2)	dead zone	---	Proportion. band dead zone
...
Cbc01	Compressor 1 operating hours	Compressor 1 operating hours (line 2)	---	---	0...999999
...	---	...
Cbd01	Enable suction setpoint compensation	Enable setpoint compensation (suction line 2)	NO	---	NO YES
...	---	...
Cbe01	Number of alarms for each compressor	Number of alarms for each compressor (line 2)	1	---	0...4
...	---	...
Cbf02	Compressor type	Type of compressors (line 2)	Reciproc.	---	Reciprocating scroll
	Number of compressors	Number of compressors (line 2)	2/3 (*)	---	1...12
...	---	...
Cbg01	Minimum voltage	Voltage corresponding to the minimum capacity of the inverter (line 2)	0.0	Hz	0.0...10.0
	Maximum voltage	Voltage corresponding to the maximum capacity of the inverter (line 2)	10.0	Hz	0.0...10.0
	Nominal freq.	Nominal frequency (frequency at nominal capacity) (line 2)	50	Hz	0...150
	Nominal power	Nominal capacity for compressor managed by inverter at nominal frequency (line 2)	10.0	Kw	0.0...500.0
...	---	...
Cca02	RPRV opening	Flash gas valve opening percentage to enable parallel line activation	30	%	0...100
	Delay	Evaluation time for activation of parallel line from when reaching the set flash valve opening	10	s	...
	Min g.c. temp	Activation threshold relative to gas cooler outlet temperature	25°C	°C/°F	...
	Tgc off thr	Parallel compression or parallel compressor line deactivation threshold relative to gas cooler outlet temperature	15°C	°C/°F	...

Mask index	Display description	Description	Def.	U. of M.	Values
Cca03	RPRV offset with par. comp. on	Offset applied to receiver pressure set point when at least one parallel compressor is active	2.0 barg	barg/psig	...
	Par. Comp. ON rising time RPRV	Time needed to add the offset to the receiver pressure set point	0	s	...
	Par. Comp. OFF falling time RPRV	Time needed to subtract the offset from the receiver pressure set point	20	s	...
Cca04	Setpoint	Set point for proportional control of integrated parallel compressor on the main board	35 barg	barg/psig	
	Prop gain	Proportional gain for proportional control of integrated parallel compressor on the main board	10	%	0...100
	Ti	Integral time for proportional control of integrated parallel compressor on the main board	30	s	...
	Td	Derivative time for proportional control of integrated parallel compressor on the main board	0	s	...
Cca05	Min.time on	Minimum integrated parallel compressor ON time	30	s	0...999
	Min.time off	Minimum integrated parallel compressor OFF time	120	s	0...999
	Min.time on same compr.	Minimum time between starts of same integrated parallel compressor	360	s	0...999
Cca06	Minimum voltage	Voltage corresponding to minimum power of the integrated parallel compressor inverter	0.0	V	0.0...10.0
	Maximum voltage	Voltage corresponding to maximum power of the integrated parallel compressor inverter	10.0	V	0.0...10.0
	Nominal freq.	Minimum integrated parallel compressor inverter frequency	30	Hz	0...150
	Nominal power	Maximum integrated parallel compressor inverter frequency	60	Hz	0...150
Cca07	Nominal freq.	Nominal frequency (frequency at nominal power) of the integrated parallel compressor	50	Hz	0...150
	Rising time	Time to move from integrated parallel compressor modulating device minimum to maximum power	20	s	0...600
	Falling time	Time to move from integrated parallel compressor modulating device maximum to minimum power	20	s	0...600
Cca11	Delay	Integrated parallel compressor generic alarm activation delay	0	s	0...999
	Delay at start	Integrated parallel compressor generic alarm activation delay at start-up	0	s	0...999
	Reset	Type of integrated parallel compressor generic alarm reset	automatic	...	automatic manual
	Priority		light	...	light serious
Cca12	DI	Integrated parallel compressor generic alarm DI input position	---	---	01...18, U1...U10 closed open
	Status	Integrated parallel compressor generic alarm DI status	---	---	closed open
	Logic	Integrated parallel compressor generic alarm DI logic	NC	---	NC NO
	Function	Integrated parallel compressor generic alarm function status	---	---	not active active
Eia14	Comp. Par. disch. Temp	Integrated parallel compressor discharge temperature	---	---	U1...U10
Cca08	Threshold	High discharge temperature alarm activation threshold for the integrated parallel compressor	120°C	°C/°F	---
	Different.	High discharge temperature alarm activation differential for the integrated parallel compressor	5°C	°C/°F	---
	Delay	High discharge temperature alarm activation delay for the integrated parallel compressor	5	s	---
Cca13	DO relay line	DO position and display status (ON/OFF) for integrated parallel compressor	---	---	DO1...DO18
	Logic	DO logic of integrated parallel compressor power supply	NC	---	NC NO
Cca14	AO	Integrated parallel compressor modulating device AO position	---	---	01...06
	Status (display only)	Integrated parallel compressor modulating device AO value	0.0	%	0...100.0

Tab. 7.d

Mask index	Display description	Description	Def.	U. of M.	Values
 Condensers					
The I/Os depend on the configuration selected, the following are only examples. See Appendix A.1 for the complete list and position of available I/Os.					
Daa01	DI	Fan 1 overload DI position (line 1)	...	---	---, 01...18, U1...U10 (****)
	Status (display only)	Fan 1 overload DI status (line 1)	---	---	closed open
	Logic	Fan 1 overload DI logic (line 1)	NC	---	NC NO
	Function (display only)	Fan 1 overload function status (line 1)	---	---	not active active
Daa18	---	---	---	---	---
	---	Gas cooler backup probe position (line 1)	B1	---	---, U1...U10 (****)
	---	Gas cooler backup probe type (line 1)	4...20 mA	---	---
	---	---	---	---	0-1 V 0-10 V 4...20 mA 0-5 V
	---	(display only) Gas cooler backup pressure value	---	---	... (**)
	---	Max limit Gas cooler backup maximum pressure value (line 1)	30.0 barg	---	... (**)
	---	Min limit Gas cooler backup pressure minimum value (line 1)	0.0 barg	---	... (**)
---	Calibration Gas cooler backup pressure probe calibration (line 1)	0.0 barg	---	... (**)	
Daa21	DO	Fan 1 DO position (line 1)	03	---	--- 01...18 (****)
	Status (display only)	Status of fan 1 DO (line 1)	---	---	closed open
	Logic	Logic of fan 1 DO (line 1)	NC	---	NC NO
	Function (display only)	Fan 1 function status (line 1)	---	---	not active active
Daa38	AO	Inverter fan AO position (line 1)	0	---	---, 01...06 (****)
	Status (display only)	Inverter fan output value (line 1)	0	%	0.0...100.0
Dab01	Regulation	Condenser regulation by temperature or pressure (line 1) Note: with HPV valve management, only temperature regulation is enabled	temperat.	---	pressure temperature
	Regulation type	Condenser regulation Type (line 1)	proport. band	---	Proportion. band dead zone
Dab02	Minimum	Condenser setpoint lower limit (line 1)	... (**)	---	... (**)
	Maximum	Condenser setpoint upper limit (line 1)	... (**)	---	... (**)
Dab03	Setpoint	Condenser setpoint (line 1)	... (**)	---	... (**)
Dab04	Fans work if at least one compressor works	Enable fan operation linked to compressor operation	NO	---	NO YES
Dab05	Cut-off enable	Enable fan cut-off	NO	---	NO YES
	Cut-off request	Cut-off value	0.0	%	0.0...100.0
	Setpoint	Setpoint cut-off	... (**)	---	... (**)
	Diff.	Differential cut-off	... (**)	---	... (**)
	Hysteresis	Hysteresis cut-off	... (**)	---	... (**)
Dab6/ Dab8 (**)	Reg. Type	Proportional regulation type (condensing line 1)	proportion.	---	proportional proport.+integer
	Integral time	Integral time for proportional regulation (cond. line 1)	300	s	0...999
Dab7/ Dab9 (**)	Differential	Differential for proportional regulation (cond. line 1)	... (**)	---	... (**)
Dab10/Dab11 (**)	DZ diff.	Dead zone regulation differential (line 1)	... (**)	---	... (**)
	Activ.diff.	Dead zone regulation differential for device activation (line 1)	... (**)	---	... (**)
	Deact.diff.	Dead zone regulation differential for device deactivation (line 1)	... (**)	---	... (**)
Dab12/Dab13 (**)	En.force off	Enable capacity immediate decreasing to 0 (line 1)	NO	---	NO YES
	Setp. force off	Threshold for capacity decreasing to 0 (line 1)	... (**)	---	... (**)

Mask index	Display description	Description	Def.	U. of M.	Values
Dab14	Power to 100% min time	Minimum time to increase capacity request to 100%, dead zone regulation (condensing line 1)	15	s	0...9999
	Power to 100% max time	Maximum time to increase capacity request to 100%, dead zone regulation (condensing line 1)	90	s	0...9999
Dab15	Power reduction to 0% min time	Minimum time to decrease capacity request to 0%, dead zone regulation (condensing line 1)	30	s	0...9999
	Power reduction to 0% max time	Maximum time to decrease capacity request to 0%, dead zone regulation (condensing line 1)	180	s	0...9999
Dac	--	Not available	---	---	---
Dad01	Enable condensing setpoint compensation	Enable setpoint compensation (condensing line 1)	NO	---	NO YES
Dad02	Winter offset	Offset applied for the Winter period	0.0	...	-999.9...999.9
	Closing offset	Offset applied for closing period	0.0	...	-999.9...999.9
Dad03	Enable setpoint compensation by scheduler	Enable scheduler setpoint compensation (condensing line 1)	NO	---	NO YES
Dad04	TB1: --:-- -> --:--	Enabling and definition of time band 1: start hour and minute, end hour and minute (condensing line 1)	---

	TB4: --:-- -> --:--	Enabling and definition of time band 4: start hour and minute, end hour and minute (condensing line 1)	---
	Change	Time band change action	---	---	--- Save changes Load previous Clear all
	Copy to	Copy settings to other days	---	---	MONDAY...SUNDAY; MON-FRI; MON-SAT; SAT&SUN; ALL
Dad05	Enable floating gas cooler setpoint	Enable floating gas cooler setpoint (condensing line 1)	NO	---	NO YES
Dad06	Offset for external temp. Controlled by: -Dig. input	Setpoint variation for floating gas cooler setpoint (condensing line 1) Enable floating gas cooler setpoint by digital input	0.0 NO	... ---	-9.9...9.9 NO YES
Dad07	Change setpoint by digital input	Enable setpoint compensation by digital input (suct/cond line 1)	NO	---	NO YES
Dae01	Gas cooler high pressure alarm	Type of gas cooler high pressure alarm threshold (line 1)	absolute	---	absolute relative
	Delay	Gas cooler high pressure alarm delay (line 1)	60	s	0...999
Dae02/Dae06	Gas cooler high pressure alarm	Gas cooler high pressure alarm threshold (line 1)	24.0 barg(**)
	Differen.	Gas cooler high pressure alarm differential (line 1)	1.0 barg(**)
Dae03	Gas cooler low pressure alarm	Type of gas cooler low pressure alarm threshold (line 1)	absolute	---	absolute relative
	Delay	Gas cooler low pressure alarm delay (line 1)	30	s	0...999
Dae04/Dae07	Gas cooler low pressure alarm	Gas cooler low pressure alarm threshold (line 1)	7.0 barg(**)
	Differen.	Gas cooler low pressure alarm differential (line 1)	1.0 barg(**)
Dae05	Common fan overload	Enable common fan overload (line 1)	YES	---	NO YES
	Delay	Common fan alarm delay	0	s	0...500
	Reset	Common fan alarm reset type	automatic	---	automatic manual
Daf01	Number of fans	Number of fans (line 1)	3	---	0...16
Daf02	Fan1, Fan2, ...	Enable fan 1...12 (line 1)	AB	---	Disabled abled
Daf03	Fan13, Fan14, ...	Enable fan 13...16 (line 1)	AB	---	Disabled abled
Daf04	Refrigerant type	Type of refrigerant (condensing line 1)	R744	---	R22 R134a R404A R407C R410A R507A R290 R600 R600a R717 R744 R728 R1270 R417A R422D R413A R422A R423A R407A R427A R245Fa R407F R32
Daf05	Device rotation type	Type of rotation devices (condensing line 1)	FIFO	---	----- FIFO LIFO TEMPO CUSTOM
Daf07, Daf08	Custom rotation on order	On order for devices for custom rotation (condensing line 1)	1	---	1...16
Daf09, Daf10	Custom rotation off	Off order for devices for custom rotation (condensing line 1)	1	---	1...16
Dag01	Speed modul. device	Modulating condenser device type (line 1)	None	---	None Inverter Phase cut-off control
Dag02	Standby zone reg.	Fan modulation even in dead zone (line 1)	NO	---	NO YES
	Min out value	Minimum voltage for compressor inverter (line 1)	0.0	V	0.0...9.9
	Max out value	Maximum voltage for compressor inverter (line 1)	10.0	V	0.0...99.9
	Min. power ref.	Minimum capacity of fan modulating device (line 1)	60	%	0...100
	Max. power ref.	Maximum capacity of fan modulating device (line 1)	100	%	0...999
Dag03	Rising time	Time to pass from minimum to maximum capacity for fan modulating device (line 1)	1200	s	0...32000
	Falling time	Time to pass from maximum to minimum capacity for fan modulating device (line 1)	1200	s	0...32000
	Num. control. fans	Number of fans under inverter (only for alarm enabling)	1	---	0...16
Dag04	Split Condenser	Enable split condenser (line 1)	NO	---	NO YES
	Controlled by: -Digital input	Split condenser controlled by digital input (line 1)	---	---	NO YES
	-External temp	Split condenser controlled by external temperature (line 1)	---	---	NO YES
	-Scheduler	Split condenser controlled by scheduler (line 1)	---	---	NO YES
Dag05	Ext.Temp.Set.	Split condenser setpoint by external temperature (line 1)	10.0 °C	...	-99.9...99.9
	Ext.Temp.Diff.	Split condenser differential by external temperature (line 1)	2.5 °C	...	-99.9...99.9
Dag06	Type	Fans enabled with split condenser (line 1)	custom	---	Custom Odd Even Greater than Less than
	---	Only when enabling is GREATER THAN or LESS THAN the number of fans to consider (line 1)	0	---	0...16
Dag09	Disable split condenser as first stage of HP pressure switch for	Disable split condenser when high condensing pressure prevent occurs (line 1)	NO	---	NO YES
		Duration of split condenser deactivation for high pressure prevent (line 1)	0	h	0...24

Mask index	Display description	Description	Def.	U. of M.	Values
Dag10	Silencer	Enable silencer (line 1)	Disabled	---	Disabled Abled
	Max output	Maximum possible request when silencer is active (line 1)	75.0 %	%	0.0...100.0
	Controlled by: -Digital input -Scheduler	Silencer controlled by digital input (condensing line 1) Silencer controlled by scheduler (condensing line 1)	NO	---	NO YES
Dag12	Day of the week	Day of the week	---	---	LUN, ..., DOM
	TB1: --- -> ---	Enabling and definition of time band 1: start hour and minute, end hour and minute (condensing line 1)	---	---	---
	TB4: --- -> ---	Enabling and definition of time band 4: start hour and minute, end hour and minute (condensing line 1)	---	---	---
	Change	Time band change action	---	---	Save changes Load previous Clear all
Dag13	Speed up	Enable speed up (condensing line 1)	YES	---	NO YES
	Speed up time	Speed up time (condensing line 1)	5	s	0...60
Dag14	Ext.Temp.Mgmt	Enable speed up management by external temperature (condensing line 1)	Disabled	---	Disabled abled
	Ext.Temp.Set	Speed up management by external temperature threshold (condensing line 1)	25.0 °C	...	-99.9...99.9
	Diff. Ext.Temp.	Speed up management by external temperature differential (condensing line 1)	2.5 °C	...	-99.9...99.9
Dag15	Enable gas cooler press. backup probe	Enable screens for the configuration of the gas cooler pressure backup probe (condensing line 1)	NO	---	NO YES
Dag15	Request in case of regulation probe fault	Value of fan forcing in case of gas cooler probe error (line 1)	50.0	%	0.0...100.0

The following parameters refer to line 2, for details, see the corresponding parameters for line 1 above

Dba01	DI	Fan 1 overload DI position (line 2)	...	---	--- 01...18 U1...U10 (****)
	Status (display only)	Fan 1 overload DI status (line 2)	---	---	closed open
	Logic	Fan 1 overload DI logic (line 2)	NC	---	NC NO
	Function (display only)	Fan 1 overload function status (line 2)	---	---	not active active
Dba39	---	Intercooler pressure probe position (downstream)	---	---	U1...U10 (****)
	---	Intercooler pressure probe type (downstream)	4...20mA	---	--- 0-1V 0-10V 4...20mA 0-5V
	---	Intercooler pressure value (downstream)	---	---	... (**)
	Max limit	Maximum intercooler pressure value (downstream)	44.8 barg (**)
	Min limit	Minimum intercooler pressure value (downstream)	0.0 barg (**)
Dbb01	Regulation	Condenser regulation by temperature or pressure (line 2)	...	---	pressure / temper.
	Regulation type	Condenser regulation Type (line 2)	Proportion. band	---	proportional Band dead zone
Dbd01	Enable condensing setpoint compensation	Enable setpoint compensation (condensing line 2)	NO	---	NO YES
Dbe01	Cond.pressure high alarm	Condensing high pressure/temperature alarm threshold type (line 2)	absolute	---	absolute relative
	Delay	Condensing high pressure/temperature alarm delay (line 2)	60	s	0...999
Dbf01	Number of fans	Number of fans (line 2)	3	---	0...16
Dbg01	Modulate speed device	Modulating condenser device type (line 2)	None	---	None, Inverter Phase cut-off control
	---	---	---	---	---

Tab. 7.e

Mask index	Display description	Description	Def.	U. of M.	Values
------------	---------------------	-------------	------	----------	--------



E. Other functions

The I/Os depend on the configuration selected, the following are only examples. See Appendix A.1 for the complete list and position of available I/Os.

Eaaa04	---	Oil temperature probe position (line 1)	B1	---	--- U1...U10 (****)
	---	Oil temperature probe type (line 1)	4...20 mA	---	--- NTC PT1000 0...1 V 0...10 V 4...20 mA 0...5 V HT NTC
	---	Oil temperature value (line 1)	---	---	... (**)
	Max limit	Maximum oil temperature value (line 1)	30.0 barg (**)
	Min limit	Minimum oil temperature value (line 1)	0.0 barg (**)
Eaaa45	DO	Oil level valve compressor 6 DO position (line 1)	03	---	---, 01...18 (****)
	Status (display only)	Oil level valve compressor 6 DO status (line 1)	---	---	closed open
Eaab04	Logic	Oil level valve compressor 6 DO logic (line 1)	NC	---	NC NO
	Function (display only)	Oil level valve compressor 6 function status (line 1)	---	---	not active active
	Enable com.cool.	Enable common oil cooling (line 1)	YES	---	NO YES
Eaab05	Number of oil pumps	Number of oil pumps for common oil cooler (line 1)	0	---	0...1 (analog output) 0...2 (digital output)
	Enable pump out.	Enable AO of common oil cooler pump (line 1)	YES	---	NO (digital output) YES (analog output)
Eaab15	Enable cool.	Enable oil cooling compressors (line 1)	NO	---	NO YES
	Oil cool. off with comp. off	Oil cooling functioning only when compressor functioning	NO	---	NO YES
Eaab06	Setpoint	Common oil cooling setpoint (line 1)	0.0 °C	---	... (**)
	Differential	Common oil cooling differential (line 1)	0.0 °C	---	-9.9...9.9
Eaab07	Pump start delay	Pump 2 start delay after pump 1 startup (line 1)	0	s	0...999
Eaab08	Oil pump config	Oil pump output configuration: none, analog, digital	non conf.	---	not configurable analogic, digital
Eaab09	Setpoint	Oil temperature setpoint (line 1)	0.0	°C/°F	...
	Differential	Oil temperature differential (line 1)	0.0	°C/°F	...
	Duty on time	Fan startup time in case of oil probe error (line 1)	0	s	0...9999
	Duty off time	Fan shutdown time in case of oil probe error (line 1)	0	s	0...9999
Eaab09	Threshold	Common oil high temperature alarm threshold (line 1)	100.0 °C	°C/°F	...
	Differential	Common oil high temperature alarm differential (line 1)	10.0 °C	°C/°F	...
	Delay	Common oil high temperature alarm delay (line 1)	0	s	0...32767

Mask index	Display description	Description	Def.	U. of M.	Values
Eaab10	Enable oil lev.	Enable oil level management (line 1)	NO	---	NO YES
	Num. oil level alarms	Number of compressor alarms associated with the oil level (line 1)	0	---	0...4 7 (*)
Eaab11	Open time	Oil level valve opening time (line 1)	0	s	0...999
	Closing time	Oil level valve closing time (line 1)	0	s	0...999
	Puls. start delay	Delay for oil level valve pulsation at startup (line 1)	0	s	0...999
	Max. puls. time	Maximum pulsing time of the oil level valve (line 1)	0	s	0...999
Eaab12	Oil level controlled by	Type of oil level separator control: with minimum level only, with minimum and maximum level and with compressor status (line 1)	livello min.	---	liv.min. liv.min.&max comp. status
	Min.off valve	Minimum separator valve closing time (line 1)	0	s	0...999
	Min.lev. delay	Minimum oil level detection delay (line 1)	0	s	0...999
Eaab13	Ton Activ.	Valve opening time during oil level reset (line 1)	10	s	0...999
	Toff Activ.	Valve closing time during oil level reset (line 1)	0	s	0...999
	Ton Deact.	Valve opening time with correct oil level (line 1)	0	s	0...999
	Toff Deact.	Valve closing time with correct oil level (line 1)	10	min	0...999
Eaab14	Threshold	Oil separator differential pressure threshold (line 1)	1.0 barg(**)
	Differential	Oil separator differential pressure (line 1)	0.5 barg(**)
	Delay	Oil separator differential pressure delay (line 1)	0	s	0...99
Eaab16	Threshold	Oil cooler high temperature alarm threshold (line 1)	100.0 °C	°C/°F	...
	Differential	Oil cooler high temperature alarm differential (line 1)	10.0 °C	°C/°F	...
	Delay	Oil cooler high temperature alarm delay (line 1)	0	s	0 to 9999
Eaab20	Threshold	Oil cooler low temperature alarm threshold (line 1)	100.0 °C	°C/°F	...
	Differential	Oil cooler low temperature alarm differential (line 1)	10.0 °C	°C/°F	...
Ebaa01	Delay	Oil cooler low temperature alarm delay (line 1)	0	s	0 to 9999
	DO	Subcooling DO valve position (line 1)	---	---	---, 01...18 (****)
Ebab01	Status (display only)	Subcooling DO valve status (line 1)	---	---	closed open
	Logic	Subcooling DO valve logic (line 1)	NO	---	NC NO
	Function (display only)	Status of the subcooling valve function (line 1)	---	---	not active active
	Subcooling contr.	Enable subcooling function (line 1)	NO	---	NO YES
Eeaab25	---	Subcooling control type (line 1)	temp.	---	Temp. Cond&Liquid
	Threshold	Threshold for subcooling activation (line 1)	0.0 °C	---	Cond&Liqu. -9999.9...9999.9
	Subcooling (display only)	Subcooling value (line 1)	0.0 °C	---	-999.9...999.9
	Enable Oil Pres.diff management	Enable common differential oil management	NO	---	YES NO
	Manage oil press. with dedicated settings	With dedicated parallel compression board, select whether to use the same settings as the main board	NO	---	YES NO
	Manage oil press. with dedicated I/O	With dedicated parallel compression board, select whether to use the same inputs and outputs as the main board	NO	---	YES NO
	---	Common oil receiver pressure probe position (line 1)	---	---	U1...U10 (****)
Ecaa01	---	Common oil receiver pressure probe type (line 1)	4...20mA	---	---, 0-1V - 0-10V- 4...20mA- 0-5V
	---	Common oil receiver pressure value (line 1)	---	---	...(**)
	Max limit	Maximum common oil receiver pressure value (line 1)	44.8 barg(**)
	Min limit	Minimum common oil receiver pressure value (line 1)	0.0 barg(**)
	Calibrat.	Common oil receiver pressure probe calibration (line 1)	0.0 barg(**)
	---	Discharge temperature probe position, compressor 1 (line 1)	B1	---	---, U1...U10 (****)
	---	Discharge temperature probe type, compressor 1 (line 1)	4...20mA	---	--- NTC PT1000 0..1 V 0..10 V 4...20 mA 0..5 V HTNTC
Ecaab12	---	Discharge temperature value, compressor 1 (line 1)	---	---	...(**)
	Max limit	Maximum discharge temperature value, compressor 1 (line 1)	30.0 barg(**)
	Min limit	Minimum discharge temperature value, compressor 1 (line 1)	0.0 barg(**)
	Calibrat.	Discharge temperature probe calibration, compressor 1 (line 1)	0.0 barg(**)
	---	Compressor 6 economizer valve DO position (line 1)	---	---	---, 01...18 (****)
	Status (display only)	Compressor 6 economizer valve DO status (line 1)	---	---	closed open
	Logic	Compressor 6 economizer valve DO logic (line 1)	NO	---	NC NO
Ecab04 (*)	Function (display only)	Compressor 6 economizer valve function status (line 1)	---	---	not active active
	Economizer	Enable economizer function (line 1)	NO	---	NO YES
	Comp.Power Thresh.	Capacity percentage threshold for economizer activation (line 1)	0	%	0...100
	Cond.Temp.Thresh.	Condensing temperature threshold for economizer activation (line 1)	0.0 °C	---	-999.9...999.9
Edaa01	Discharge Temp.Thresh.	Discharge temperature threshold for economizer activation (line 1)	0.0 °C	---	-999.9...999.9
	---	Discharge temperature probe position, compressor 1 (line 1)	B1	---	---, U1...U10 (****)
	---	Discharge temperature probe type, compressor 1 (line 1)	4...20mA	---	--- NTC PT1000 0..1 V 0..10 V 4...20 mA 0..5 V HTNTC
	---	Discharge temperature value, compressor 1 (line 1)	---	---	...(**)
	Max limit	Discharge temperature maximum value, compressor 1 (line 1)	30.0 barg(**)
	Min limit	Discharge temperature minimum value, compressor 1 (line 1)	0.0 barg(**)
	Calibration	Discharge temperature probe calibration, compressor 1 (line 1)	0.0 barg(**)
Edaa12	---	Compressor 6 injection valve DO position (line 1)	---	---	---, 01...18 (****)
	Status (display only)	Compressor 6 injection valve DO status (line 1)	---	---	closed open
	Logic	Compressor 6 injection valve DO logic (line 1)	NO	---	NC NO
	Function (display only)	Compressor 6 injection valve function status (line 1)	---	---	not active active
Edab01/Edab03 (*)	Liquid inj.	Enable liquid injection function (line 1)	Disabled	---	Disabled abled
	Threshold	Liquid injection setpoint (line 1)	70.0 °C	---	...(**)
	Differential	Liquid injection differential (line 1)	5.0	---	...(**)
Eeaa02	DI HR Enable/Activation	Digital input to activate heat reclaim	...	---	---, 01...18, U1... U10 (****)
	Status	Status HR DI (display only)	...	---	Open Closed
	Logic	Logic HR DI	No	---	NC No
	Function (display only)	Function Status HR DI	...	---	Not active Active
	AI HR ext. signal: Probe Type	AI HR ext. Signal (HR request)	...	%	---, U1...U10 (****)
Eeaa05	Ext. Signal Value	Heat reclaim Ext. Signal Value	...	%	...(**)
	Upper Value:	Upper Value HR ext. Signal	100%	%	0.0...100.0
	Lower Value:	Lower Value HR ext. Signal	0%	%	0.0...100.0
	Calibration:	Calibration HR ext. Signal	0%	%	0.0...100.0
	DO Heat Reclaim out position:	DO Heat Reclaim out position	...	---	--- 01...18 (****)
	Status (display only)	Status HR DO (display only)	...	---	Open Closed
Eeaa09	Logic:	Logic HR DO:	NO	---	NC NO
	Function (display only)	Function HR DO (display only)	Active	---	Not active Active
	AO Heat Reclaim water pump:	AO Heat Reclaim water pump:	0	---	--- 01...06 (****)
	Status:	Status HR AO (display only)	...	%	...

Mask index	Display description	Description	Def.	U. of M.	Values
Eeab01	Enable heat reclaim 1:	Enable heat reclaim 1	No		YES NO
	Enable heat reclaim 2:	Enable heat reclaim 2	No		YES NO
	Consider contribution for tot. req.:	Composition of total request	HR1 only		None Solo RC1 Solo RC2 RCI+RC2
Eeab02	Gas Cooler Pressure lower limit	Gas cooler lower limit admitted to activate heat reclaim	40.0	barg	
	Min toff betw. 2 activ. Heat reclaim 1:	Minimum time off between 2 activations Heat reclaim 1	30	min	
	Min toff betw. 2 activ. Heat reclaim 2:	Minimum time off between 2 activations Heat reclaim 2	30	min	
Eeab04	Disable floating cond. By heat reclaim:	Disable floating condensing by heat reclaim	No		YES NO
Eeab05	Enable activation by scheduler:	Enable heat reclaim activation by scheduler	No		YES NO
	Activation independent from the closing:	Activation independent from the closing	No		YES NO
Eeab07	HR1 Regulation type:	Different type of regulation of first heat reclaim	Temperat.		External Signal Temperature Digital Input
	Setpoint	Setpoint if HR1 is regulated by temperature	55	°C/°F	
	Kp:	Kp if HR1 is regulated by temperature	1	%/°C	
	Integral time:	Integral time if HR1 is regulated by temperature	200	s	
Eeab08	HR1 Valve type:	Type of valve of first heat reclaim	ON/OFF		ON OFF 0 10V
	Activation thr.:	Threshold to activate valve output HR1	10.0	%	
	De-activat thr.:	Threshold to de-activate valve output HR1	5.0	%	
	Activation delay:	Delay to activate valve output HR1	30	s	
	En. Pump:	Enable pump of first heat reclaim	No		YES NO
Eeab09	Pump type:	Selection of pump type of first heat reclaim			Modulating ON OFF
	Pump delay off:	Delay to switch off pump HR1	0	s	
Eeab10	Pump regulation type:	Different type of pump regulation of first heat reclaim	HR request		HR request Diff temperature
	On threshold:	Threshold to activate pump output HR1	5.0	%	
	Off threshold:	Threshold to deactivate pump output HR1	0.0	%	
Eeab11	Pump Management Setpoint:	Setpoint if HR1 pump is regulated by temperature	55	°C/°F	
	Kp:	Kp if HR1 pump is regulated by temperature	1	%/°C	
	Integral time:	Integral time if HR1 pump is regulated by temperature	120	s	
Eeab13	HR1 enable HR probe temp. Filter:	Enable multiple measurements of temperature probe	No		YES NO
	Number of samples	Number of samples			1...200
Eeab14	Max. water temp. Alarm thresh:	Maximum water temperature Alarm threshold	85	°C/°F	
	Differential:	Differential for maximum water temperature Alarm threshold	5	°C/°F	
Eeab15	HR2 Regulation type:	Different type of regulation of first heat reclaim	Temperat.		External Signal Temperature Digital Input
	Setpoint	Setpoint if HR2 is regulated by temperature	40	°C/°F	
	Kp:	Kp if HR2 is regulated by temperature	1	%/°C	
	Integral time:	Integral time if HR2 is regulated by temperature	200	s	
Eeab16	HR2 Valve type:	Type of valve of first heat reclaim	ON/OFF		ON OFF 0 10V
	Activation thr.:	Threshold to activate valve output HR2	10.0	%	
	De-activat thr.:	Threshold to de-activate valve output HR2	5.0	%	
	Activation delay:	Delay to activate valve output HR2	30	s	
	En. Pump:	Enable pump of first heat reclaim	No		YES NO
Eeab17	Pump type:	Selection of pump type of first heat reclaim			Modul. ON OFF
	Pump delay off:	Delay to switch off pump HR2	0	s	
Eeab18	Pump regulation type:	Different type of pump regulation of first heat reclaim	HR request		HR request Diff temperature
	On threshold:	Threshold to activate pump output HR2	5.0	%	
	Off threshold:	Threshold to de-activate pump output HR2	0.0	%	
Eeab19	Pump Management Setpoint:	Setpoint if HR2 pump is regulated by temperature	55	°C/°F	
	Kp:	Kp if HR2 pump is regulated by temperature	1	%/°C	
	Integral time:	Integral time if HR2 pump is regulated by temperature	120	s	
Eeab20	HR2 enable HR probe temp. Filter:	Enable multiple measurements of temperature probe	No		YES NO
	Number of sample	Number of samples			1...200
Eeab21	Maximum water temp. Alarm thresh:	Maximum water temperature Alarm threshold	85	°C/°F	
	Differential:	Differential for maximum water temperature Alarm threshold	5	°C/°F	
Eeab25	Actions on HPV valve and gas cooler fans setpoints done in:	Type of HPV setpoint increment	Simultan. Mode		Simultaneous Sequential mode with Threasold
	Wait. Time to act:	Delay to start HPV setpoint increment	120	s	
Eeab26	En. GasCool.bypass:	Enable Gas Cooler bypass	No		YES NO
	Gas cooler bypass 3way valve type:	Gas cooler bypass 3way valve type	0/10	V	0 10 ON OFF
	Valve Mode	Bypass valve mode	ON/OFF		Modulating ON OFF
	Eval. Time to byp.:	Evaluation time to start GC bypass	30	s	
Eeab28	Max receiver press. To allow byp.:	Max receiver pressure to allow bypass	60.0	barg	
	HPV valve modul. Setp.min%:	Min. HPV setpoint with heat reclaim total request upper setted threshold	75.0	barg	
	HPV valve modul. Setp.100%:	Max. HPV setpoint with heat reclaim total request equal to 100%	85.0	barg	
	Time to min setp.:	Time to reach minimum setpoint	60	s	
	Incr. Step:	Value of incremental step between setpoint min& e setpoint 100%	0.5	barg	
	Wait time:	Time each step	60	s	
	Gas cool. Fans modul. Step:	Value of GC incremental step	1.0	°C/°F	
Eeab29	Gas cool. Fans modul. Wait time:	Time each step	60	s	
	Gas cool. Fans modul. Max offset:	GC maximum offset	5.0	°C/°F	
	Gas cool. Fans modul. Min. HR request:	Minimum HR total request to start GC action	30.0	%	
	Gas cool. Fans modul. Diff. OFF:	Differential to decrease GC action	5.0	%	
	Max decrease time of HPV offset:	Time to decrease total HPV offset	240	s	
Eeab30	Max decrease time of GC offset:	Time to decrease total GC offset	120	s	
	Max t.close byp.:	Time to close bypass valve	120	s	

Mask index	Display description	Description	Def.	U. of M.	Values
Efa05	Min.HR request:	Enable generic stage function 1	30.0	%	
	Diff.OFF:	...	5.0	%	
	JAN.funct.5	Enable generic stage function 5	disable	---	disable enable
Efa06	Regulation variable	Regulation variable for stage 1 generic function	---	---	...
	Mode	Direct or reverse regulation	direct	---	direct Reverse
Efa07	Enable	Enabling variable for stage 1 generic function	---	---	...
	Description	Enable description change	skip	---	skip change
Efa08	Setpoint	Setpoint stage 1 generic function	0.0 °C (**)
	Differential	Stage 1 generic function differential	0.0 °C (**)
Efa09	High alarm	High alarm enabling for stage 1 generic function	disable	---	disable enable
	High alarm	High alarm threshold for stage 1 generic function	0.0 °C (**)
	Delay	High alarm delay for stage 1 generic function	0	s	0...9999
	Alarm type	High alarm type for stage 1 generic function	Normal	---	Normal Serious
	Low alarm	Low alarm enabling for stage 1 generic function	disable	---	disable enable
	Low alarm	Low alarm threshold for stage 1 generic function	0.0 °C (**)
	Delay	Low alarm delay for stage 1 generic function	0	s	0...9999
	Alarm type	Low alarm type for stage 1 generic function	Normal	---	Normal Serious
	---	...
	---	...
Efb05	JAN.modulat.1	Enable generic modulating function 1 management	disable	---	disable enable
	JAN.modulat.2	Enable generic modulating function 2 management	disable	---	disable enable
Efb06	Regulation variable	Regulation variable for generic modulating function 1	---	---	...
	Mode	Direct or reverse regulation	direct	---	Direct Reverse
Efb07	Enable	Enabling variable for generic modulating function 1	---	---	...
	Description	Enable description change	Skip	---	skip change
Efb08	Setpoint	Setpoint for generic modulating function 1	0.0 °C (**)
	Differential	Differential for generic modulating function 1	0.0 °C (**)
Efb09	High alarm	High alarm enabling for generic modulating function 1	disable	---	disable enable
	High alarm	High alarm threshold for generic modulating function 1	0.0 °C (**)
	Delay	High alarm delay for generic modulating function 1	0	s	0...9999
	Alarm type	Low alarm type for generic modulating function 1	Normal	---	Normal Serious
Efb20	Low alarm	Low alarm enabling for stage 1 generic function	Disable	---	disable Enable
	Low alarm	Low alarm threshold for stage 1 generic function	0.0 °C (**)
	Delay	Low alarm delay for stage 1 generic function	0	s	0...9999
	Alarm type	Low alarm type for stage 1 generic function	Normal	---	Normal Serious
Efb10	Out upper limit	Output upper limit for generic modulating function 1	100.0	%	0...100
	Out lower limit	Output lower limit for generic modulating function 1	0.0	%	0...100
	Cut-off enable	Enable cut-off function for generic modulating function 1	NO	---	NO YES
	Cutoff Diff	Cut-off differential for generic modulating function 1	0.0 °C (**)
	Cutoff hys.	Cut-off hysteresis for generic modulating function 1	0.0 °C (**)
Efb15	---	...
	Out upper limit	Output upper limit for generic modulating function 1	100.0	%	0...100
	Out lower limit	Output lower limit for generic modulating function 1	0.0	%	0...100
	Cut-off enable	Enable cut-off function for generic modulating function 1	NO	---	NO YES
	Cutoff Diff	Cut-off differential for generic modulating function 1	0.0 °C (**)
Efc05	---	...
	JAN Alarm 1	Enable generic alarm function 1	disable	---	disable Enable
	JAN Alarm 2	Enable generic alarm function 2	disable	---	disable Enable
	Regulation variable	Monitored variable for generic alarm function 1	---	---	...
	Enable	Enabling variable for generic alarm function 1	---	---	...
Efc06	Description	Enable description change	Salta	---	skip Change
	Description	Description	---	---	...
	Alarm type	Priority type for generic alarm function 1	Normal	---	Normal Serious
Efc07	Delay	Delay for generic alarm function 1	0	s	0...9999
	---	...
Efd05	Enable generic scheduler funct.	Enable generic scheduler function	...	---	disable enable
	JAN. scheduling connected to common scheduler	Generic scheduler with the same days and special periods	NO	---	NO YES
	---	...
Efd06	Enable	Enabling variable for generic scheduler function	---	---	...
Efd07	TB1: --- -> ---	Enabling and definition of time band 1: start hour and minute, end hour and minute (suction line 1)	---	---	...
	---	---	...
	TB4: --- -> ---	Enabling and definition of time band 4: start hour and minute, end hour and minute (suction line 1)	---	---	...
	Change	Time band change action	---	---	---, save changes load previous clear all
Efe05	JAN. A measure	Generic analog input A unit of measure selection	°C	---	°C °F barg psig % ppm
	---	...
Efe06/Efe07 (**)	...	Generic probe A position	B1	---	---, U1...U10 (****)
	---	Generic probe A type	4...20 mA	---	... (**)
	--- (display only)	Generic probe A value	---	---	... (**)
	Max limit	Generic probe A maximum limit	30.0 barg	---	... (**)
	Min limit	Generic probe A minimum limit	0.0 barg	---	... (**)
	Calibration	Generic probe A calibration	0.0 barg	---	... (**)
Efe21	---	...
	DO	Generic stage 1 DO position	---	---	---, 01...18 (****)
	Status (display only)	Status of generic stage 1 DO	---	---	closed open
	Logic	Logic of generic stage 1 DO	NO	---	NC NO
Efe29	Function (display only)	Generic stage 1 function status	---	---	not active active
	---	...
	Modulating1	Generic modulating 1 AO position	0	---	---, 01...06 (****)
	Status (display only)	Generic modulating 1 function output value	0	%	0.0...100.0
Egaa01	---	...
	DI	ChillBooster fault DI position (line 1)	---	---	---, 01...18, U1... U10 (****)
	Status	ChillBooster fault DI status (line 1)	---	---	closed open
	Logic	ChillBooster fault DI logic (line 1)	NC	---	NC NO
	Function	ChillBooster fault function status (line 1)	---	---	not active active
Egaa02	DO	ChillBooster fault DO position (line 1)	---	---	---, 01...18 (****)
	Status (display only)	ChillBooster fault DO status (line 1)	---	---	closed open
	Logic	ChillBooster fault DO logic (line 1)	NO	---	NC NO
	Function (display only)	ChillBooster function status (line 1)	---	---	not active active
Egab01	Device present	Enable ChillBooster function (line 1)	NO	---	NO YES
	Deactivation when fan power less than	Fan capacity under which the ChillBooster is deactivated (line 1)	95	%	0...100

Mask index	Display description	Description	Def.	U. of M.	Values
Egab02	Before activ. fans at max for	Min. time for fans at maximum capacity before ChillBooster activation (line 1)	5	min	0...300
	Ext.tempThresh	External temperature threshold for ChillBooster activation (line 1)	30.0 °C (**)
Egab03	Sanitary proc.	Enable sanitary procedure (line 1)	Disable	---	disable Enable
	Start	Sanitary procedure starting time (line 1)	00:00	---	...
	Duration	Sanitary procedure duration (line 1)	0	min	0...30
	Ext.tempThresh	External temperature threshold for sanitary procedure activation (line 1)	5.0 °C (**)
Egab04	Maint. req. Chillb. after	Tempo massimo funzionamento ChillBooster (linea 1)	200	h	0...999
	Maint time reset	Reset tempo funzionamento ChillBooster (linea 1)	NO	---	NO YES
Ehb01	Avoid simultaneous pulse between lines	Abilitazione inibizione spunti contemporanei compressori	NO	---	NO YES
	Delay	Ritardo tra partenze compressori linee diverse	0	s	0...999
Ehb03	Force3 off L2 comps for L1 fault	Abilitazione forzatura OFF compressori linea 2 per guasto compressori linea 1	NO	---	NO YES
	Delay	Ritardo forzatura OFF compressori linea 2 per guasto compressori linea 1	0	s	0...999
Ehb04	Activ. L1 comps for L2 activ.	Abilitazione forzatura ON compressori linea 1 per accensione compres. linea 2	NO	---	NO YES
	Delay	Ritardo forzatura ON compressori linea 1 per accensione compressori linea 2	30	s	0...999
Ehb05	Force off L2 comps for L1 off	Abilitazione forzatura OFF compressori linea 2 per off linea 1	NO	---	NO YES
	Enable minimum threshold for act. of L1	Enable line 1 activation for DSS only when the suction pressure is greater than a minimum threshold	NO	---	NO YES
	Threshold	Minimum threshold for line 1 activation for DSS	--- (**)
Ehb06	Enable pump down	Enable pump down with at least one LT compressor active	NO	---	NO YES
	Threshold	Pump down threshold	1.5 barg (**)
Eia01	---	RPRV tank pressure probe position	---	---	---, U1...U10 (****)
	---	RPRV tank pressure probe type	4...20 mA	---	... (**)
	---	RPRV tank pressure probe value	---	---	... (**)
	Max limit	RPRV tank pressure probe maximum value	60.0 barg (**)
	Min limit	RPRV tank pressure probe minimum value	0.0 barg (**)
	Calibration	RPRV tank pressure probe calibration	0.0 barg (**)
...
Eia04	DI	HPV alarm digital input position	---	---	---, 01...18, U1...U10 (****)
	Status	HPV alarm digital input status	---	---	closed open
	Logic	HPV alarm digital input logic	NC	---	NC NO
	Function	HPV alarm digital input status	---	---	not active active
...
Eia06	---	HPV valve analog output position	0	---	---, 01...06 (****)
	Status (display only)	HPV valve analog output value	0	%	0.0...100.0
...
Eia08	DO Line relay	DO position and On/Off Status Parallel compressor	---	---	---, 01...18 (****)
	Logic:	Logic Parallel Compressor DO:	NA	---	NC NA
...
Eia15	DI On/Off parall.compr.	Digital input on/off parallel compressor	---, 01...18, U1...U10 (****)
	Status	Status parallel compressor DI (display only)	---	---	Open Closed
	Logic	Logic parallel compressor DI	NA	---	NC NA
	Function (display only)	Function Status parallel compressor DI	---	---	Not active Active
...
Eib01	Enable HPV valve management	HPV valve management enabled, or transcritical operation mode enabled	NO	---	NO YES
	Algorithm selection	Selection of the algorithm-type to apply to the calculation of the pressure setpoint	optimiz.	---	optimiz. custom
Eib02	Min HPV vale opening when OFF	Minimum opening of the HPV valve with the unit OFF	0	%	0.0...100.0
	During ON	Minimum opening of the HPV valve with the unit ON	0	%	0.0...100.0
	Max HPV valve opening	Maximum opening of the HPV valve	0	%	0.0...100.0
	Max delta	Maximum variation per second allowed for the HPV valve output	0	%	0.0...100.0
Eib03	Pre-positioning	Opening of the HPV valve at start-up during pre-positioning	0	%	0.0...100.0
	Prepos. time	Pre-positioning duration	0	s	0...9999
Eib04	---	Calculation algorithm graph	---	---	---
Eib05 (Definition of the points on the graph, see mask Eib04)	P100%	P _{upper} upper pressure limit	109.0 barg (**)
	Pmax	P _{max} pressure for defining the upper proportional zone	104.0 barg (**)
	Pcritic	P _{critic} optimal pressure calculated at the passage temperature between the intermediate zone and transcritical zone	76.8 barg (**)
	T12	T ₁₂ limit temperature between the transcritical zone and intermediate zone	31.0 °C (**)
	T23	T ₂₃ temperature limit between the intermediate zone and subcritical zone	20.0 °C (**)
	Tmin	T _{min} temperature for defining the lower proportional zone	6.0 °C (**)
Eib06 (Definition of the points on the graph, see mask Eib04)	T100%	T _{100%} temperature for defining the complete opening zone of the valve	-10.0 °C (**)
	Delta	Subcooling for optimized regulation	3.0 °C (**)
	Coeff.1	Coefficient for determining the customized line	2.5	---	...999.9...999.9
Eib07	P1	Proportional gain for the proportional + integral regulation of the HPV valve	5 %/ barg	%/barg	0...100
	I1	Integral time for the proportional + integral regulation of the HPV valve	60	s	0...9999
	PHR	Prop. gain for the proportional + integral regulation of the HPV valve with heat recovery	5 %/ barg	%/barg	0...100
	IHR	Integral time for the proportional + integral regulation of the HPV valve with heat recovery	60	s	0...9999
Eib08	Enable HPV setpoint filter	Enabling of the filter action on the HPV valve setpoint	NO	---	NO YES
	Number of samples	Number of samples	5	---	0...99
Eib09	Enable mgmt of HPV with HR	Enabling of the various management of the HPV valve during heat recovery activation	NO	---	NO YES
	HR setp.	Setpoint regulation of the HPV valve during heat recovery	90.0 barg (**)
	Post HR Dt	Time scale for the setpoint reset procedure after heat recovery	0.1	s	0...999
	Post HR DP	Pressure scale for the setpoint reset procedure after heat recovery	1.0 barg (**)
Eib10	HPV valve safety position	HPV valve safety position	50.0	%	0.0...100.0
Eib11	Gas cooler temp delta with probe error	Offset to be applied to the external temperature in the event of gas cooler pressure probe error	0.0 °C (**)
Eib12	Enable HPV safeties from tank pressure	HPV valve safety procedure enabling	NO	---	NO YES
Eib13	High tank pressure threshold	High tank pressure threshold	40.0 barg (**)
	Max tank pressure	Maximum tank pressure allowed	45.0 barg (**)
	HPV set.incr.	Maximum offset to add to the HPV setpoint when the tank pressure exceeds the high pressure threshold	10.0 barg (**)
Eib14	Low tank pressure threshold	Low tank pressure threshold	32.0 barg (**)
	Min tank pressure	Minimum tank pressure allowed	27.0 barg (**)
	HPV set.decr.	Maximum offset to subtract from the HPV setpoint when the tank pressure goes below the low pressure threshold	10.0 barg (**)
Eib15	Force close with comp OFF	Enable HPV valve closure when all compressors on line 1 are off	NO	---	NO YES
	Delay clos. with comp. OFF	HPV valve closure delay when all compressors on line 1 are off	10	s	0...999
Eib16	Regul. in subcritical zone	Enabling the regulation of the gas cooler in the subcritical zone	NO	---	NO YES
Eib17	Enable	Enable warning func. when the gas cooler pressure is too far from the setpoint for the set time	NO	---	NO YES
	Delta	Difference between the gas cooler pressure and the setpoint which generates the warning	30.0 barg (**)
	Delay	Delay time before generating the warning	30	s	0...999
Eib18	Enable RPRV valve mgmt	Enable RPRV valve mgmt	NO	---	NO YES
Eib19	Min RPRV valve opening when ON	Minimum opening of the RPRV valve with the unit ON	10.0	%	0.0...100.0
	During OFF	Minimum opening of the RPRV valve with the unit OFF	10.0	%	0.0...100.0

Mask index	Display description	Description	Def.	U. of M.	Values
Eib20	Pre-positioning	Opening of the RPRV valve at start-up during pre-positioning	50.0	%	0.0...100.0
	Prepos. time	Pre-positioning duration	5	s	0...9999
Eib21	Max RPRV valve opening	Maximum opening of the RPRV valve	100.0	%	0.0...100.0
	Max delta	Maximum variation allowed for the HPV valve output	10.0	%	0.0...100.0
Eib22	CO2 rec. pressure setpoint	Regulation setpoint for the pressure for the CO2 receiver	35.0 barg (**)
	Gain	Proportional gain for the proportional + integral regulation of the RPRV valve	20 %/barg	%/barg	0...100
	Int time	Integral time for the proportional + integral regulation of the RPRV valve	60	s	0...9999
Eib23	RPRV valve safety position	RPRV valve safety position	50.0	%	0.0...100.0
Eib24	Force close with comp OFF	Enable RPRV valve closure when all compressors on line 1 are off	NO	---	NO YES
	Delay clos. with comp. OFF	RPRV valve closure delay when all compressors on line 1 are off	10	s	0...999
Eib25	Threshold	Receiver high pressure threshold alarm	45.0 barg (**)
	Diff.	Receiver high pressure differential alarm	5.0 barg (**)
	Delay	Receiver high pressure alarm delay	30	s	0...9999
	Reset	Receiver high pressure alarm reset type	manual	---	manual auto
	Switchoff comp.	Enable compressor shutdown when high pressure receiver alarm occurs	NO	---	NO YES
Eib27	Enable parallel compressor:	Enable parallel compressor	NO	---	YES NO
Eib28	RPRV opening:	RPRV opening to allow parallel compressor	30	%	
	Delay:	Delay on parallel compressor activation	10	s	0...999
	Min g.c.temp.:	Minimum GC temperature to allow parallel compressor	15	°C/°F	
Eib31	Receiver pressure threshold	Threshold pressure for the gas cooler when the Heat Reclaim is ON	---	---	---
	Time	Time during which this threshold remains active	---	---	---
	Var. delta	Allowed variation	---	---	---
Eib32	Max. HPV valve opening percentage	HPV valve maximum opening	0	%	0.0...100.0
	Max. delta	HPV valve maximum variation per second	0	%	0.0...100.0
Eib35	Min on time:	Parallel compressor by inverter, timings. Min on time	30	s	
	Min off time:	Parallel compressor by inverter, timings. Min off time	30	s	
	Min time to start same compressor:	Parallel compressor by inverter, timings. Min time to start same compressor	60	s	
Eib40	RPRV offset with par. comp. On:	Increment of RPRV setpoint during parallel compressor regulation	2	barg	
	Par. Comp. ON Rising time RPRV:	Rising time of RPRV setpoint	0	s	
	Par. Comp. Off Falling time RPRV:	Falling time of RPRV setpoint	20	s	
Eic01	HPV Valve	Enable EVS management of HPV valve	enable	---	enable disable
	RPPV Valve	Enable EVS management of HPV valve RPRV	enable	---	enable disable
	EVD address	Driver address managed in FBUS from pRack	198	---	0..207
	Valves routing	Valve type driver association	---	---	Single A->HPV Single A->RPRV Twin A->RPRV B->HPV Twin A->HPV B->RPRV
	EVD Status	Driver connection to pRack status	---	---	connected not connected
Eic02	HPV Valve type	HPV valve type	CAREL EXV	---	CAREL EXV, CUSTOM, Danfoss CCMT, Danfoss ICMETS (0-10V)
	RPRV Valve type	RPRV valve type	CAREL EXV	---	CAREL EXV, CUSTOM, Danfoss ETS 400, Danfoss ETS 250, Danfoss ETS 100B, Danfoss ETS 50B, Danfoss ETS 12.5-25B, Danfoss CCM 40 Danfoss CCM 10-20-30 Danfoss ICMETS (0-10V)
Eic03 (Valvola HPV)	Min. steps	Minimum valve step number	50	step	0...9999
	Max. steps	Maximum valve step number	480	step	0...9999
	closing steps	Valve closing steps	500	step	0...9999
	Nom. step rate	Valve nominal speed	50	step/s	1...2000
	Move current	Nominal current	450	mA	0...800
	Holding current	Holding current	100	mA	0...250
Eic04 (Valvola HPV)	Duty Cycle	Valve duty cycle	30	%	0...100
	Opening sincre	Opening position synchronization	YES	----	YES NO
	Closing sincre	Closing position synchronization	YES	----	YES NO
	Em. closing speed	Valve emergency closing speed	150	step/s	1...2000
Eic05 (Valvola RPRV)	Min. steps	Minimum valve step number	50	step	0...9999
	Max. steps	Maximum valve step number	480	step	0...9999
	closing steps	Valve closing steps	500	step	0...9999
	Nom. step rate	Valve nominal speed	50	step/s	1...2000
	Move current	Nominal current	450	mA	0...800
	Holding current	Holding current	100	mA	0...250
Eic06 (Valvola RPRV)	Duty Cycle	Valve duty cycle	30	%	0...100
	Opening sincre	Opening position synchronization	YES	----	YES NO
	Closing sincre	Closing position synchronization	YES	----	YES NO
	Em. closing speed	Valve emergency closing speed	150	step/s	1...2000

The following parameters refer to line 2, for details, see the corresponding parameters for line 1 above

Eaba04	---	Oil temperature probe position (line 2)	B1	---	---, U1...U10 (****)
	---	Oil temperature probe type (line 2)	4...20 mA	---	--- NTC PT1000 0...1 V 0...10 V 4...20 mA 0.5 V HTNTC
...	---	Oil temperature value (line 2)	---	---	... (**)
	---	Maximum oil temperature value (line 2)	30.0 barg	---	... (**)
	---	Minimum oil temperature value (line 2)	0.0 barg	---	... (**)
	---	Oil temperature probe calibration (line 2)	0.0 barg	---	... (**)
	---	---	---	---	---
Eabb04	Enable com.cool.	Enable common oil cooling (line 2)	YES	---	NO YES
	Number of oil pumps	Number of oil pumps for common oil cooler (line 2)	0	---	0...1 (analog. output) 0...2 (digital outputs)
	Enable pump out.	Enable AO of common oil cooler pump (line 2)	YES	---	NO (digital outputs) YES (analog. output)
Eeba01	---	---	---	---	---
	DO	Subcooling DO valve position (line 2)	---	---	---, 01...18 (****)
	Status (display only)	Subcooling DO valve status (line 2)	---	---	closed open
	Logic	Subcooling DO valve logic (line 2)	NO	---	NC NO
	Function (display only)	Status of the subcooling valve function (line 2)	---	---	not active active
---	---	---	---	---	

Mask index	Display description	Description	Def.	U. of M.	Values
Ebbb01	Subcooling contr.	Enable subcooling function (line 2)	NO	---	NO YES
	---	Subcooling control type (line 2)	Temp. Cond&Liqu.	---	Temp. Cond&Liquid only Liquid Temp.
	Threshold	Threshold for subcooling activation (line 2)	0.0 °C	---	-9999.9...9999.9
	Subcooling (display only)	Subcooling value (line 2)	0.0 °C	---	-999.9...999.9
Ecba01	---	---	---	---	---
	---	Discharge temperature probe position, compressor 1 (line 2)	B1	---	--- U1...U10 (****)
	---	Discharge temperature probe type, compressor 1 (line 2)	4...20 mA	---	--- NTC PT1000 0..1 V 0..10 V 4...20 mA 0..5 V HTNTC
	---	---	---	---	---
	---	Discharge temperature value, compressor 1 (line 2)	---	---	... (**)
	Max limit	Discharge temperature maximum value, compressor 1 (line 2)	30.0 barg	---	... (**)
	Min limit	Discharge temperature minimum value, compressor 1 (line 2)	0.0 barg	---	... (**)
	Calibration	Discharge temperature probe calibration, compressor 1 (line 2)	0.0 barg	---	... (**)
Ecbb04	---	---	---	---	---
	Economizer	Enable economizer function (line 2)	NO	---	NO YES
	Comp.Power Thresh.	Capacity percentage threshold for economizer activation (line 2)	0	%	0...100
	Cond.Temp.Thresh.	Condensing temperature threshold for economizer activation (line 2)	0.0 °C	---	-999.9...999.9
	Discharge Temp.Thresh.	Discharge temperature threshold for economizer activation (line 2)	0.0 °C	---	-999.9...999.9
Edba01	---	---	---	---	---
	---	Discharge temperature probe position, compressor 1 (line 2)	B1	---	---, U1...U10 (****)
	---	Discharge temperature probe type, compressor 1 (line 2)	4...20mA	---	--- NTC PT1000 0..1 V 0..10 V 4...20 mA 0..5 V HTNTC
	---	---	---	---	---
	---	Discharge temperature value, compressor 1 (line 2)	---	---	... (**)
	Max limit	Discharge temperature maximum value, compressor 1 (line 2)	30.0 barg	---	... (**)
	Min limit	Discharge temperature minimum value, compressor 1 (line 2)	0.0 barg	---	... (**)
	Calibration	Discharge temperature probe calibration, compressor 1 (line 2)	0.0 barg	---	... (**)
Edbb01	---	---	---	---	---
	Liquid inj.	Enable liquid injection function (line 2)	Disabled	---	Disabled abled
	Threshold	Liquid injection setpoint (line 2)	70.0 °C	---	... (**)
	Differential	Liquid injection differential (line 2)	5.0	---	... (**)
Eeba02	---	---	---	---	---
	DI	Heat recovery from digital input DI position (line 2)	---	---	---, 01...18, U1... U10 (****)
	Status	Heat recovery from digital input DI status (line 2)	---	---	closed open
	Logic	Heat recovery from digital input DI logic (line 2)	NC	---	NC NO
	Function	Heat recovery from digital input function status (line 2)	---	---	not active active
Eebb01	Enable heat rec.	Enable heat recovery function (line 2)	NO	---	NO YES
Egba01	---	---	---	---	---
	DI	ChillBooster fault DI position (line 2)	---	---	--- 01...18 U1...U10 (****)
	Status	ChillBooster fault DI status (line 2)	---	---	closed open
	Logic	ChillBooster fault DI logic (line 2)	NC	---	NC NO
	Function	ChillBooster fault function status (line 2)	---	---	not active active
Egbb01	---	---	---	---	---
	Device present	Enable ChillBooster function (line 2)	NO	---	NO YES
	Deactivation when fan power less than	Fan capacity under which the ChillBooster is deactivated (line 2)	95	%	0...100

Tab. 7.f


Mask index	Display description	Description	Def.	U. of M.	Values
F.settings					
Faaa01	Summer/Winter	Enable summer/winter management	NO	---	NO YES
	Special days	Enable special days management	NO	---	NO YES
	Closing per.	Enable closing period management	NO	---	NO YES
Faaa02	Start	Summer start date	---	---	01 JAN...31 DEC
	End	Summer end date	---	---	01 JAN...31 DEC
Faaa03	Day 1	Special day 1 date	---	---	01 JAN...31 DEC
	---	---	---	---	---
Faaa04	Day 10	Special day 10 date	---	---	01 JAN...31 DEC
Faaa05	P1	P1 closing period start date	---	---	01 JAN...31 DEC
	---	P1 closing period end date	---	---	01 JAN...31 DEC
	---	---	---	---	---
	P5	P5 closing period start date	---	---	01 JAN...31 DEC
	---	P5 closing period end date	---	---	01 JAN...31 DEC
Faab01	Date format	Date format	DD/MM/YY	---	DD MM YY MM DD YY YY MM DD
Faab02	Hour	Hour and minutes	---	---	---
Faab03	Date	Date	---	---	---
Faab04	Day (display only)	Day of the week calculated from the date	---	---	Monday... Sunday
Faab05	Daylight savings time	Enable daylight savings time	disable	---	disable enable
	Transition time	offset time	60	---	0...240
	Start	Daylight savings time starting week, day, month and time	---	---	---
	End	Daylight savings time ending week, day, month and time	---	---	---
Fb01	Language	Current language	english	---	---
Fb02	Disable language mask at startup	Disable the change language screen at startup	YES	---	NO YES
	Countdown	Starting value for countdown, time change language screen active	60	s	0...60
Fb03	Main mask selection	Main screen selection	Linea 1	---	Line 1 Line 2 Double suction Double cond.
Fb04	Probes Configuration	Enable main screen configuration in terms of probes and values displayed	don't configure	---	configure don't configure
	Info Configuration	Enable main screen configuration in terms of icons displayed	don't configure	---	configure don't configure
Fb05* *refers to double lines and GC configuration at the start-up	L1 - Suction	Suction pressure L1	L1 - Suction	barg	main probes available
	L2 - Suction	Suction pressure L2	L2 - Suction	barg	main probes available
	[Empty]	Free to display new value	[Empty]	---	main probes available
	GC out temp	Gas cooler outlet temperature	GC OUT temp	°C/°F	main probes available
	Gas cool.	Gas cooler pressure	Gas cool.	barg	main probes available
Fb09	I1% value	Activation status of first control value	L1 - Compr	%	main status available
	I2% value	Activation status of second control value	L2 - Compr	%	main status available
Fb10	I3% value	Activation status of first control value	L1 - Fans	%	main status available
	I4% value	Activation status of second control value	HPV	%	main status available

Mask index	Display description	Description	Def.	U. of M.	Values
Fca01	Address	Address of the supervisory system (line 1)	196	---	0...207
	Protocol	Supervisor communication protocol (line 1)	Carel slave local	---	---, CAREL SLAVE LOCAL, CAREL SLAVE REMOTE, MODBUS SLAVE pRACK MANAGER CAREL SLAVE GSM
Fd01	Baudrate	Supervisor communication speed (line 1)	19200	---	1200...19200
	Insert password	Password Current password level	0000 ---	---	0...9999 User Service Manufacturer
Fd02	Logout	Logout	NO	---	NO YES
Fd03	User	User password	0000	---	0...9999
	Service	Service password	1234	---	0...9999
	Manufacturer	Manufacturer password	1234	---	0...9999
Fda01	Enable CpCOe	Enable expansion card	NO	---	YES NO
	Offline pattern	Enable output configuration when offline	Disabled	---	Abled Disabled
	Digital Output pattern 1: ... 6	Digital output status when expansion card offline	OFF	---	ON OFF
Fda02	Universal Input pattern UI01..UI10	Analogue output status when expansion card offline	0	%	0...100

The following parameters refer to line 2, for details, see the corresponding parameters for line 1 above

Fcb01	Address	Address of the supervisory system (line 2)	196	---	0...207
	Protocol	Supervisor communication protocol (line 2)	pRack manager	---	---, CAREL SLAVE LOCAL, CAREL SLAVE REMOTE, MODBUS SLAVE pRACK MANAGER CAREL SLAVE GSM
	Baudrate	Supervisor communication speed (line 2)	19200	---	1200...19200


Tab. 7.g

Mask index	Display description	Description	Def.	U. of M.	Values
 G. Safeties					
Gba01	Enable prevent	Enable high pressure condensing prevent (line 1)	NO	---	NO YES
Gba02	Setpoint	High pressure condensing prevent threshold (line 1)	0.0 barg (**)
	Differential	High pressure condensing prevent differential (line 1)	0.0 barg	...	0...99.9
Gba03	Decrease compressor power time	Decreasing compressor capacity time (line 1)	0	s	0...999
	Enable heat recov. as first prevent step	Enabling heat recovery as first stage for condensing HP prevent (line 1)	NO	---	NO YES
Gba04	Offset HeatRecov	Offset between heat recovery and prevent setpoint (line 1)	0.0 barg	...	0.0...99.9
	Enable ChillB. as first prevent step	Enable ChillBooster as first stage for condensing HP prevent (line 1)	NO	---	NO YES
Gba05	Chill. offset	Offset between ChillBooster and prevent setpoint (line 1)	0.0 barg	...	0.0...99.9
	Max. num prevent	Max number of prevent before locking compressors (line 1)	3	---	1...5
Gca01	Prevent max number evaluation time	Prevent max number evaluation time	60	h	0...999
	Reset automatic prevent	Reset maximum number of prevent (line 1)	NO	---	NO YES
Gca02	Common HP type	Type of reset for common HP alarm (line 1)	AUTO	---	AUTO MAN
	Common HP delay	Common high pressure delay (line 1)	10	s	0...999
Gca03	Common LP start delay	Common low pressure delay at startup (line 1)	60	s	0...999
	Common LP delay	Common low pressure delay during operation (line 1)	20	s	0...999
Gca04	Time of semi-automatic alarm evaluation	Number of LP interventions evaluation time (line 1)	120	min	0...999
	Number of retries before alarm becomes manual (line 1)	Number of LP interventions in the period after which the alarm becomes a manual reset (line 1)	5	---	0...999
Gca05	Liquid alarm delay	Liquid level alarm delay (line 1)	0	s	0...999
	Oil alarm delay	Common oil alarm delay (line 1)	0	s	0...999
	Output relay alarm activation with	Selection of output relay alarm activation with active alarms or alarms not reset	alarms active		alarms active alarms no reset


The following parameters refer to line 2, for details, see the corresponding parameters for line 1 above

Gbb01	Enable prevent	Enable high pressure condensing prevent (line 2)	NO	---	NO YES
...	---	...
Gcb01	Common HP type	Type of reset for common HP alarm (line 2)	AUTO	---	AUTO MAN
	Common HP delay	Common high pressure delay (line 2)	10	s	0...999
...	---	...

Tab. 7.h

Mask index	Display description	Description	Def.	U. of M.	Values
 H. Info					
H01 (display only)	Ver.	Software version and date	...	---	...
	Bios	Bios version and date	...	---	...
	Boot	Boot version and date	...	---	...
H02 (display only)	Board type	Hardware type	...	---	...
	Size	Hardware size	...	---	...
	FLASH mem	Flash memory size	---	kB	...
	RAM	RAM memory size	---	kB	...
	Built-in type	Built-in display type	---	---	None pGDE
	Cycle time	Number of cycles per second and cycle time software	---	cicli/s / ms	...

Tab. 7.i

Mask index	Display description	Description	Def.	U. of M.	Values
 I. Setup					
lb01	Type of system	Type of system	Aspiraz + Condens.	---	Suction Condenser Suction + Condenser
lb02	Units of meas.	Units of measure	°C/barg	---	°C barg °F psig
lb03	Compressor type	Type of compressors (line 1)	Reciproc.	---	Reciprocating Scroll
	Number of compressors	Number of compressors (line 1)	2/3 (*)	---	1...6 12 (*)
lb04	Number of alarms for each compressor	Number of alarms for each compressor (line 1)	1	---	0...4 7 (*)

Mask index	Display description	Description	Def.	U. of M.	Values
lb05	Modulate speed device	Modulating device for first compressor (line 1)	None	---	None Inverter --- Digital scroll(*) --- Continuous (*)
lb30	Compress. size	Compressors sizes (line 1)	Same size & Same Partial.	---	Same size & Same Partial. Same size & different Partial. Define sizes
lb34	S1	Enable size and size for compressor group 1 (line 1)	YES 10.0	---	NO YES 0.0...500.0
	---	---	---	---	---
	S4	Enable size and size for compressor group 4 (line 1)	NO ---	---	NO YES 0.0...500.0
lb35	S1	Enable stages and stages for compressor group 1 (line 1)	YES 100	---	NO YES 100 50/100 50/75/100 25/50/75/100 33/66/100
	---	---	---	---	---
	S4	Enable stages and stages for compressor group 4 (line 1)	NO ---	---	NO YES S1...S4
lb36	C01	Size for compressor 1 or presence of inverter (line 1)	S1	---	S1...S4/INV
	---	---	---	---	---
	C12	Size for compressor 12 (line 1)	S1	---	S1...S4
lb11	Compress. size	Compressors sizes (line 1)	Same size	---	Same size Define sizes
lb16	S1	Enable size and size for compressor group 1 (line 1)	YES ---	---	NO YES 0.0...500.0
	---	---	---	---	---
	S4	Enable size and size for compressor group 4 (line 1)	NO ---	---	NO YES 0.0...500.0
---	---	---	---	---	---
lb17	C01	Size for compressor 1 or presence of inverter (line 1)	S1	---	S1...S4/INV
	---	---	---	---	---
	C06	Size for compressor 6 (line 1)	---	---	S1...S4
lb20	Compress. size	Compressors sizes (line 1)	Same size	---	Same size Define sizes
lb21	S1	Enable size and size for compressor group 1 (line 1)	YES ---	---	NO YES 0.0...500.0
	---	---	---	---	---
	S4	Enable size and size for compressor group 4 (line 1)	NO ---	---	NO YES 0.0...500.0
lb22	C01	Size for compressor 1 or presence of inverter (line 1)	S1	---	S1...S4/INV
	---	---	---	---	---
	C12	Size for compressor 12 (line 1)	S1	---	S1...S4
lb40	Regulation	Compressor control by temperature or pressure (line 1)	Pressure	---	Pressure Temper.
	Units of measure	Units of measure (line 1)	barq	---	---
	Refrigerant	Type of refrigerant (suction line 1)	R744	---	R22 R134a R404A R407C R410A R507A R290 R600 R600a R717 R744 R728 R1270 R417A R422D R413A R422A R423A R407A R427A R245Fa R407F R32
lb41	Regulation type	Compressor regulation type (line 1)	Dead zone	---	proportion. band Dead zone
	Enable integral time action	Enable integral time for proportional regulation of suction line (line 1)	NO	---	NO YES
lb42	Setpoint	Setpoint without compensation (suction line 1)	3,5 barg	---	...(**)
	Differential	Differential (suction line 1)	0,3 barg	---	...(**)
lb43	Configure another suction line	Second line configuration	NO	---	NO YES
lb45	Dedicated pRack board for suction line	Suction lines in different boards	NO	---	NO YES
lb50	Compressor type	Type of compressors (line 2)	Reciproc.	---	Reciprocating Scroll
	Number of compressors	Number of compressors (line 2)	3	---	1...12
lb51	Number of alarms for each compressor	Number of alarms for each compressor (line 2)	1	---	0...4
lb52	Modulate speed device	Modulating device for first compressor (line 2)	None	---	None Inverter --- Digital scroll(*)
lb70	Compress. size	Compressors sizes (line 1)	Same size & Same Partial.	---	Same size & Same Partial. Same size & different Partial. Define sizes
lb74	S1	Enable size and size for compressor group 1 (line 1)	YES ---	---	NO YES 0.0...500.0
	---	---	---	---	---
	S4	Enable size and size for compressor group 4 (line 1)	NO ---	---	NO YES 0.0...500.0
lb75	S1	Enable stages and stages for compressor group 1 (line 1)	YES 100	---	NO YES 100 50/100 50/75/100 25/50/75/100 33/66/100
	---	---	---	---	---
	S46	Enable stages and stages for compressor group 4 (line 1)	NO ---	---	NO YES S1...S4
lb76	C01	Size for compressor 1 or presence of inverter (line 1)	S1	---	S1...S4 INV
	---	---	---	---	---
	C12	Size for compressor 6 (line 1)	S1	---	S1...S4

Mask index	Display description	Description	Def.	U. of M.	Values
lb60	Compress. size	Compressors sizes (line 1)	Same size	---	Same size Define sizes
lb61	S1	Enable size and size for compressor group 1 (line 1)	YES [*]	---	NO YES
	---	kW	0.0...500.0
lb62	S4	Enable size and size for compressor group 4 (line 1)	NO	---	NO YES
	---	kW	0.0...500.0
lb80	C01	Size for compressor 1 or presence of inverter (line 1)	S1	---	S1...S4 INV
	---	---	---
lb80	C12	Size for compressor 6 (line 1)	S1	---	S1...S4
	Regulation	Compressor control by temperature or pressure (line 1)	Pressure	---	Pressure Temperature
lb81	Units of measure	Units of measure (line 1)	barq	---	---
	Refrigerant	Type of refrigerant (suction line 1)	R744	---	R22 R134a R404A R407C R410A R507A R290 R600 R600a R717 R744 R728 R1270 R417A R422D R413A R422A R423A R407A R427A R245Fa R407F R32
lb81	Regulation type	Compressor regulation type (line 1)	Dead zone	---	Proportion.band Dead zone
	Enable integral time action	Enable integral time for proportional regulation of suction line (line 2)	NO	---	NO YES
lb82	Setpoint	Setpoint without compensation (suction line 2)	3,5 barg	... (**)	... (**)
	Differential	Differential (suction line 2)	0,3 barg	... (**)	... (**)
lb90	Dedicated pRack board for cond. line	Suction and condensing lines on different boards, that is condensing line on dedicated board	NO	---	NO YES
lb91	Number of fans	Number of fans (line 1)	3	---	0...16
lb54	Modulate speed device	Fan modulating device (line 1)	None	---	None Inverter Contr. taglio di fase
lb93	Regulation	Fan regulation by pressure or temperature (line 1)	Pressure	---	Pressure Temperature
	Units of measure	Units of measure (line 1)	barq	---	---
lb93	Refrigerant	Type of refrigerant (condensing line 1)	R744	---	R22 R134a R404A R407C R410A R507A R290 R600 R600a R717 R744 R728 R1270 R417A R422D R413A R422A R423A R407A R427A R245Fa R407F R32
	Regulation type	Fan regulation type (line 1)	Banda proporz.	---	Banda proporz. Dead zone
lb94	Enable integral time action	Enable integral time for proportional regulation	NO	---	NO YES
	Setpoint	Setpoint without compensation (condens. line 1)	12,0 barg	... (**)	... (**)
lb95	Differential	Differential (condensing line 1)	2,0 barg	... (**)	... (**)
	Configure another condens. line	Configuration of a second condensing line	NO	---	NO YES
lb1a	Number of fans	Number of fans (line 2)	3	---	0...16
...	---	---	---
lb1e	Differential	Differential (condensing line 2)	2,0 barg	... (**)	... (**)
lc01	Type of system	Type of system	Aspiraz. + Conden.	---	Suction Condenser Aspiraz. + Conden.
lc02	Units of measure	Unit of measure	°C/barg	---	°C/barg °F/psig
lc03	Number of suction lines	Number of suction lines	1	---	0...2
lc04	Dedicated pRack board for suction line	Suction line in separate boards	NO	---	NO YES
lc05	Compressor type	Type of compressors (line 1)	Reciproc.	---	Reciprocating Scroll
	Number of compressors	Number of compressors (line 1)	4	---	1...6/12 (*)
lc06	Compressor type	Type of compressors (line 2)	Reciproc.	---	Reciprocating Scroll
	Number of compressors	Number of compressors (line 2)	0	---	1...6
lc07	Condenser line number	System condensing line number	1	---	0...2
lc08	Line 1	Number of fans (line 1)	4	---	0...16
	Line 2	Number of fans (line 2)	0	---	0...16
lc09	Dedicated pRack board for cond. line	Condensing lines in separate boards	NO	---	NO YES
lc10 (solo visual.)	Boards needed	pLAN boards needed for the selected configuration	---	---	---
ld01	Save configuration	Save Manufacturer configuration	NO	---	NO YES
	Load configuration	Install Manufacturer configuration	NO	---	NO YES
ld02	Reset Carel default	Install default Carel configuration	NO	---	NO YES

Tab. 7.j

(*) According to compressor type

(**) According to unit of measure selected

(***) According to compressor manufacturer, refer to the related paragraph.

(****) According to hardware size

7.2 Alarm table

pRack pR300T can manage both alarms relating to the status of the digital inputs and to system operation, similar to the pRack pR300. For each alarm, the following are controlled:

- The actions on the devices, if necessary
- The output relays (one global and two with different priorities, if configured)
- The red LED on the terminal and the buzzer, where present
- The type of acknowledgement (automatic, manual, semiautomatic)
- Any activation delay

The complete list of alarms for the pRack pR300T with the related information as described above, is reported below.

Code	Description	Reset	Delay	Alarm relay	Action
ALA**	C.pCOe offline no. 001 Offline	Automatic	0s	R1	Outputs blocked in current status or according to pattern
ALA01	Discharge temperature probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA02	Gas cooler pressure probe malfunction	Automatic	60 s	R1	Related functions disabled
ALA03	Outside temperature probe error	Automatic	60 s	R2	Related functions disabled
ALA04	Generic probe A malfunction, PLB1	Automatic	60 s	R2	Related functions disabled
ALA05	Generic probe B malfunction, PLB1	Automatic	60 s	R2	Related functions disabled
ALA06	Generic probe C malfunction, PLB1	Automatic	60 s	R2	Related functions disabled
ALA07	Generic probe D malfunction, PLB1	Automatic	60 s	R2	Related functions disabled
ALA08	Generic probe E malfunction, PLB1	Automatic	60 s	R2	Related functions disabled
ALA09	Generic probe A malfunction, PLB2	Automatic	60 s	R2	Related functions disabled
ALA10	Generic probe B malfunction, PLB2	Automatic	60 s	R2	Related functions disabled
ALA11	Generic probe C malfunction, PLB2	Automatic	60 s	R2	Related functions disabled
ALA12	Generic probe D malfunction, PLB2	Automatic	60 s	R2	Related functions disabled
ALA13	Generic probe E malfunction, PLB2	Automatic	60 s	R2	Related functions disabled
ALA14	Generic probe A malfunction, PLB3	Automatic	60 s	R2	Related functions disabled
ALA15	Generic probe B malfunction, PLB3	Automatic	60 s	R2	Related functions disabled
ALA16	Generic probe C malfunction, PLB3	Automatic	60 s	R2	Related functions disabled
ALA17	Generic probe D malfunction, PLB3	Automatic	60 s	R2	Related functions disabled
ALA18	Generic probe E malfunction, PLB3	Automatic	60 s	R2	Related functions disabled
ALA19	Generic probe A malfunction, PLB4	Automatic	60 s	R2	Related functions disabled
ALA20	Generic probe B malfunction, PLB4	Automatic	60 s	R2	Related functions disabled
ALA21	Generic probe C malfunction, PLB4	Automatic	60 s	R2	Related functions disabled
ALA22	Generic probe D malfunction, PLB4	Automatic	60 s	R2	Related functions disabled
ALA23	Generic probe E malfunction, PLB4	Automatic	60 s	R2	Related functions disabled
ALA24	Suction pressure probe malfunction	Automatic	60 s	R1	Related functions disabled
ALA25	Suction temperature probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA26	Room temperature probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA27	Condensing pressure probe malfunction, line 2	Automatic	60 s	R1	Related functions disabled
ALA28	Discharge temperature probe malfunction, line 2	Automatic	60 s	R2	Related functions disabled
ALA29	Suction pressure probe malfunction, line 2	Automatic	60 s	R1	Related functions disabled
ALA30	Suction temperature probe malfunction, line 2	Automatic	60 s	R2	Related functions disabled
ALA31	Gas cooler pressure backup probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA32	Condensing pressure backup probe malfunction, line 2	Automatic	60 s	R2	Related functions disabled
ALA33	Suction pressure backup probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA34	Suction pressure backup probe malfunction, line 2	Automatic	60 s	R2	Related functions disabled
ALA35	Common oil temperature probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA36	Common oil temperature probe malfunction, line 2	Automatic	60 s	R2	Related functions disabled
ALA39	Discharge temperature probe malfunction, compressor 1-6	Automatic	60 s	R2	Related functions disabled
ALA40	Discharge temperature probe malfunction, compressor 1-6, line 2	Automatic	60 s	R2	Related functions disabled
ALA41	Oil temperature probe malfunction, compressor 1-6, line 1	Automatic	60 s	R2	Related functions disabled
ALA42	Compressor 1 oil temperature probe malfunction, line 2	Automatic	60 s	R2	Related functions disabled
ALA43	Gas cooler outlet temperature probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA44	CO2 receiver pressure probe malfunction	Automatic	60 s	R2	Related functions disabled
ALA45	Gas cooler outlet temperature backup probe malfunction	Automatic	60 s	R2 R2	Related functions disabled Related functions disabled
ALA55	Discharge probe malfunction, line 1	Automatic	60 s		
ALA56	Discharge probe malfunction, line 2	Automatic	60 s	R2	Related functions disabled
ALA57	High/low discharge pressure, line 1	Automatic	Settable	R1	"Low pressure -> fans stopped, compressors remain on High pressure -> fans on at 100%, compressor shutdown"
ALA58	High/low discharge pressure, line 2	Automatic	Settable	R1	
ALB01	Low suction pressure from pressure switch	Semi-auto	Config.	R1	Compressor shutdown
ALB02	High condensing pressure from pressure switch	Man/Auto	Config.	R1	Compressor shutdown
ALB03	Low gas cooler outlet temperature from probe	Automatic	Settable	R1	Fans forced to 0%
ALB04	High gas cooler outlet temperature from probe	Automatic	Settable	R1	Fans forced to 100% and compressor shutdown
ALB05	Liquid level	Automatic	Config.	R2	-
ALB06	Common oil differential	Automatic	Config.	R2	-
ALB07	Common fan thermal protector	Automatic	Config.	Config.	-
ALB08	Low suction pressure from pressure switch, line 2	Semi-auto	Config.	R1	Compressor shutdown, line 2
ALB09	High condensing pressure from pressure switch, line 2	Man/Auto	Config.	R1	Compressor shutdown, line 2
ALB10	Low condensing pressure from probe, line 2	Automatic	Config.	R1	-
ALB11	High condensing pressure from probe, line 2	Automatic	Config.	R1	-
ALB12	Liquid level, line 2	Automatic	Config.	R2	-
ALB13	Common oil differential, line 2	Automatic	Config.	R2	-
ALB14	Common fan thermal protector, line 2	Automatic	Config.	Config.	-
ALB15	High suction pressure from probe	Automatic	Config.	R1	-
ALB16	Low suction pressure from probe	Automatic	Config.	R1	-
ALB17	High suction pressure from probe, line 2	Automatic	Config.	R1	-
ALB18	Low suction pressure from probe, line 2	Automatic	Config.	R1	-
ALB21	High pressure prevention	Manual	Config.	R1	Compressor shutdown
ALB22	High pressure prevention, line 2	Manual	Config.	R1 Config.	Compressor shutdown, line 2
ALC90	L1 - Generic comp. alarm	Man/Auto	Config.		Compressor shutdown due to alarm

Code	Description	Reset	Delay	Alarm relay	Action
ALC91	L1 - Compressor overload alarm	Man/Auto	Config.	Config.	Compressor shutdown due to alarm
ALC92	L1 - Compressor high pressure	Man/Auto	Config.	Config.	Compressor shutdown due to alarm
ALC93	L1 - Compressor low pressure	Man/Auto	Config.	Config.	Compressor shutdown due to alarm
ALC94	L1 - Compressor oil alarm	Man/Auto	Config.	Config.	Compressor shutdown due to alarm
ALC96	L2 - Compressor generic alarm	Man/Auto	Config.	Config.	Compressor shutdown due to alarm
ALC97	L2 - Compressor overload alarm	Man/Auto	Config.	Config.	Compressor shutdown due to alarm
ALC98	L2 - Compressor high pressure	Man/Auto	Config. Config.	Config. Config.	Compressor shutdown due to alarm
ALC99	L2 - Compressor low pressure	Man/Auto			Compressor shutdown due to alarm
ALC9a	L2 - Compressor oil alarm	Man/Auto	Config.	Config.	Compressor shutdown due to alarm
ALCad	Digital Scroll™ oil sump high temperature	Man/Auto	Config.	R2	Compressor shutdown
ALCae	Digital Scroll™ high discharge temperature	Man/Auto	Config.	R2	Compressor shutdown
ALCaf	Digital Scroll™ high oil dilution	Man/Auto	Config.	R2	Compressor shutdown
ALCag	Digital Scroll™ oil sump high temperature, line 2	Man/Auto	Config.	R2	Compressor shutdown
ALCah	Digital Scroll™ high discharge temperature, line 2	Man/Auto	Config.	R2	Compressor shutdown
ALCai	Digital Scroll™ high oil dilution, line 2	Man/Auto	Config.	R2	Compressor shutdown
ALCal	High discharge temperature, compressor 1-6	Automatic	60 s	R2	Related functions disabled
ALCam	High discharge temperature, compressor 1-6, line 2	Automatic	60 s	R2	Related functions disabled
ALCan	Compressor envelope	Manual	Config.	R1	Compressor shutdown
ALCao	High compressor oil temperature, line 1	Automatic	Config.	R2	-
ALCap	High compressor oil temperature, line 2	Automatic	Config.	R2	-
ALCag	High oil temperature, compressor 1 to 6	Automatic	-	R2	Related functions disabled
ALCar	Low oil temperature, compressor 1 to 6	Automatic	-	R2	Related functions disabled
ALF01	Fan thermal protector	Man/Auto	Config.	R2	Fans off
ALF02	Fan thermal protector, line 2	Man/Auto	Config.	R2	Fans off
ALG01	Clock error	Automatic	-	R2	Related functions disabled
ALG02	Extended memory error	Automatic	-	R2	Related functions disabled
ALG11	High alarms generic thermostat 1- 5, PLB1	Man/Auto	Config.	Config.	-
ALG12	High alarms generic thermostat 1- 5, PLB2	Man/Auto	Config.	Config.	-
ALG13	High alarms generic thermostat 1- 5, PLB3	Man/Auto	Config.	Config.	-
ALG14	High alarms generic thermostat 1- 5, PLB4	Man/Auto	Config.	Config.	-
ALG15	Low alarms generic thermostat 1- 5, PLB1	Man/Auto	Config.	Config.	-
ALG16	Low alarms generic thermostat 1- 5, PLB2	Man/Auto	Config.	Config.	-
ALG17	Low alarms generic thermostat 1- 5, PLB3	Man/Auto	Config.	Config.	-
ALG18	Low alarms generic thermostat 1- 5, PLB4	Man/Auto	Config.	Config.	-
ALG19	High alarms generic modulating 6 and 7, PLB1	Man/Auto	Config.	Config.	-
ALG20	High alarms generic modulating 6 and 7, PLB2	Man/Auto	Config.	Config.	-
ALG21	High alarms generic modulating 6 and 7, PLB3	Man/Auto	Config.	Config.	-
ALG22	High alarms generic modulating 6 and 7, PLB4	Man/Auto	Config.	Config.	-
ALG23	Low alarms generic modulating 6 and 7, PLB1	Man/Auto	Config.	Config.	-
ALG24	Low alarms generic modulating 6 and 7, PLB2	Man/Auto	Config.	Config.	-
ALG25	Low alarms generic modulating 6 and 7, PLB3	Man/Auto	Config.	Config.	-
ALG26	Low alarms generic modulating 6 and 7, PLB4	Man/Auto	Config.	Config.	-
ALG27	Normal alarm generic functions 1/2, PLB1	Man/Auto	Config.	Config.	-
ALG28	Serious alarm generic functions 8/9, PLB1	Man/Auto	Config.	Config.	-
ALG29	Normal alarm generic functions 8/9, PLB2	Man/Auto	Config.	Config.	-
ALG30	Serious alarm generic functions 8/9, PLB2	Man/Auto	Config.	Config.	-
ALG31	Normal alarm generic functions 8/9, PLB3	Man/Auto	Config.	Config.	-
ALG32	Serious alarm generic functions 8/9, PLB3	Man/Auto	Config.	Config.	-
ALG33	Normal alarm generic functions 8/9, PLB4	Man/Auto	Config.	Config.	-
ALG34	Serious alarm generic functions 8/9, PLB4	Man/Auto	Config.	Config.	-
ALH01	ChillBooster fault	Automatic	Config.	R2	ChillBooster disabled
ALH02	ChillBooster fault, line 2	Automatic	Config.	R2	ChillBooster disabled
ALO02	pLAN malfunction	Automatic	60 s	R1	Unit shutdown
ALT01	Compressor maintenance request	Manual	-	Not present	-
ALT02	Compressor maintenance request, line 2	Manual	-	Not present	-
ALT03	ChillBooster maintenance request	Manual	0 s	Not present	-
ALT04	ChillBooster maintenance request, line 2	Manual	0 s	Not present	-
ALT07	HPV valve alarm	Automatic	-	R2	Safety procedures activated
ALT08	RPRV valve alarm	Automatic	-	R2	Safety procedures activated
ALT09	Compressor 1 oil alarm	Automatic	Settable	Not featured	Related functions disabled
ALT10	Compressor 2 oil alarm	Automatic	Settable	Not featured	Related functions disabled
ALT11	Compressor 3 oil alarm	Automatic	Settable	Not featured	Related functions disabled
ALT12	Compressor 4 oil alarm	Automatic	Settable	Not featured	Related functions disabled
ALT13	Compressor 5 oil alarm	Automatic	Settable	Not featured	Related functions disabled
ALT14	Compressor 6 oil alarm	Automatic	Settable	Not featured	Related functions disabled
ALT15	Low superheat alarm	Settable	Settable	R1	Compressor shutdown, line 1
ALT16	Low superheat alarm, line 2	Settable	Settable	R1	Compressor shutdown, line 2
ALT17	HPV valve opening different from set point warning	Automatic	-	Not featured	-
ALT18	High receiver pressure	Settable	Settable	R1	Comp. shutdown, line 1 (can be enabled)
ALU01	Configuration not allowed	Automatic	Not present	Not present	Unit shutdown
ALU02	Control probes absent	Automatic	Not present	Not present	Unit shutdown
ALW01	High pressure prevent warning	Automatic	Config.	Not present	Compressors shutdown, except for minimum capacity step
ALW02	High pressure prevent warning, line 2	Automatic	Config.	Not present	Compressors shutdown, except for minimum capacity step, line 2
ALW03	Compressor inverter warning	Automatic	Not present	Not present	-
ALW04	Compressor inverter warning, line 2	Automatic	Not present	Not present	-
ALW05	Fan inverter warning	Automatic	Not present	Not present	-
ALW06	Fan inverter warning, line 2	Automatic	Not present	Not present	-
ALW07	Envelope warning: refrigerant not compatible with compressor series	Automatic	Not present	Not present	-
ALW08	Envelope warning: custom envelope not configured	Automatic	Not present	Not present	-
ALW09	Envelope warning: suction or condensing probes not configured	Automatic	Not present	Not present	-
ALW10	Low superheat warning	Automatic	Not present	Not present	-
ALW11	Low superheat warning, line 2	Automatic	Not present	Not present	-

Code	Description	Reset	Delay	Alarm relay	Action
ALW12	ChillBooster working without outside probe warning	Automatic	0 s	Not present	-
ALW13	ChillBooster working without outside probe warning, line 2	Automatic	0 s	Not present	-
ALW14	Probe type configured not allowed warning	Automatic	Not present	Not present	-
ALW15	Error during auto-configuration warning	Automatic	Not present	Not present	-
ALW16	Oil receiver levels not configured correctly warning, line 1	Automatic	-	R2	-
ALW17	Oil receiver levels not configured correctly warning, line 2	Automatic	-	R2	-
ALW18	Probe SX fault	Automatic	Not present	Not present	Depends on "Probe SX alarm management" parameter
ALW19	EEPROM damaged	Replace driver / contact service	Not present	Not present	Total shutdown
ALW20	Valve motor error	automatic	Not present	Not present	Interruption
ALW21	Driver OFFLINE	manual	5 s	Not present	Unit shutdown
ALW22	Battery discharged	Replace the battery	Not present	Not present	No effect
ALA02	Broken gas cooler pressure probe	Automatic	10s	Serious	
ALA66	Receiver outlet temperature probe broken or disconnected	Automatic	10s	Normal	related function disabled
ALA49	Heat recovery temperature probe broken or disconnected	Automatic	10s	Normal	
ALA50	Heat recovery temperature probe 2 broken or disconnected	Automatic	10s	Normal	related function disabled
ALA48	Parallel compressor Shp low temperature Probe	Automatic	10s	Normal	
ALA46	Parallel compressor discharge pressure probe broken or disconnected	Automatic	10s	Normal	
ALA47	Parallel compressor discharge temperature probe broken or disconnected	Automatic	Settable	Normal	
ALW32	Heat recovery discharge temperature probe 2 broken or disconnected	Automatic	10s	Normal	
ALB32	SERIOUS common alarm from digital input	Automatic	Not present	Serious	
ALC51	CO2 level alarm	Automatic	Settable	Normal	
ALC52	Leakage detector alarm	Automatic	Settable	Normal	
ALC95	Rotation - L1	Automatic	Settable		
ALC9b	Rotation - L2	Automatic	Settable		
ALT05	HPV valve opening too different from feedback	Automatic	Settable	Normal	
ALT06	RPRV valve opening too different from feedback	Automatic	Settable	Normal	
ALT25	Parallel comp. oil solenoid management alarm	Automatic	Settable	Normal	
ALT19	Compressor 1 oil solenoid management alarm L2	Manual	Settable		
ALT20	Compressor 2 oil solenoid management alarm L2	Manual	Settable		
ALT21	Compressor 3 oil solenoid management alarm L2	Manual	Settable		
ALT22	Compressor 4 oil solenoid management alarm L2	Manual	Settable		
ALT23	Compressor 5 oil solenoid management alarm L2	Manual	Settable		
ALT24	Compressor 6 oil solenoid management alarm L2	Manual	Settable		
ALW23	High temperature prevent warning	Automatic	Settable	Normal	
ALW24	High temperature prevent warning, line 2	Automatic	Settable	Normal	
ALW30	Alarm: heat recovery 1	Automatic	Settable	Normal	
ALW31	Alarm: heat recovery 2	Automatic	Settable	Normal	
ALW34	heat recovery 1 water inlet temperature probe broken	Automatic	10s	Normal	
ALW35	heat recovery 2 water inlet temperature probe broken	Automatic	10s	Normal	
ALW36	heat recovery 1, external 0-10 V signal fault	Automatic	10s	Normal	
ALW37	heat recovery 2, external 0-10 V signal fault	Automatic	10s	Normal	
ALO04	expansion board alarm	Automatic	Not present	Serious	
ALO05	expansion board not compatible	Automatic	Not present	Serious	
ALA60	Intercooler temperature probe broken or disconnected	Automatic	10s	Normal	
ALA59	L1 - Oil reserve probe broken or disconnected	Automatic	10s	Normal	
ALA61	parallel compressor alarm from DI	Automatic	Settable		
ALA65	parallel compressor pLAN alarm	Automatic	Not present	Serious	
ALA91	HPV, RPRV valve custom setting absent	Manual	Not present		
ALAA2	high / low chiller water outlet temperature	Automatic	Settable	Normal	-
ALAA3	high / low chiller water inlet temperature	Automatic	Settable	Normal	-
ALA93	heat recovery low differential temperature	Automatic	Settable	Normal	related function disabled
ALA94	Heat recovery temperature differential control disabled, probe absent	Automatic	10s	Normal	related function disabled
ALA95	Flow switch alarm in the chilled water line. Unit shutdown	Manual	Settable	Serious	Unit shutdown
ALA96	Chiller frost protection alarm	Manual	Settable, but depends on the control water temperature	Serious	Unit shutdown
ALA97	Chiller frost protection prevention alarm	Semi-automatic	Settable	Normal	See paragraph on chiller frost protection
ALA98	Chiller water outlet malfunction	Automatic	10s	Normal	See the paragraph on the chiller probe
ALA99	Chiller water inlet malfunction	Automatic	10s	Normal	See the paragraph on the chiller probe
ALAA0	Flow switch warning: pump off, but flow detected	Automatic	Settable	Normal	-
ALAA1	High water inlet-outlet temperature delta (chiller)	Automatic	Settable	Normal	-
ALAA4	Chiller frost protection probe malfunction	Automatic	10s	Normal	See paragraph on chiller frost protection
ALAA5	Max capacity probe L1: -Not configured - broken or disconnected	Automatic	10s	Normal	See paragraph on maximum capacity limit
ALAA6	Max capacity probe L2: -Not configured - broken or disconnected	Automatic	10s	Normal	
ALAA7	Backup function active: valve failure -HPV -RPRV	Automatic	See the paragraph on the backup function		
ALAA8	Config. Backup I/O absent /: -RPRV-HPV	Automatic			
ALAA9	Maximum number of supplementary function activations reached for - HPV valve _ RPRV valve	Automatic			

Tab. 7.k

7.3 I/O Table

The list of pRack pR300T inputs and outputs is reported below.

Digital inputs

Line 1

Screen	Description	Var. value	Logic	Channel	Notes
Baa56	L1 - Common low pressure from pressure switch	0	NC	---	
Baa57	L1 - Common high pressure from pressure switch	0	NC	---	
Baa58	L1 - Compressor inverter warning	0	NC	---	
Baa02	L1 - Compressor 1 alarm 1	0	NC	---	
Baa03	L1 - Parallel compressor alarm	0	NC	---	
Baa04	L1 - Compressor 1 alarm 2	0	NC	---	
Baa05	L1 - Compressor 1 alarm 3	0	NC	---	
Baa06	L1 - Compressor 1 alarm 4	0	NC	---	
Baa07	L1 - Compressor 1 alarm 5	0	NC	---	
Baa08	L1 - Compressor 1 alarm 6	0	NC	---	
Baa09	L1 - Compressor 1 alarm 7	0	NC	---	
Baa10	L1 - Compressor 2 alarm 1	0	NC	---	
Baa11	L1 - Compressor 2 alarm 2	0	NC	---	
Baa12	L1 - Compressor 2 alarm 3	0	NC	---	
Baa13	L1 - Compressor 2 alarm 4	0	NC	---	
Baa14	L1 - Compressor 2 alarm 5	0	NC	---	
Baa15	L1 - Compressor 2 alarm 6	0	NC	---	
Baa17	L1 - Compressor 2 alarm 7	0	NC	---	
Baa18	L1 - Compressor 3 alarm 1	0	NC	---	
Baa19	L1 - Compressor 3 alarm 2	0	NC	---	
Baa20	L1 - Compressor 3 alarm 3	0	NC	---	
Baa21	L1 - Compressor 3 alarm 4	0	NC	---	
Baa22	L1 - Compressor 3 alarm 5	0	NC	---	
Baa23	L1 - Compressor 3 alarm 6	0	NC	---	
Baa24	L1 - Compressor 3 alarm 7	0	NC	---	
Baa25	L1 - Compressor 4 alarm 1	0	NC	---	
Baa26	L1 - Compressor 4 alarm 2	0	NC	---	
Baa27	L1 - Compressor 4 alarm 3	0	NC	---	
Baa28	L1 - Compressor 4 alarm 4	0	NC	---	
Baa29	L1 - Compressor 4 alarm 5	0	NC	---	
Baa30	L1 - Compressor 4 alarm 6	0	NC	---	
Baa32	L1 - Compressor 4 alarm 7	0	NC	---	
Baa33	L1 - Compressor 5 alarm 1	0	NC	---	
Baa34	L1 - Compressor 5 alarm 2	0	NC	---	
Baa35	L1 - Compressor 5 alarm 3	0	NC	---	
Baa36	L1 - Compressor 5 alarm 4	0	NC	---	
Baa37	L1 - Compressor 5 alarm 5	0	NC	---	
Baa38	L1 - Compressor 5 alarm 6	0	NC	---	
Baa39	L1 - Compressor 5 alarm 7	0	NC	---	
Baa40	L1 - Compressor 6 alarm 1	0	NC	---	
Baa41	L1 - Compressor 6 alarm 2	0	NC	---	
Baa42	L1 - Compressor 6 alarm 3	0	NC	---	
Baa43	L1 - Compressor 6 alarm 4	0	NC	---	
Baa44	L1 - Compressor 6 alarm 5	0	NC	---	
Baa45	L1 - Compressor 6 alarm 6	0	NC	---	
Baa47	L1 - Compressor 6 alarm 7	0	NC	---	
Baa48	L1 - Compressor 7 alarm 1	0	NC	---	
Baa49	L1 - Compressor 7 alarm 2	0	NC	---	
Baa50	L1 - Compressor 8 alarm 1	0	NC	---	
Baa51	L1 - Compressor 8 alarm 2	0	NC	---	
Baa52	L1 - Compressor 9 alarm 1	0	NC	---	
Baa53	L1 - Compressor 9 alarm 2	0	NC	---	
Baa54	L1 - Compressor 10 alarm 1	0	NC	---	
Baa55	L1 - Compressor 11 alarm 1	0	NC	---	
Baa58	L1 - Compressor 12 alarm 1	0	NC	---	
Baa59	L1 - Common oil alarm	0	NC	---	
Baa59	L1 - Liquid level alarm	0	NC	---	
Baa59	L1 - CO2 leak alarm	0	NC	---	
Baa59	CO2 level alarm	0	NC	---	
Baaap	L2 - Common low pressure	0	NC	---	
Baadb	L2 - Compressor inverter warning	0	NC	---	
Baaag	L2 - Common high pressure	0	NC	---	
Baaar	L2 - Common oil alarm	0	NC	---	
Baa61	L2 - Compressor 1 alarm 1	0	NC	---	
Baa62	L2 - Compressor 1 alarm 2	0	NC	---	
Baa63	L2 - Compressor 1 alarm 3	0	NC	---	
Baa64	L2 - Compressor 1 alarm 4	0	NC	---	
Baa65	L2 - Compressor 1 alarm 5	0	NC	---	
Baa66	L2 - Compressor 1 alarm 6	0	NC	---	
Baa67	L2 - Compressor 1 alarm 7	0	NC	---	
Baa68	L2 - Compressor 2 alarm 1	0	NC	---	
Baa69	L2 - Compressor 2 alarm 2	0	NC	---	
Baa70	L2 - Compressor 2 alarm 3	0	NC	---	
Baa71	L2 - Compressor 2 alarm 4	0	NC	---	
Baa72	L2 - Compressor 2 alarm 5	0	NC	---	
Baa73	L2 - Compressor 2 alarm 6	0	NC	---	
Baa74	L2 - Compressor 2 alarm 7	0	NC	---	
Baa76	L2 - Compressor 3 alarm 1	0	NC	---	
Baa77	L2 - Compressor 3 alarm 2	0	NC	---	
Baa78	L2 - Compressor 3 alarm 3	0	NC	---	
Baa79	L2 - Compressor 3 alarm 4	0	NC	---	
Baa80	L2 - Compressor 3 alarm 5	0	NC	---	
Baa81	L2 - Compressor 3 alarm 6	0	NC	---	
Baa82	L2 - Compressor 3 alarm 7	0	NC	---	
Baa83	L2 - Compressor 4 alarm 1	0	NC	---	
Baa84	L2 - Compressor 4 alarm 2	0	NC	---	
Baa85	L2 - Compressor 4 alarm 3	0	NC	---	

Screen	Description	Var. value	Logic	Channel	Notes
Baa86	L2 - Compressor 4 alarm 4	0	NC	---	
Baa87	L2 - Compressor 4 alarm 5	0	NC	---	
Baa88	L2 - Compressor 4 alarm 6	0	NC	---	
Baa89	L2 - Compressor 4 alarm 7	0	NC	---	
Baa91	L2 - Compressor 5 alarm 1	0	NC	---	
Baa92	L2 - Compressor 5 alarm 2	0	NC	---	
Baa93	L2 - Compressor 5 alarm 3	0	NC	---	
Baa94	L2 - Compressor 5 alarm 4	0	NC	---	
Baa95	L2 - Compressor 5 alarm 5	0	NC	---	
Baa96	L2 - Compressor 5 alarm 6	0	NC	---	
Baa97	L2 - Compressor 5 alarm 7	0	NC	---	
Baa98	L2 - Compressor 6 alarm 1	0	NC	---	
Baa99	L2 - Compressor 6 alarm 2	0	NC	---	
baaaa	L2 - Compressor 6 alarm 3	0	NC	---	
Baaab	L2 - Compressor 6 alarm 4	0	NC	---	
Baaac	L2 - Compressor 6 alarm 5	0	NC	---	
baaad	L2 - Compressor 6 alarm 6	0	NC	---	
Baaae	L2 - Compressor 6 alarm 7	0	NC	---	
Baaag	L2 - Compressor 7 alarm 1	0	NC	---	
Baaah	L2 - Compressor 7 alarm 2	0	NC	---	
Baaai	L2 - Compressor 8 alarm 1	0	NC	---	
Baaaj	L2 - Compressor 8 alarm 2	0	NC	---	
Baaak	L2 - Compressor 9 alarm 1	0	NC	---	
Baaal	L2 - Compressor 9 alarm 2	0	NC	---	
Baaam	L2 - Compressor 10 alarm 1	0	NC	---	
Baaan	L2 - Compressor 11 alarm 1	0	NC	---	
Baaao	L2 - Compressor 12 alarm 1	0	NC	---	
BAAAS	L2 - Liquid level alarm	0	NC	---	
Baadc	L1 - Fan inverter warning	0	NC	---	
Baadf	L1 - High pressure prevention	0	NC	---	
Baaau	L1 - Fan 1 overload	0	NC	---	
Baaav	L1 - Fan 2 overload	0	NC	---	
Baaaw	L1 - Fan 3 overload	0	NC	---	
Baaax	L1 - Fan 4 overload	0	NC	---	
Baaay	L1 - Fan 5 overload	0	NC	---	
Baaaz	L1 - Fan 6 overload	0	NC	---	
Baaba	L1 - Fan 7 overload	0	NC	---	
Baabbb	L1 - Fan 8 overload	0	NC	---	
Baabcb	L1 - Fan 9 overload	0	NC	---	
Baabdb	L1 - Fan 10 overload	0	NC	---	
Baabeb	L1 - Fan 11 overload	0	NC	---	
Baabfb	L1 - Fan 12 overload	0	NC	---	
Baabgb	L1 - Fan 13 overload	0	NC	---	
Baabhb	L1 - Fan 14 overload	0	NC	---	
Baabib	L1 - Fan 15 overload	0	NC	---	
Baabjb	L1 - Fan 16 overload	0	NC	---	
Baabkb	L1 - Common fan thermal protector	0	NC	---	
Baacz	Parallel compressor running	0	NC	---	
Baacx	L1 - Chillbooster alarm from DI	0	NC	---	
Baadd	L2 - Fan inverter warning	0	NC	---	
Baabn	L2 - Fan 1 overload	0	NC	---	
Baabob	L2 - Fan 2 overload	0	NC	---	
Baabpb	L2 - Fan 3 overload	0	NC	---	
Baabqb	L2 - Fan 4 overload	0	NC	---	
Baabrb	L2 - Fan 5 overload	0	NC	---	
Baabsb	L2 - Fan 6 overload	0	NC	---	
Baabtb	L2 - Fan 7 overload	0	NC	---	
Baabub	L2 - Fan 8 overload	0	NC	---	
Baabvb	L2 - Fan 9 overload	0	NC	---	
Baabwb	L2 - Fan 10 overload	0	NC	---	
Baabxb	L2 - Fan 11 overload	0	NC	---	
Baabyb	L2 - Fan 12 overload	0	NC	---	
Baabzb	L2 - Fan 13 overload	0	NC	---	
Baacab	L2 - Fan 14 overload	0	NC	---	
Baacab	L2 - Fan 15 overload	0	NC	---	
Baaccb	L2 - Fan 16 overload	0	NC	---	
Baacdb	L2 - Common fan overload	0	NC	---	
Baace	L2 - Heat recovery activation request	0	NC	---	
Baadg	L2 - Chillbooster alarm from DI	0	NC	---	
Baacf	Status of generic digital input F	0	NC	---	
Baacg	Status of generic digital input G	0	NC	---	
Baach	Status of generic digital input H	0	NC	---	
Baaci	Status of generic digital input I	0	NC	---	
Baacj	Status of generic digital input J	0	NC	---	
Baack	L1 - On/Off via digital input	0	NC	---	
Baacy	L2 - On/Off via digital input	0	NC	---	
Baacl	L1 - Set point compensation from digital input	0	NC	---	
Baacm	L2 - Set point compensation from digital input	0	NC	---	
Baacn	pRack automatic or manual operating status	0	NC	---	
Baade	HPV alarm from digital input	0	NC	---	
Baadf	RPRV alarm from digital input	0	NC	---	
Baadn	L1 - Heat recovery 1 activation from DI	0	NC	---	
Baado	L1 - Heat recovery 1 flow switch	0	NC	---	
Baadp	L1 - Heat recovery 2 activation from DI	0	NC	---	
Baadq	L1 - Heat recovery 2 flow switch	0	NC	---	
Baadr	Heat recovery defrost DI	0	NC	---	
Baaf1	Common maximum oil level	0	NC	---	
Baadt	Chiller water flow switch	0	NC	---	
Baadh	Leakage detector alarm	0	NC	---	
Baadi	CO2 level alarm	0	NC	---	
Baads	Serious common alarm	0	NC	---	

Screen	Description	Var. value	Logic	Channel	Notes
Bac02	L1 - Compressor 1 line relay	0	NO	---	
Bac02	L1 - Compressor 1 delta relay	0	NO	---	
Bac02	L1 - Compressor 1 star relay	0	NO	---	
Bac03	L1 - Compressor 1 valve 1	0	NO	---	
Bac04	L1 - Compressor 1 valve 2	0	NO	---	
Bac05	L1 - Compressor 1 valve 3	0	NO	---	
Bac06	L1 - Compressor 1 valve 4	0	NO	---	
Bac07	L1 - Compressor 1 equalising valve	1	NO	---	
Bac08	L1 - Compressor 2 line relay	0	NO	---	
Bac08	L1 - Compressor 2 delta relay	0	NO	---	
Bac08	L1 - Compressor 2 star relay	0	NO	---	
Bac10	L1 - Compressor 2 valve 1	0	NO	---	
Bac11	L1 - Compressor 2 valve 2	0	NO	---	
Bac12	L1 - Compressor 2 valve 3	0	NO	---	
Bac09	L1 - Compressor 2 valve 4	0	NO	---	
Bac13	L1 - Compressor 2 equalising valve	0	NO	---	
Bac15	L1 - Compressor 3 line relay	0	NO	---	
Bac15	L1 - Compressor 3 delta relay	0	NO	---	
Bac15	L1 - Compressor 3 star relay	0	NO	---	
Bac16	L1 - Compressor 3 valve 1	0	NO	---	
Bac17	L1 - Compressor 3 valve 2	0	NO	---	
Bac18	L1 - Compressor 3 valve 3	0	NO	---	
Bac19	L1 - Compressor 3 valve 4	0	NO	---	
Bac20	L1 - Compressor 3 equalising valve	0	NO	---	
Bac21	L1 - Compressor 4 line relay	0	NO	---	
Bac21	L1 - Compressor 4 delta relay	0	NO	---	
Bac21	L1 - Compressor 4 star relay	0	NO	---	
Bac22	L1 - Compressor 4 valve 1	0	NO	---	
Bac23	L1 - Compressor 4 valve 2	0	NO	---	
Bac24	L1 - Compressor 4 valve 3	0	NO	---	
Bac25	L1 - Compressor 4 valve 4	0	NO	---	
Bac26	L1 - Compressor 4 equalising valve	0	NO	---	
Bac28	L1 - Compressor 5 line relay	0	NO	---	
Bac28	L1 - Compressor 5 delta relay	0	NO	---	
Bac28	L1 - Compressor 5 star relay	0	NO	---	
Bac29	L1 - Compressor 5 valve 1	0	NO	---	
Bac30	L1 - Compressor 5 valve 2	0	NO	---	
Bac31	L1 - Compressor 5 valve 3	0	NO	---	
Bac32	L1 - Compressor 5 valve 4	0	NO	---	
Bac33	L1 - Compressor 5 equalising valve	0	NO	---	
Bac34	L1 - Compressor 6 line relay	0	NO	---	
Bac34	L1 - Compressor 6 delta relay	0	NO	---	
Bac34	L1 - Compressor 6 star relay	0	NO	---	
Bac35	L1 - Compressor 6 valve 1	0	NO	---	
Bac36	L1 - Compressor 6 valve 2	0	NO	---	
Bac37	L1 - Compressor 6 valve 3	0	NO	---	
Bac38	L1 - Compressor 6 valve 4	0	NO	---	
Bac39	L1 - Compressor 6 equalising valve	0	NO	---	
Bac41	L1 - Compressor 7 line relay	0	NO	---	
Bac41	L1 - Compressor 7 part winding relay	0	NO	---	
Bac42	L1 - Compressor 7 valve 1	0	NO	---	
Bac43	L1 - Compressor 7 valve 2	0	NO	---	
Bac44	L1 - Compressor 7 valve 3	0	NO	---	
Bac45	L1 - Compressor 7 equalising valve	0	NO	---	
Bac46	L1 - Compressor 8 line relay	0	NO	---	
Bac46	L1 - Compressor 8 part winding relay	0	NO	---	
Bac47	L1 - Compressor 8 valve 1	0	NO	---	
Bac48	L1 - Compressor 8 valve 2	0	NO	---	
Bac49	L1 - Compressor 8 valve 3	0	NO	---	
Bac50	L1 - Compressor 8 equalising valve	0	NO	---	
Bac51	L1 - Compressor 9 line relay	0	NO	---	
Bac51	L1 - Compressor 9 part winding relay	0	NO	---	
Bac52	L1 - Compressor 9 valve 1	0	NO	---	
Bac53	L1 - Compressor 9 valve 2	0	NO	---	
Bac54	L1 - Compressor 9 valve 3	0	NO	---	
Bac55	L1 - Compressor 9 equalising valve	0	--	---	
Bac56	L1 - Compressor 10 line relay	0	NO	---	
Bac56	L1 - Compressor 10 part winding relay	0	NO	---	
Bac56	L1 - Compressor 10 valve 1	0	NO	---	
Bac57	L1 - Compressor 10 valve 2	0	NO	---	
Bac58	L1 - Compressor 10 valve 3	0	NO	---	
Bac59	L1 - Compressor 10 equalising valve	0	NO	---	
Bac61	L1 - Compressor 11 line relay	0	NO	---	
Bac61	L1 - Compressor 11 part winding relay	0	NO	---	
Bac62	L1 - Compressor 11 valve 1	0	NO	---	
Bac63	L1 - Compressor 11 valve 2	0	NO	---	
Bac64	L1 - Compressor 11 valve 3	0	NO	---	
Bac65	L1 - Compressor 11 equalising valve	0	NO	---	
Bac66	L1 - Compressor 12 line relay	0	NO	---	
Bac66	L1 - Compressor 12 part winding relay	0	NO	---	
Bac67	L1 - Compressor 12 valve 1	0	NO	---	
Bac68	L1 - Compressor 12 valve 2	0	NO	---	
Bac69	L1 - Compressor 12 valve 3	0	NO	---	
Bac70	L1 - Compressor 12 equalising valve	0	NO	---	
Bac71	L1 - Oil reserve digital output	0	NO	---	
Bac73	L2 - Compressor 1 line relay	0	NO	---	
Bac73	L2 - Compressor 1 delta relay	0	NO	---	
Bac73	L2 - Compressor 1 star relay	0	NO	---	
Bac74	L2 - Compressor 1 valve 1	0	NO	---	
Bac75	L2 - Compressor 1 valve 2	0	NO	---	
Bac76	L2 - Compressor 1 valve 3	0	NO	---	
Bac77	L2 - Compressor 1 valve 4	0	NO	---	
Bac78	L2 - Compressor 1 equalising valve	0	NO	---	
Bac79	L2 - Compressor 2 line relay	0	NO	---	

Screen	Description	Var. value	Logic	Channel	Notes
Bac79	L2 - Compressor 2 delta relay	0	NO	---	
Bac79	L2 - Compressor 2 star relay	0	NO	---	
Bac80	L2 - Compressor 2 valve 1	0	NO	---	
Bac81	L2 - Compressor 2 valve 2	0	NO	---	
Bac82	L2 - Compressor 2 valve 3	0	NO	---	
Bac83	L2 - Compressor 2 valve 4	0	NO	---	
Bac84	L2 - Compressor 2 equalising valve	0	NO	---	
Bac86	L2 - Compressor 3 line relay	0	NO	---	
Bac86	L2 - Compressor 3 delta relay	0	NO	---	
Bac86	L2 - Compressor 3 star relay	0	NO	---	
Bac87	L2 - Compressor 3 valve 1	0	NO	---	
Bac88	L2 - Compressor 3 valve 2	0	NO	---	
Bac89	L2 - Compressor 3 valve 3	0	NO	---	
Bac90	L2 - Compressor 3 valve 4	0	NO	---	
Bac91	L2 - Compressor 3 equalising valve	0	NO	---	
Bac92	L2 - Compressor 4 line relay	0	NO	---	
Bac92	L2 - Compressor 4 delta relay	0	NO	---	
Bac92	L2 - Compressor 4 star relay	0	NO	---	
Bac94	L2 - Compressor 4 valve 1	0	NO	---	
Bac95	L2 - Compressor 4 valve 2	0	NO	---	
Bac96	L2 - Compressor 4 valve 3	0	NO	---	
Bac97	L2 - Compressor 4 valve 4	0	NO	---	
Bac98	L2 - Compressor 4 equalising valve	0	NO	---	
Bacaa	L2 - Compressor 5 line relay	0	NO	---	
Bacaa	L2 - Compressor 5 delta relay	0	NO	---	
Bacaa	L2 - Compressor 5 star relay	0	NO	---	
Bacab	L2 - Compressor 5 valve 1	0	NO	---	
Bacac	L2 - Compressor 5 valve 2	0	NO	---	
Bacad	L2 - Compressor 5 valve 3	0	NO	---	
Bacae	L2 - Compressor 5 valve 4	0	NO	---	
Bacaf	L2 - Compressor 5 equalising valve	0	NO	---	
Bacag	L2 - Compressor 6 line relay	0	NO	---	
Bacag	L2 - Compressor 6 delta relay	0	NO	---	
Bacag	L2 - Compressor 6 star relay	0	NO	---	
Bacah	L2 - Compressor 6 valve 1	0	NO	---	
Bacai	L2 - Compressor 6 valve 2	0	NO	---	
Bacaj	L2 - Compressor 6 valve 3	0	NO	---	
Bacak	L2 - Compressor 6 valve 4	0	NO	---	
Bacal	L2 - Compressor 6 equalising valve	0	NO	---	
Bacan	L2 - Compressor 7 line relay	0	NO	---	
Bacan	L2 - Compressor 7 delta relay	0	NO	---	
Bacan	L2 - Compressor 7 star relay	0	NO	---	
Bacao	L2 - Compressor 7 valve 1	0	NO	---	
Bacap	L2 - Compressor 7 valve 2	0	NO	---	
Bacaq	L2 - Compressor 7 valve 3	0	NO	---	
Bacar	L2 - Compressor 7 equalising valve	0	NO	---	
Bacas	L2 - Compressor 8 line relay	0	NO	---	
Bacas	L2 - Compressor 8 part winding relay	0	NO	---	
Bacat	L2 - Compressor 8 valve 1	0	NO	---	
Bacau	L2 - Compressor 8 valve 2	0	NO	---	
Bacav	L2 - Compressor 8 valve 3	0	NO	---	
Bacaw	L2 - Compressor 8 equalising valve	0	NO	---	
Bacax	L2 - Compressor 9 line relay	0	NO	---	
Bacax	L2 - Compressor 9 part winding relay	0	NO	---	
Bacay	L2 - Compressor 9 valve 1	0	NO	---	
Bacaz	L2 - Compressor 9 valve 2	0	NO	---	
Bacba	L2 - Compressor 9 valve 3	0	NO	---	
Bacbb	L2 - Compressor 9 equalising valve	0	NO	---	
Bacbc	L2 - Compressor 10 line relay	0	NO	---	
Bacbc	L2 - Compressor 10 part winding relay	0	NO	---	
Bacbd	L2 - Compressor 10 valve 1	0	NO	---	
Bacbe	L2 - Compressor 10 valve 2	0	NO	---	
Bacbf	L2 - Compressor 10 valve 3	0	NO	---	
Bacbg	L2 - Compressor 10 equalising valve	0	NO	---	
Bacbh	L2 - Compressor 11 line relay	0	NO	---	
Bacbh	L2 - Compressor 11 part winding relay	0	NO	---	
Bacbi	L2 - Compressor 11 valve 1	0	NO	---	
Bacbj	L2 - Compressor 11 valve 2	0	NO	---	
Bacbk	L2 - Compressor 11 valve 3	0	NO	---	
Bacbl	L2 - Compressor 11 equalising valve	0	NO	---	
Bacbm	L2 - Compressor 12 line relay	0	NO	---	
Bacbm	L2 - Compressor 12 part winding relay	0	NO	---	
Bacbn	L2 - Compressor 12 valve 1	0	NO	---	
Bacbo	L2 - Compressor 12 valve 2	0	NO	---	
Bacbp	L2 - Compressor 12 valve 3	0	NO	---	
Bacbq	L2 - Compressor 12 equalising valve	0	NO	---	
Baceo	L2 - Oil receiver	0	NO	---	
Bacbt	L1 - Fan 1 status	0	NO	---	
Bacbu	L1 - Fan 2 status	0	NO	---	
Bacbv	L1 - Fan 3 status	0	NO	---	
Bacbw	L1 - Fan 4 status	0	NO	---	
Bacbx	L1 - Fan 5 status	0	NO	---	
Bacby	L1 - Fan 6 status	0	NO	---	
Bacbz	L1 - Fan 7 status	0	NO	---	
Bacca	L1 - Fan 8 status	0	NO	---	
Baccb	L1 - Fan 9 status	0	NO	---	
Baccc	L1 - Fan 10 status	0	NO	---	
Baccd	L1 - Fan 11 status	0	NO	---	
bacce	L1 - Fan 12 status	0	NO	---	
Baccf	L1 - Fan 13 status	0	NO	---	
Baccg	L1 - Fan 14 status	0	NO	---	
Bacch	L1 - Fan 15 status	0	NO	---	
Bacci	L1 - Fan 16 status	0	NO	---	
backk	L1 - Heat recovery pump ON/OFF	0	NO	---	

Screen	Description	Var. value	Logic	Channel	Notes
Bacef	Parallel compressor line relay	0	NO	---	
Baccl	L1 - Chillbooster status	0	NO	---	
Baccn	L2 - Fan 1 status	0	NO	---	
Bacco	L2 - Fan 2 status	0	NO	---	
Baccp	L2 - Fan 3 status	0	NO	---	
Baccq	L2 - Fan 4 status	0	NO	---	
Baccr	L2 - Fan 5 status	0	NO	---	
Baccs	L2 - Fan 6 status	0	NO	---	
Bacct	L2 - Fan 7 status	0	NO	---	
Baccu	L2 - Fan 8 status	0	NO	---	
Baccv	L2 - Fan 9 status	0	NO	---	
Baccw	L2 - Fan 10 status	0	NO	---	
Baccx	L2 - Fan 11 status	0	NO	---	
baccy	L2 - Fan 12 status	0	NO	---	
Baccz	L2 - Fan 13 status	0	NO	---	
Bacda	L2 - Fan 14 status	0	NO	---	
Bacdb	L2 - Fan 15 status	0	NO	---	
Bacdc	L2 - Fan 16 status	0	NO	---	
Bacde	L2 - Heat recovery pump ON/OFF	0	NO	---	
Bacdf	L2 - Chillbooster status	0	NO	---	
Bacdg	L1 - Generic function output stage 1	0	NO	---	
Bacdh	L1 - Generic function output stage 2	0	NO	---	
Bacdi	L1 - Generic function output stage 3	0	NO	---	
Bacdj	L1 - Generic function output stage 4	0	NO	---	
Bacdk	L1 - Generic function output stage 5	0	NO	---	
Bacdl	Active alarms	0	NO	---	
Bacdm	Generic alarm 1 status	0	NO	---	
Bacdn	Generic alarm 2 status	0	NO	---	
Bacdo	Generic scheduler function	0	NO	---	
Bacdp	L1 - Oil pump 1 status	0	NO	---	
Bacdq	L1 - Oil pump 2 status	0	NO	---	
Bacdr	L1 - Oil fan status	0	NO	---	
Bacds	L2 - Oil pump 1 status	0	NO	---	
Bacdt	L2 - Oil pump 2 status	0	NO	---	
Bacdu	L2 - Oil fan status	0	NO	---	
Bacdv	L1 - Compressor 1 liquid injection status	0	NO	---	
Bacdww	L1 - Compressor 2 liquid injection status	0	NO	---	
Bacdx	L1 - Compressor 3 liquid injection status	0	NO	---	
Bacdy	L1 - Compressor 4 liquid injection status	0	NO	---	
Bacdz	L1 - Compressor 5 liquid injection status	0	NO	---	
Bacea	L1 - Compressor 6 liquid injection status	0	NO	---	
Baceb	L2 - Compressor 1 liquid injection status	0	NO	---	
Bacec	L2 - Compressor 2 liquid injection status	0	NO	---	
Baced	L2 - Compressor 3 liquid injection status	0	NO	---	
Bacee	L2 - Compressor 4 liquid injection status	0	NO	---	
Bacef	L2 - Compressor 5 liquid injection status	0	NO	---	
Baceg	L2 - Compressor 6 liquid injection status	0	NO	---	
Baceh	Heartbeat	0	NO	---	
BACEI	L1 - Forcing from BMS	0	NO	---	
Bacej	L1 - Anti liquid return	0	NO	---	
Bac72	L2 - Anti liquid return	0	NO	---	
Bacep	L2 - Forcing from BMS	0	NO	---	
Bacek	L1 - Subcooling status	0	NO	---	
Bacel	L2 - Subcooling status	0	NO	---	
Bacem	Normal alarm status	0	NO	---	
BACEN	Serious alarm status	0	NO	---	
Bacfa	L1 - Heat recovery 1 status	0	NO	---	
Bacfb	L1 - Heat recovery 2 status	0	NO	---	
Bacfd	L1 - Heat recovery 3-way bypass valve	0	NO	---	
Bacfc	Heat recovery pump 2	0	NO	---	
Bacfd	Extra load	0	NO	---	
Bacet	Chiller water pump	0	NO	---	
Baca1	Chiller ExV valve	0	NO	---	

Tab. 7.m

Digital outputs

Screen	Description	Var. value	UOM	Logic	Channel	Min	Max	Offset	Notes
BAB01	L1 - Suction pressure	0	barg	0-1V	---	0	0	0	
Bab60	L1 - Suction pressure probe compensation	0	°C	0-1V	---	0	0	--	
Bab02	L1 - Backup suction pressure probe	0	barg	0-1V	---	0	0	0	
Bab03	L1 - Suction temperature	0	°C	NTC	---	0	0	0	
Bab75	L1 - Discharge pressure	0	barg	4-20mA	---	0	150	0	
Bab11	L1 - Discharge temperature	0	°C	NTC	---	0	0	0	
Bab04	L1 - Gas cooler pressure	0	barg	---	---	0	0	0	
Bab09	L1 - Backup gas cooler pressure probe	0	barg	---	---	0	0	0	
Bab61	L1 - Gas cooler outlet temperature	0	°C	NTC	---	0	0	0	
Bab62	L1 - Backup gas cooler temperature probe	0	°C	NTC	---	0	0	0	
Bab70	L1 - Gas cooler inlet temperature	0	°C	NTC	---	0	0	0	
Bab71	L1 - Gas cooler set point compensation from analogue input	0	barg	---	---	0	0	--	
Bab63	L1 - Oil reserve pressure	0	barg	---	---	0	0	0	
Bab90	L1 - Temperature between heat recovery exchangers 1 and 2	0	°C	NTC	---	0	0	0	
Bab13	L1 - Heat recovery 1 temperature	0	°C	NTC	---	0	0	0	
Bab05	L2 - Suction pressure	0	barg	0-1V	---	0	0	0	
Bbb75	L2 - Discharge pressure	0	barg	4-20mA	---	--	150	0	
Bab48	L2 - Discharge temperature	0	°C	NTC	---	0	0	0	
Bab49	L1 - Heat recovery 1 request from external 0/10V signal	0	barg	0-1V	---	0	0	0	
Bab64	L2 - Suction set point compensation from analogue input	0	barg	0-1V	---	0	0	--	
Bab06	L2 - Suction pressure backup	0	barg	0-1V	---	0	0	0	
Bab07	L2 - Suction temperature	0	°C	NTC	---	0	0	0	
Bab73	L2 - Intercooler temperature	0	°C	NTC	---	0	0	0	
Bab14	L2 - Heat recovery 2 temperature	0	°C	NTC	---	0	0	0	

Screen	Description	Var. value	UOM	Logic	Channel	Min	Max	Offset	Notes
Bab65	L2 - Oil reserve pressure	0	barq	---	---	0	0	0	
Bab18	L2 - Heat recovery temperature probe	0	°C	NTC	---	0	0	0	
Bab15	L1 - Outside temperature	0	°C	NTC	---	0	0	0	
Bab16	Room temperature	0	°C	NTC	---	0	0	0	
Bab17	L1 - Common oil temperature	0	°C	NTC	---	0	0	0	
Bab20	L1 - Generic probe 1	0	barq	NTC	---	0	0	0	
Bab22	L1 - Generic probe 2	0	barq	NTC	---	0	0	0	
Bab24	L1 - Generic probe 3	0	barq	NTC	---	0	0	0	
Bab26	L1 - Generic probe 4	0	barq	NTC	---	0	0	0	
Bab28	L1 - Generic probe 5	0	barq	NTC	---	0	0	0	
Bab29	L1 - Compressor 1 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab30	L1 - Compressor 2 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab31	L1 - Compressor 3 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab32	L1 - Compressor 4 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab33	L1 - Compressor 5 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab34	L1 - Compressor 6 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab35	L2 - Compressor 1 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab36	L2 - Compressor 2 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab37	L2 - Compressor 3 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab38	L2 - Compressor 4 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab39	L2 - Compressor 5 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab40	L2 - Compressor 6 high discharge temperature	0	°C	NTC	---	0	0	0	
Bab41	L1 - Compressor 1 oil temperature	0	barq	---	---	0	0	0	
Bab42	L1 - Compressor 2 oil temperature	0	barq	---	---	0	0	0	
Bab43	L1 - Compressor 3 oil temperature	0	barq	---	---	0	0	0	
Bab44	L1 - Compressor 4 oil temperature	0	barq	---	---	0	0	0	
Bab45	L1 - Compressor 5 oil temperature	0	barq	---	---	0	0	0	
Bab46	L1 - Compressor 6 oil temperature	0	barq	---	---	0	0	0	
Bab47	L2 - Compressor 1 oil temperature	0	barq	---	---	0	0	0	
Bab66	L1 - Receiver pressure	0	barq	---	---	0	0	0	
Bab67	HPV opening feedback	0	barq	--	---	0	0	0	
Bab68	RPRV opening feedback	0	barq	--	---	0	0	0	
Bab72	L1 - HPV set point compensation from analogue input	0	barq	---	---	0	0	--	
Bab91	L1 - Heat recovery 1 water inlet temperature	0	°C	NTC	---	--	--	0	
Bab93	L1 - Heat recovery 2 water outlet temperature	0	°C	NTC	---	--	--	0	
Bab94	L1 - Heat recovery 2 water inlet temperature	0	°C	NTC	---	--	--	0	
Bab95	L1 - Heat recovery 2 request external 0/10V signal	0	%	0-1V	---	0	0	0	
Bab96	L1 - Gas cooler bypass temperature	0	°C	NTC	---	--	--	0	
Bab92	L1 - Heat recovery 1 request external 0/10V signal	0	°C	NTC	---	--	--	0	
Bab65	Chiller water outlet temperature	0	°C	NTC	---	--	--	0	
Bab59	Chiller water inlet temperature	0	°C	NTC	---	--	--	0	
Bab97	Chiller water frost protection temperature	0	°C	NTC	---	--	--	0	
Bab69	Temp. Subcooled liquid	0	°C	NTC	---	--	--	0	
Bab76	L2 - Discharge pressure	0	°C	NTC	---	--	--	0	
Bab08	L2 - Condenser pressure	0	°C	NTC	---	--	--	0	
Bab10	L2 - Condenser backup probe	0	°C	NTC	---	--	--	0	

Tab. 7.n

Analogue outputs

Screen	Description	Var. value	UOM	Logic	Channel	Min	Max	Offset	Notes
Bad01	L1 - Compressor 1 inverter output	0	%	0-10V	---	--	--	--	
Bad02	L1 - Oil pump output	0	%	0-10V	---	--	--	--	
Bad04	L2 - Compressor 1 inverter output	0	%	0-10V	---	--	--	--	
Bad05	L2 - Oil pump output	0	%	0-10V	---	--	--	--	
Bad07	L1 - Fan inverter output	0	%	0-10V	---	--	--	--	
Bad25	HPV valve output	0	%	0-10V	---	--	--	--	
Bad26	RPRV valve output	0	%	0-10V	---	--	--	--	
Bad20	L1 - Heat recovery 1 pump output	0	%	0-10V	---	--	--	--	
Bad21	L1 - Heat recovery 2 valve output	0	%	0-10V	---	--	--	--	
Bad22	L1 - Heat recovery 2 pump output	0	%	0-10V	---	--	--	--	
Bad23	L1 - Heat recovery 3-way bypass valve output	0	%	0-10V	---	--	--	--	
Bad24	L1 - Heat recovery extra load	0	%	0-10V	---	--	--	--	
bacck	L1 - Heat recovery 1 valve output	0	%	0-10V	---	--	--	--	
Bad16	Parallel compressor inverter output	0	%	0-10V	---	--	--	--	
Bad10	L2 - Fan inverter output	0	%	0-10V	---	--	--	--	
Bad11	L2 - Heat recovery analogue output	0	%	0-10V	---	--	--	--	
Bad12	Generic modulating function 1 output	0	%	0-10V	---	--	--	--	
Bad13	Generic modulating function 2 output	0	%	0-10V	---	--	--	--	
	L1 - Compressor 2 inverter output	0	%	0-10V	---	--	--	--	
	L2 - Compressor 2 inverter output	0	%	0-10V	---	--	--	--	

Tab. 7.o

8. ALARMS

pRack PR300T can manage both alarms relating to the status of the digital inputs and to operation of the system. For each alarm, the following are controlled:

- The actions on the devices, if necessary
- The output relays (one global and two with different priorities, if configured)
- The red LED on the terminal and the buzzer, where present
- The type of acknowledgement (automatic, manual, semiautomatic)
- Any activation delay

The complete list of alarms, with the related information as described above, is available in Alarm table.

8.1 Alarm management

All alarms feature the following behaviour:

- When an alarm is activated, the red LED flashes and the buzzer is activated (where present); the output relays corresponding to the global alarm and to any alarms with priority are activated (if configured)
- Pressing the ▲ (Alarm) button, the red LED stays on steady, the buzzer is muted and the alarm screen is shown
- If there is more than one active alarm, these can be scrolled using ↑ (Up) ↓ (Down). This condition is signalled by an arrow at the bottom right of the screen
- Pressing the ▲ (Alarm) button again for at least 3 seconds acknowledges the alarms manually, and these are cleared from the display unless others are active (they are saved in the log)

8.1.1 Priority

For certain alarms, the alarm output relay can be set with two types of priority:

- R1: serious alarm
- R2: normal alarm

The corresponding relays, once configured, are activated when an alarm with the corresponding priority occurs. For the other alarms, the priority is fixed and is associated by default with one of the two relays.

8.1.2 Acknowledgement

The alarms can have manual, automatic or semiautomatic acknowledgement:

- Manual: the alarm is acknowledged by pressing the ▲ (Alarm) button twice, the first time displays the corresponding alarm screen and mutes the buzzer, the second (extended, for at least 3 seconds) cancels the alarm (which is saved in the log). If the alarm is still active, acknowledgement has no effect and the signal is shown again.
- Automatic: when the alarm condition ceases, the alarm is automatically reset, the LED comes on steady and the corresponding screen remains displayed until the ▲ (Alarm) button is pressed and held; the alarm is saved in the log.
- Semiautomatic: acknowledgement is automatic, until a maximum number of activations in set time. If the number reaches the maximum set, acknowledgement becomes manual.

For manual acknowledgement, the functions associated with the alarm are not reactivated until acknowledgement has been completed, while for automatic acknowledgement they're reactivated as soon as the alarm condition ceases.

8.1.3 Log

The alarm log can be accessed:

- from branch G.a of the main menu
- by pressing the ▲ (Alarm) button and then ↵ (Enter) when there are no active alarms
- by pressing ↵ (Enter) after having scrolled all the alarms.

The alarm log screens show:

1. Order of activation (no. 01 is the oldest alarm)
2. Hour and date the alarm was activated
3. Short description
4. Main values recorded at the moment the alarm was activated (suction pressure and condensing pressure).

Note: A maximum of 50 alarms can be logged; after this limit any new events overwrite the oldest ones, which are therefore deleted.

8.2 Compressor alarms

The number of alarms for each compressor can be set during the configuration phase using the Wizard or subsequently from branch C.a.e/ C.b.e of the main menu. The number of alarms is the same for all the compressors on the same line.




Fig. 8.a

Note: The maximum number of alarms that can be configured for each compressor depends not only on the type of compressor, but also on the size of pRack and the number of compressors fitted.

After having selected the number of alarms (maximum 4), the settings can be configured for each alarm, choosing a description from the options shown in the table, the output relay, the type of reset, delay and priority. The effect of the alarm on the devices is set and involves stopping the compressor, except for the oil warning.

Possible descriptions for compressor alarms

Reciprocating or scroll
Generic
Overload
High pressure
Low pressure
Oil

Tab. 8.a

An example of a screen for selecting the description of the alarm is shown in the figure:




Fig. 8.b


After having selected the 'generic' description, no other description can be selected. In general, the descriptions are divided in:

- overload,
- oil,
- high pressure
- low pressure.


After a description has been selected for a certain group, descriptions from a different group can not be selected for that alarm. For example, generic only, or overload + oil, or rotation only or overload + high pressure., etc. can be selected. Each alarm will have one alarm screen, which will show all the descriptions associated to that alarm.

Starting from version 3.3.0, the main alarms relating to the compressors have been grouped together; specifically, the alarms can be configured in the path: C.Compressors → d.Alarms → Cae01 (Fig.8.a). The screens show which compressors (only those configured) will be shutdown (and which not) when a specific alarm is activated (generic alarm, high pressure.); for example, with 3 compressors and the first 2 with alarms, the following will occur:

According to the number of alarms selected, the default associated descriptions will be as shown in the table.



Further example:



The same applies to the following alarms:

- L1 – Compressors overload alarm
- L1 – Compressors high pressure
- L1 – Compressors low pressure
- L1 – Compressors oil alarm
- L2 – Compressors generic alarm
- L2 – Compressors overload alarm
- L2 – Compressors high pressure
- L2 – Compressors low pressure
- L2 – Compressors oil alarm

Default descriptions based on the number of alarms

Number of alarms	Descriptions
1	Generic
2	Overload HP-LP
3	Overload HP-LP Oil
4	Overload HP LP Oil

Tab. 8.b

Note: for oil alarms, special management is available whereby the alarm is interpreted as an oil level alarm. When the alarm is activated, a number of attempts are made to restore the level for a set time before the alarm is signalled and the compressor stopped.

If a modulating device is used for the compressors, further alarms become available:

- compressor inverter warning, common for the entire suction line, when the device is an inverter
- oil sump temperature alarm, high discharge temperature and oil dilution, for Digital Scroll™ compressors

For each compressor, two alarm variables are sent to the supervisor, one for each priority. As well as the alarm signal, the description of the alarm is also sent to the supervisor, using the values shown in the table:

The supervisor can interpret the variables sent by pRack PR300T and provide the correct description of the alarm.

8.3 Pressure and prevent alarms

pRack PR300T can manage pressure alarms from a pressure switch or probe, according to the following diagram.

Alarms from pressure switch:

- Low suction pressure
- High condensing pressure

Alarms from probe:

- Low suction pressure

- High suction pressure
- Low condensing pressure
- High condensing pressure

One possible example for the low pressure alarms is shown in the figure:




Fig. 8.c

In addition, the high pressure alarm features a prevent function, available by manually overriding the devices as well as using additional functions, such as heat recovery and ChillBooster. Operation of the alarms and prevent function is described below.

8.3.1 Pressure alarms from pressure switch

The parameters corresponding to these alarms can be set in branch G.c.a/G.c.b of the main menu.

Low suction pressure from pressure switch

The low suction pressure alarm from pressure switch has the effect of stopping all the compressors without observing the various times, therefore when the digital input configured as low pressure switch is activated, all the compressors on the line affected are stopped immediately.

This alarm features semiautomatic reset, and both the monitoring time and the number of activations in the specified period can be set. If the number of activations is higher, reset becomes manual.

In addition, the delay after which the alarm is activated on both start-up and during operation can be set.

The delay at start-up only applies to unit start-up and not compressor power-up.

High condensing pressure from pressure switch

The high condensing pressure alarm from pressure switch has the effect of stopping all the compressors without observing the various times and forcing the fans on at maximum speed, therefore when the digital input configured as high pressure switch is activated, all the compressors on the line affected are stopped immediately and the fans operate at maximum output.

This alarm features manual or automatic reset, as configured by the user. The delay after which the alarm is activated can also be set

8.3.2 Pressure alarms from probe

The parameters corresponding to these alarms can be set in branch C.a.e/C.b.e of the main menu for the suction pressure and D.a.e/D.b.e for the condensing pressure.

For these types of alarms, reset is automatic and the activation threshold and differential can be set, as well as the type of threshold, which may be absolute or relative to the control set point. The figure shows an example of setting the threshold to relative.




Fig. 8.d

Note: for temperature control, the alarms from probe are managed based on temperature even when pressure probes are fitted.

The effects of the different pressure alarms from probe are described below.

CAREL

Low suction pressure from probe

The low suction pressure alarm from probe has the effect of stopping all the compressors, ignoring the times.

High suction pressure from probe

The high suction pressure alarm from probe has the effect of forcing all the compressors on, ignoring the control times, but observing the compressor protection times.

Low condensing pressure from probe

The low condensing pressure alarm from probe has the effect of stopping all the fans, ignoring the times.

High condensing pressure from probe

The high condensing pressure alarm from probe has the effect of forcing all the fans on and stopping all the compressors, ignoring the times. The reference for the alarm will be the discharge pressure probe (Bab75 or Bbb75), or if this is not configured, the gas cooler / intercooler pressure probe (Bab04 and Dba39).




Fig. 8.e

8.3.3 High pressure prevention

pRack PR300T can manage 3 types of high condensing pressure prevention actions, involving:

- overriding the compressors and fans
- activating heat recovery
- activating ChillBooster

Prevent by overriding the compressors and fans

The parameters relating to this function can be set in branch G.b.a/G.b.b of the main menu.

The effect of this type of prevent action is to force all the fans on at maximum and switch all the compressors off, except for the minimum capacity stage, ignoring the control times but observing the compressor protection times. The minimum capacity stage means one compressor in the case of compressors without capacity control and modulation devices, or the minimum capacity stage for capacity-controlled compressors (e.g. 25%), or alternatively the minimum output of the modulation device in the case of inverters, Digital Scroll™.

As well as the activation threshold, which is always absolute, and the activation differential, a compressor deactivation time can be set, corresponding to the time needed to switch off all the compressors, except for the minimum capacity stage.

In addition, both the monitoring time and the number of activations in the specified period can be set. If the number of activations is higher, reset becomes manual.

Prevent by activating heat recovery

The parameters corresponding to this function can be set in branch G.b.a/G.b.b of the main menu, if the heat recovery function is present.

As well as enabling the function, an offset from the activation threshold for the prevent by overriding devices function must be set. The activation differential for this function is the same as set for the prevent by overriding devices function.

When reaching the threshold, pRack PR300T activates the heat recovery function, if the conditions allow.

Prevent by activating ChillBooster

The parameters relating to this function can be set in branch G.b.a/G.b.b of the main menu, if the ChillBooster function is present.

As well as enabling the function, an offset from the activation threshold for the prevent by overriding devices function must be set. The activation differential for this function is the same as set for the prevent by overriding devices function.

When reaching the threshold, pRack PR300T force activates the ChillBooster, if the conditions allow.

The following figure illustrates the activation thresholds for the prevent function and the safety devices:

8.3.4 High temperature prevention

Prevention by overriding compressors and fans

The parameters relating to the high temperature prevention function can be set in branch G.b.a/ of the main menu.

```
Prevent Gba01
High Pressure
Prevent enable: NO
High Temperature
Prevent enable: YES
```

When enabling this function, a warning is shown that a compressor discharge temperature probe needs to be configured, if this has not already been done previously.

This function is designed to keep the common compressor discharge temperature under control. If the temperature exceeds the set threshold, all of the fans are forced on at maximum speed and all of the compressors are switched off, except for the minimum capacity step.

The compressors are stopped without waiting for the control times, however after the compressor protection times.

Minimum capacity step refers to one compressor for compressors without capacity control and without modulating devices, or the minimum capacity step for compressors with capacity control (e.g. 25%), or the minimum capacity that the modulating device can deliver for inverter or Digital Scroll (TM) compressors.

If there is a parallel compressor connected to the same board in the system, this will also operate at the minimum capacity step. In addition to the activation threshold, which is always absolute, and the activation differential, a compressor deactivation time can also be set, corresponding to the time required to switch off all of the compressors, except for the minimum capacity step.

Furthermore, the evaluation time and the number of activations allowed in a set time period can be set. If the number of activations is greater than the value set, all of the compressors are switched.

```
Prevent Gba01
High Pressure
Prevent enable: NO
High Temperature
Prevent enable: YES
```

9. SUPERVISORY AND COMMISSIONING SYSTEMS

pRack PR300T can be connected to various supervisory systems, specifically the Carel and Modbus communication protocols can be used. For the Carel protocol, the PlantVisor PRO and PlantWatch PRO models are available. In addition, pRack PR300T can be connected to the pRack Manager commissioning software.

9.1 PlantVisor PRO and PlantWatch PRO supervisory systems

Connection to Carel PlantVisor PRO and PlantWatch PRO supervisor systems uses the RS485 card already fitted on some models of pRack PR300T. For details on the models of card available, see Chapter 1.

Note: In generale tutte le schede pRack dovrebbero essere dotate di scheda e collegamento alla supervisione.

Three different models of PlantVisor PRO and PlantWatch PRO are available, used to supervise system configurations with one or two lines:

- L1 – one line: can be used for system configurations with just one suction and/or condenser line.
- L2 – one line: can be used for system configurations with two suction and/or condenser lines, and the two suction lines are managed by separate boards.
- Two lines: can be used for system configurations with two suction and/or condenser lines, and the two suction lines are managed by the same board.

Important: model L2 – One line must be used only in association with model L1 – One line. For supervision of system configurations with just one line only model L1 – One line can be used.

Tutorial: the rule applied for using the models is summarised below:

- cconfiguration with board with pLAN address 2 → separate models
- configuration without board with pLAN address 2 → one model only

A connection example for using PlantVisor PRO and PlantWatch PRO is shown in the figure.




Fig. 9.a

The complete list of supervisor variables, with the corresponding addresses and descriptions, can be supplied upon request.

9.2 Commissioning software

pRack Manager is configuration and real-time monitoring software used to check the operation of pRack PR300T, for commissioning, debug and maintenance operations.

The software is available on the internet at <http://ksa.CAREL.com> in the section "download à support à software utilities". The installation includes, in addition to the program, the user manual and the necessary drivers.

pRack Manager can be used to set the configuration parameters, modify the values of volatile and permanent variables, save graphs of the main system values to file, manually manage the unit I/Os using simulation files and monitor/reset alarms on the unit where the device is installed.

pRack PR300T is able to virtualise all the inputs and outputs, both digital and analogue, therefore each input and output can be overridden by pRack Manager.

pRack Manager manages <file name>.DEV files that contain the user parameter configurations and that can be downloaded from the pRack PR300T board and then subsequently uploaded.

To use the pRack Manager program, a serial converter output RS485 with CVSTDUTLF0 (telephone connector) or CVSTDUMORO (3 pin terminal) must be connected to the board.

The connection to pRack Manager can be made:

1. Via the RS485 serial port used for the "pLAN" connection
2. Via the BMS serial port with RS485 serial card and activating the pRack Manager protocol by parameter on screen Fca01 or connecting pRack Manager and selecting SearchDevice = Auto (BMS or FB) on the "Connection settings" tab. In this case, the connection is established after around 15-20 seconds.

Important: the BMS serial port should only be used for monitoring the variables, while to update the software use the RS485 serial port dedicated to the pLAN connection.

The following figure shows an example of connection to the PC via the RS485 serial port used for the "pLAN" connection




Fig. 9.b

Note: for further details see the pRack Manager program online help.

10. SOFTWARE UPDATE AND CONFIGURATION

10.1 Smart Key: operating instructions



Fig. 10.a

Programming the Smart Key via Personal Computer

The operating modes described in the table below can be configured using a program on the PC. The program can also load the software to the key or transfer logged data from the controller to disk.

Type	Function	Mode button
B	Update software from key to pRack (BIOS, application, parameters, etc.)	Disabled
C*	Copy software from pRack to pRack (BIOS, application, parameters, etc.)	Switches the key from write mode to read mode

*: Default mode

Tab. 10.a

The key is factory-programmed in read/write mode (type C) so that it can be used immediately to transfer software from one controller to another. When the key is connected to the personal computer, the symbols have the following meanings:

↑ ↓	Flashing	Waiting for connection to PC
↑ ↓	Alternating	When connected to PC indicates data transfer in progress

The programming key is compatible starting from BIOS version 3.43 and BOOT version 3.01. For more detailed information on programming the key, see the pRack Manager program manual.

Using the Smart Key with the pRack

Switch off the pRack, remove any peripherals connected in the pLAN and plug the key into the telephone connector on the controller. When switching on again, all the symbols light up momentarily and the buzzer emits a beep. A few seconds later the key becomes operational. During this period the symbols ↑ ↓ will flash. The controller then enters programming mode and the start button lights up steadily. Press the button to start data transfer.

Important: If the key is type B or C pressing the start button will immediately delete the software already loaded on the pRack.

Important: Do not remove the key while data is being transferred to the key itself, as the file being transferred will be lost and the corresponding space will not be restored. To restore the original capacity all the files will need to be deleted. If the key is type "C", simply perform a new application read operation.

Meanings of Buttons/Symbols

↑ ↓	Flashing: The key is connecting to the pRack. During this phase, which may last a few seconds, the start button is disabled.
start	Flashing: The key has detected the pRack and is checking the access rights.
start + ↑	On steady: Pressing the start button will start writing the software to the pRack.
start + ↓	On steady: Pressing the start button will start reading the software from the pRack.
start + [document icon]	On steady: Pressing the start button will start reading the logs from the pRack.
mode	On steady: In case of C, pressing the button for 1 second switches from read to write.

Tab. 10.b

If the key is type C, pressing the "mode" button for 1 second switches from read to write. The symbols ↑ (write to pRack), ↓ (read from pRack), [document icon] (read logs) reflect the selected status. **If the key is not type "C", the "mode" button is disabled and off.** The "start" button starts the read or write operation, indicated by the flashing of the corresponding symbol (↑ or ↓) at a frequency proportional to the progress of the operation. When the operation is completed, the buzzer will sound intermittently for 2 seconds. Pressing the "start" button again will make the buzzer sound without repeating the operation. To repeat the operation, the key must first be unplugged. In case of error the symbol will light up together with the other LEDs. The following table can help you find the cause of the problem.

Errors before pressing the START button

[Warning icon] + ↑ + ↓	Symbols flashing	Communication error: No response from the pRack or: Key firmware version is incompatible.
[Warning icon] + mode	Symbols steady	Password error
[Warning icon] + mode	Symbols flashing	Type of key is incompatible.
[Warning icon] + ↑	Symbols steady	The key is missing one or more required files (memory empty; no kit for the type of pRack connected).
[Warning icon] + ↑ + start	Symbols steady + flashing start	Incompatibility between the software on the key and the pRack HW.
[Warning icon] + ↑ + mode	Symbols steady + flashing mode	Incompatibility between pRack application and HW (application size).
[Warning icon] + ↑ + [document icon]	Symbols steady	No logged data present on the pRack.
[Warning icon]	Steady	Type of key not programmed.

Tab. 10.c

Errors after pressing the START button

[Warning icon] + start + ↑ + buzzer	Symbols flashing and buzzer sounding intermittently	Write operation failed.
[Warning icon] + start + ↓ + buzzer	Symbols flashing and buzzer sounding intermittently	Read operation failed.
[Warning icon] + start + [document icon] + buzzer	Symbols flashing and buzzer sounding intermittently	Read logs operation failed.
[Warning icon] + ↑ + [document icon]	Symbols steady + flashing	Incompatibility between log configuration and pRack HW (no dedicated flash memory). This error does not prevent writing other files.
[Warning icon] + [document icon]	Steady	Insufficient space to read logs.
[Warning icon]	Flashing	Generic error

Tab. 10.d

10.2 pRack Manager: operating instructions

pRack Manager is a program that lets you manage all the configuration, debugging and maintenance operations on CAREL pRack devices. pRack Manager can be installed by itself or as part of the 1Tool programming environment.

Installing pRack Manager

On <http://ksa.carel.com>, under the section "software & support/ Configuration & updating software/parametric controller software", select pRack_manager. After having selected the most recent version of the tool, click "download" and accept the general terms and conditions for the free software user license; the program can then be installed on the computer.

Connecting the PC to the pRack

Connect a cable with USB/RS485 converter to the USB port on the computer, and connect the converter to a telephone cable plugged into the pLAN port of the pRack. Additional connection methods are described in par. 6.5.




Fig. 10.b

Upon launching, pRack_manager will display a screen showing the connection settings in the upper right-hand corner. Choose:

- 1) "connessione locale" [local connection]
- 2) baud rate: Auto
- 3) "ricerca dispositivo" [find device]: Auto (pLAN)

As for the port number, follow the Wizard's instructions for the port to be identified automatically (e.g. COM4).




Fig. 10.c

Switch the controller off and then on again and use the Connect command to establish the connection. When the connection is established the flashing message "ONLINE" will appear at the bottom left of the screen.



Fig. 10.d

10.2.1 Installing the application to update the software

Select the directory containing the application program files and click "Upload" to upload the program to the pRack controller.




Fig. 10.e

10.2.2 Commissioning

Using the mouse, select "Commissioning" at the bottom left. A new work environment will appear.




Fig. 10.f

Click on "configura dispositivo" [configure device] to display all the application variables. The variables can be selected according to the categories that appear at the bottom.




Fig. 10.g

10.2.3 Changing a parameter

Select the parameter category and then the parameter that you want to edit. The parameter (e.g. recovery.recovery_type) will be highlighted in blue.




Fig. 10.h

1. Double-click on the column marked "letto" [read]. A window will appear in which you can enter the new value for the parameter.




Fig. 10.i

CAREL

2. Enter the new value (e.g. 3) and click OK. The new value will appear in the column marked "scritto" [written]. To write the parameter to the pRack controller, right-click and select "scrivi selezionate" [write selected]. The new value will appear in the column marked "scritto" [written], meaning that the parameter has been written to the controller.

Default	Letto	Scritto
120	120	✓ 120
1	1	✓ 1
5,0	5,0	✓ 5,0
60	60	✓ 60
3,0	3,0	✓ 3,0
0	0	✓ 0
100	100	✓ 100
120	120	✓ 120
4,0	4,0	✓ 4,0
-1,0	-1,0	✓ -1,0
20	20	✓ 20
0,3	0,3	✓ 0,3
0,5	0,5	✓ 0,5
1	1	✓ 1
0	0	✓ 0
1	3	✓ 3



Fig. 10.j

Click on "Salva" [Save] to generate the project's ".2cw" file.

10.2.4 Commissioning: basic concepts

Note: The following paragraphs are from the online help of pRack Manager, to which the user is referred for further details.

Commissioning is a configuring and real-time monitoring software that can be used to supervise the performance of an application program installed on a pRack, to start up the pRack and to perform debugging and maintenance.

Operators using Commissioning for maintenance will be able to see the necessary variables and to draw from preset configuration values.

10.2.5 Support files

Once the design of the application is completed, 1Tool generates a number of files in the compiling stage, two of which are required by Commissioning:

- <nomeApplicativo>.2CF [<ApplicationName>.2CF] (variable descriptor)
- <nomeApplicativo>.2CD [<ApplicationName>.2CD] (category and access profile descriptor)

In addition to these files, the software also manages the <nome applicativo>.DEV [<Application Name>.DEV] file, which contains the unit's preset parameters.

When the user has finished using Commissioning, whether for configuration or monitoring purposes, the following files can be generated:

- <nomeApplicativo>.2CW [<ApplicationName>.2CW] (descriptor for categories, access profiles, monitoring groups)
- <nomefileCommissioningLog>.CSV [<FilenameCommissioningLog>.CSV] (file used for the commissioning log, containing data of the variables logged during monitoring)

Therefore, to configure Commissioning the following files are required:.2CF, 2CD and, if necessary, the.DEV file, which can be imported or exported. For monitoring purposes, in addition to the files above, it might also be necessary to have the.2CW file, containing the definition of the work environment. The commissioning log file is a simple output file.

10.2.6 pRack Load: basic concepts

pRackLoad is the module that manages:

- uploading to the flash memory (of the device or of the ProgKeyX key installed on the pRack);
- uploading to the NAND memory of certain devices;
- downloading the log file,.DEV file and P memory (from the flash memory);
- downloading files from the NAND memory, if present.

The files exchanged with the Flash memories of pRack controllers are:

- BOOT.BIN (download reserved, upload enabled from menu)
- BIOS.BIN (download reserved)
- <nomeApplicativo>.BLB [<ApplicationName>.BLB] (download reserved)

- <nomeApplicativo>.BIN [<ApplicationName>.BIN] (download reserved)
- <nomeApplicativo>.DEV [<ApplicationName>.DEV]
- <nomeApplicativo>.GRT [<ApplicationName>.GRT] (upload only, from which the.GRP file is extracted)
- <nomeApplicativo>.IUP [<ApplicationName>.IUP]
- <nomeApplicativo>.LCT [<ApplicationName>.LCT]
- <nomeApplicativo>.PVT [<ApplicationName>.PVT]
- <nomepRacklog>.BIN, <nomepRacklog>.CSV, <nomepRacklog>_GRAPH>.CSV [<pRacklogName>.BIN, <pRacklogName>.CSV, <pRacklog_GRAPHName>.CSV] (only if log files have been configured, download only).

The files exchanged with the NAND memories of pRack controllers are:

- any file that the pRack can independently copy to the flash memory (see above list);
- external files (e.g..pdf or.doc files for documentation).

10.3 Pendrive: operating instructions

10.3.1 File extensions, names and contents

Various types of files can be uploaded and downloaded and are distinguished by their extension.

File names

In order to be recognised, the names of the directories and files on the pendrive must have no more than 8 characters; the controller makes no distinction between upper-case and lower-case characters. However, during DOWNLOAD the names of the directories created by the controller on the pendrive are always in upper-case.

FILE TYPES FOR UPLOAD

File extension	Description
.IUP	Contains the definitions of the screens on the terminal
.BLB	Contains the application
.BIN	Contains the application (with pLAN table)
.BLX	Contains the Logique of atoms custom in C language
.GRP	Contains the graphics
.DEV	Contains the preset configuration parameter values
PVT,.LCT	Contains the descriptions of the public variables to be logged. Generated by 1Tool, this is used by the LogEditor module and must be loaded together with the.LCT file

Downloaded files are saved in directories created automatically, with the following name format:

NAMXY_WZ

Where:

NAM: identifies the type of data downloaded (LOG for logs, BKP for the application, DEV for the buffer memory, CPY for all the data from the controller).

XY: progressive number from 0 to 99

WZ: controller pLAN address.

Example: a directory named LOG00_01 contains the log files (LOG) downloaded from a device whose pLAN address is 1. Since the key contained no directory of this type before download, it is indicated with 00.



Important: No more than 100 files of the same type can be downloaded to the pendrive, as the directories created can only be numbered with XY=00 to 99.

FILE TYPES FOR DOWNLOAD (controller pLAN address = 1)

File extension	Directory name	Description
.DWL	LOG00_01	Logged data
.DWL,.DEV,.LCT,.PVT	BKP00_01	Application
.DEV	DEV00_01	Non-volatile parameters
.DWL,.DEV,.LCT,.PVT	CPY00_01	All data on the controller

Tab. 10.e

The downloaded files to have fixed names. In particular, the application file is called "ppl-pRack.dwl", the BIOS file "bios-pRack.bin", the files containing the logs and related information are "logs.dwl", "logs.lot" and "logs.pvt", respectively. Finally, the buffer memory is saved to the file on the pendrive.

Menu access

The following are the steps for accessing the pendrive management menu. Procedure:

1. Connect the pendrive to the master port.




Fig. 10.k

2. Press Alarm and Enter together for 3 seconds to enter the option menu. Select FLASH/USB memory and press Enter to confirm.




Fig. 10.l

3. Select USB pen drive and press Enter to confirm.




Fig. 10.m

Important: Wait a few seconds after the pendrive has been plugged in for it to be recognised by the controller. If the message “No USB disk or PC connected” is displayed momentarily with the request to connect a pendrive key or computer USB cable, wait a few seconds until the recognition message is shown (“USB disk found”) and the following screen appears.

4. Select UPLOAD.



Fig. 10.n

10.3.2 Upload

An application plus BIOS or buffer memory (parameters) can be uploaded from the pendrive. The following modes are available: automatic, autorun and manual. Automatic and autorun modes require using configuration files.

Configuration file structure

Configuration files must start with the string “[FUNCTION]” followed by a string that identifies the function, as shown in the table.

Function	String
UPLOAD an application or a BIOS file plus an application	Upload application
UPLOAD non-volatile memory (.dev)	Upload non volatile memory
UPLOAD the entire contents of the pRack	Copy pRack upload

After the description of the desired function, various options are available:

1. To copy the complete contents of the directory, simply write the name of the directory (e.g. the entire contents of the CHILLER directory):

```
[FUNCTION]
Upload non volatile memory

[DIR]
CHILLER
```

2. To copy just 1 file in a directory, enter the file's name (e.g. the CHILLER.DEV file in the CHILLER directory).

```
[FUNCTION]
Upload non volatile memory

[DIR]
CHILLER

CHILLER.DEV
```

To show a string on the display describing the operation being performed, add the “[NAM]” instruction, followed by the string to display. The following file will display the string:

```
“UPL CHILLER.DEV”

[FUNCTION]
Upload non volatile memory

[DIR]
CHILLER

[NAM]
UPL CHILLER.DEV

CHILLER.DEV
```

3. To select only some of the files in the same directory, list them after a label. The following labels are allowed and **must be entered in the order shown in the table:**

UPLOAD file labels

No.	Label	File type	No.	Label	File type
1	[BIO] (*)	file.bin	6	[PVT]	file.pvt
2	[IUP]	file.iup	7	[LCT]	file.lct
3	[BIN]	file.bin, blb	8	[OED]	file.oed
4	[DEV]	file.dev	9	[SGN]	file.sgn
5	[GRP]	file.grp			

(*) BIO = BIOS file



Notes:

- to get the .bin file from the BIOS in the format available on <http://ksa.carel.com> (.os file), unzip the .os file;
- the [IUP] label can be followed by one or more “.iup” files.



Important:

- the order in which the file names are entered is fundamental and must not be changed;
- do not enter empty lines or spaces in the file (e.g. at the end of a line);
- each file after the last line of code must contain a “carriage return” character (CR↵), as shown in the following example.

Example: The following file will upload the BIOS and an application.

```
[FUNCTION] ↵
Upload application ↵
↵
[DIR] ↵
NEW AHU ↵
↵
[NAM] ↵
BIOS+APPL+LOGSv58B36 ↵
↵
bisn509.bin ↵
↵
[IUP] ↵
AHU_EN.iup ↵
AHU_IT.iup ↵
↵
[BIN] ↵
AHU.blb ↵
↵
[DEV] ↵
AHU.dev ↵
↵
[GRP] ↵
AHU.grp ↵
↵
[PVT] ↵
AHU.pvt ↵
↵
[LCT] ↵
AHU.lct ↵
```

10.3.3 Automatic upload

To automatically upload the parameter memory using the first configuration file shown in the preceding paragraph, access the system menu as previously described and proceed as follows:

1. Select automatic mode. A screen is shown describing the function of the buttons. Press Enter to confirm.




Fig. 10.o

2. Confirm by selecting Prg. A screen is displayed requesting confirmation to upload the non-volatile memory. Press Enter to confirm.




Fig. 10.p

3. At the end a message will ask the user to remove the pendrive.




Fig. 10.q

10.3.4 Upload in autorun mode

Uploading in autorun mode is a special case of uploading in automatic mode. Unlike automatic mode, the user must wait for a specific message to appear on the display to start or disable the operation described in the configuration file. To upload a file in autorun mode, a configuration file must be created and named "autorun.txt". Example of uploading BIOS+application. The upload involves two steps: first the BIOS is updated and then the application. The information is shown on the pRack's built-in display and on the pGDE terminal, when both are featured.

Procedure:

1. Connect the pendrive to port A.



2. After a few seconds, Autorun mode starts. Press Enter to confirm.



Fig. 10.r

3. The validity of the FW is checked and the BIOS is loaded.




Fig. 10.s

4. The display flashes to indicate that after loading the new BIOS the controller is being reset.



Fig. 10.t




Fig. 10.u

5. The test phase starts.




Fig. 10.v




Fig. 10.w

6. The controller warns that no application has been loaded.




Fig. 10.x




Fig. 10.y

7. The application update then starts.




Fig. 10.z




Fig. 10.aa

8. Remove the pendrive. The update is complete. Wait for the display to stop flashing, indicating that the controller is being reset before restarting.



Fig. 10.ab




Fig. 10.ac

! Important: As can be seen, when updating the BIOS and the application, the pGDE terminal shows the message “NO LINK”, meaning that no connection is established. Do not remove the terminal and wait for the end of the update procedure, when the pGDE terminal replicates the messages on the built-in display.

▶ Note: Autorun run is especially useful in those cases in which the same operation needs to be performed on several controllers. For example, to load different applications on controllers connected in a pLAN network, only one autorun file needs to be created; this uploads the various directories contained on the pendrive based on the address of the controllers. The controller with address XY will only load the directory called “nomedir_XY” [“DirName_XY”]. The pendrive then only needs to be plugged into each controller to run the upload, confirming from the shared terminal.

10.3.5 Manual upload

To manually upload the contents of the pendrive the user must access the management menu from the system screens, selecting UPLOAD and then MANUAL. The files are selected by pressing ENTER when the cursor is on the desired file name. A selected file is marked by the symbol “*” on the left. Once the files have been selected (all in the same directory), press PRG to start the upload. To display the contents of a directory press ENTER. To go up one directory level press ESC. Once the upload has started, the messages shown on the screen are the same as in automatic and autorun mode.


10.3.6 Download

As mentioned above, the DOWNLOAD operation can be managed in two ways:

1. Manual mode: follow the steps described in the paragraph “Automatic upload” and select manual operation. Then each file must be selected and downloaded.
2. Autorun mode: prepare a file called “autorun.txt”, containing a string that identifies the function to be performed.

Function	String
DOWNLOAD the application	Download application
DOWNLOAD non-volatile memory	Download non volatile memory (.dev)
DOWNLOAD the entire contents of the pRack	Copy pRack download

The result is the creation of files with the required extensions, which will be placed in the respective directories as described in the paragraph “File names”. When the operation is completed, the display shows a message with the name of the directory created.



The following screen will be displayed.

1. Press Enter to confirm.




Fig. 10.ad

2. Download completed.



Fig. 10.ae

11. APPENDIX

A.1 System configurations with more than one pLAN board

If the system configuration involves the connection of more than one board in a pLAN, the addresses must be set correctly before selecting a configuration solution. pRack pR300T can use two user terminals (as well as a built-in terminal) with addresses 31 and 32. The default user terminal address is 32, so only if a second terminal is required must the address of this be set to 31, as described below. The address of the terminal is also required when having to set the address of the pRack pR300T boards, when multiple boards are connected to the pLAN. After having correctly connected and configured the pLAN network of pRack pR300T boards, the system can be configured as described in paragraph 4.1.

A.1.1 Setting the terminal address

The pRack pR300T user terminal is supplied with the default address 32, allowing the terminal to be used without requiring any additional operations; nonetheless, in order to use an additional terminal or configure the pLAN address of the boards, it needs to be changed according to the following procedure:

1. power the terminal via the telephone connector;
2. press the three buttons **↑**, **↓** & **←** together for at least 5 seconds; the terminal will display a screen similar to the one below, with the cursor flashing in the top left corner:




Fig. A.a

3. press **←** once: the cursor will move to the "Display address setting" field;
4. select the desired value using **↑** & **↓**, and confirm by pressing **←** again; if the value selected is different from the value saved, the following screen will be displayed and the new value will be saved to the display's permanent memory.




Fig. A.b

Note: if the address field is set to 0, the "I/O Board address" field is no longer displayed, as it has no meaning.

Important:

- if the settings are not made correctly, the text and the images on the display will be displayed incorrectly and out of order.
- if during this operation the terminal detects inactivity of the pRack board whose output is being displayed, the display is cleared and a message similar to the one below is shown.




Fig. A.c

If the terminal detects inactivity of the entire pLAN network, that is, it does not receive any messages from the network for 10 seconds consecutively, it clears the display and shows the following message:




Fig. A.d

A.1.2 Setting the pRack pR300T board address

The pLAN address of the pRack boards can be set from any pGD1 terminal, using the following procedure:

1. set address 0 on the terminal (see the previous paragraph for details on how to set this address);
2. power down the pRack pR300T board;
3. disconnect any pLAN connections to other boards from the pRack pR300T board;
4. connect the terminal to the pRack pR300T board;
5. power up the pRack pR300T board, while pressing **↑** & **▲** on the terminal together. After a few seconds the pRack pR300T board begins the start-up sequence and the display shows a screen similar to the one below:




Fig. A.e

6. when this screen is displayed, wait 10 seconds and then release the buttons;
7. the pRack pR300T board interrupts the start-up sequence and shows a configuration screen, similar to the one below :




Fig. A.f

Then, modify the pLAN address using the **↑** & **↓** buttons on the terminal.

8. Confirm the address by pressing **←**: the pRack pR300T board completes the start-up sequence and uses the set address.

1. Displaying the pLAN address

- press briefly (no more than 5 seconds) button A to display the current controller pLAN address. The display is cleared 5 seconds after releasing the button.




Fig. A.g

Setting the pLAN address

1. press button A for 5 seconds. The pLAN address will start flashing;
2. press repeatedly or press and hold the button until reaching the desired address (e.g. 7); remove the screwdriver;
3. wait until the address starts flashing quickly. The address is now saved but not yet active for the application program;
4. power down the controller;
5. power up the controller again. The address will now be activated.




Fig. A.h

CAREL

CAREL INDUSTRIES - Headquarters
Via dell'Industria, 11 - 35020 Brugine - Padova (Italy)
Tel. (+39) 049.9716611 - Fax (+39) 049.9716600
e-mail: carel@carel.com - www.carel.com

Agenzia / Agency: